



Product Introduction



CYBERBLUE POWER TUBE MagStation is a magnetic wireless charging speaker, capable of wireless charging mobile phones and other devices, strong magnetic force to hold mobile phone firmly, worry of misplacement charging is a thing of past. The top charging cover can be opened with the magnetic device, and the maximum 60° artificial scientific angle can be adjusted, which is convenient to release the pressure on hands during the process of phone watching and gaming or learning. The bottom supports 5W output charging, like smart watch, Bluetooth headset and other wireless charging devices. Built-in Bluetooth 5.0 Bluetooth speaker, high-definition call function, using $\phi 40\text{mm}$ full-frequency diaphragm unit, high-resolution and low-latency sound quality, bringing higher audio-visual enjoyment.

SPECIFICATIONS

Input Voltage/Current: 5V  2A(Max) 9V  3A(Max)

Input Interface: TYPE-C

Sensing Distance: 5mm(Max)

Transmit Power: 4 dBm

Working Frequency: 2.4G ISM wave band,2.402-2.480GHz

Size: 63mm*63mm*83mm

Transfer Distance: >10M

Wireless Output: 5W~15W

Standby Power Consumption: <0.7W

Bluetooth Output Power: 3W

Modulation: GFSK, $\pi/4$ DQPSK, 8DPSK

Receive Sensitivity: -88dbm(typical)

Weight: \approx 300g

Suitable Ambient Temperature: 0-45°C

USAGE

Charge your phone or mobile devices:

1. Connect DC power, insert the TYPE-C cable into the C port to supply power.
2. Place the mobile phone or mobile devices on the middle of the product, there is a prompt when the wireless charger and the mobile phone connected successfully, and the status light will be on.
3. Open the lid of the product, and put the watch or other mobile devices in the center, there is a prompt for charging if the wireless charger connected successfully with the smart watch.
4. Foreign Body Induction: When putting is a non-wireless charging metal object on it, the status light will flashes quickly to indicate that the device is wrong.

Bluetooth connection operation:

1. Power on: Short press the button for 1s, the Bluetooth is turned on(with prompt voice “Bluetooth mode”), the blue light below the button flashes 3 times.
2. Turn on the Bluetooth of your mobile phone, search the device pairing name: BS300, and click to connect.
3. When there is an incoming call: Short press to answer and hang up the call; long press for 3 seconds to reject the call.
4. When playing music: Short press to pause and play.
5. Power off: Press and hold the button for 3 seconds to shutdown in the power-on state(there is a prompt sound “POWER OFF”); or automatically shutdown in 10 minutes in the unconnected mode.

! NOTICE: Using a charger that does not meet the specifications may render the product unusable and even damage the product. In addition, it is recommended to use a fast charging adapter above 20W.

SAFETY PRECAUTION

Read all instructions and warnings prior to apply this product. Improper usage may result in product damage, excess heat or even fire.

1. Carefully read the instructions before using.
2. Choosing the USB power adapter with caution, ensure the product has security certificates.
3. Do not open or disassemble the product or apply destructive force on it.
4. Protect from water and moisture.
5. Keep the product in a place where children are not easy to get it, to avoid any danger.
6. Disconnect the phone from wireless charger after charging.
7. Check out if your device fulfill the product's requirement. Or please contact dealer for more details.

SAFETY WARNING:

1. Please do not use metal case or place any metal or magnetic objects between phone and wireless charging speaker during wireless charging, avoid excess heat at your own risk.
2. Fast charging of mobile phone would generate additional heat, if it is over heated, the mobile phone will automatically stop charging for safety protection. It needs to wait for a while till the phone cool down, and then re-charging for the phone.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WARRANTY CARD

Thanks for your purchase of CYBERBLUE's product. CYBERBLUE warrants that the product is at the time of its original purchase free of defects in workmanship and material. This limited warranty for the product shall last for twelve(12) months from the date of original purchase. This original warranty card and original invoice must be presented at the time you require warranty service or such warranty will be voided. This limited warranty is valid only if the product is used for the purpose for which it was designed. It does not apply to damage or loss caused by negligence; physical abuse; misuse; accident; exposure to moisture; dampness or extreme temperatures; unauthorized modifications; unauthorized opening or repair; force of nature; or other actions beyond the reasonable control of CYBERBLUE. In case of when the warranty does not apply, a repair or replacement charge will be incurred. The customer shall be responsible for sending the defective products to and collecting the repaired or replaced product from the service center.

Product Name: _____

Model No.: _____

Purchase Date: _____

Dealer Shop: _____

Customer Name: _____

Order No./Website Name: _____

Mobile Phone No.: _____

Contact Addr.: _____

Postal Code: _____

Failure Description: _____

For more efficiency on handling your case, please provide correct info and mail with the failure product to CyberBlue authorized repair center.



Responsible Party:

Company name:

Address:

Tel:

E-mail