Luxury Massage Chair

Operation Manual

catalog

One、catalog
Two, Safety precautions
1. Usage environment
2. Not suitable for use
Three, Preparation before use
1、Cushion installation
2. Sitting posture adjustment
3. Moving method of massage chair
4. Placement of massage chair
5. Poweron!
Four、Main structure name and function
Five, Introduction of control panel function
Six, Massage program operating instructions
Seven, Daily maintenance
Eight, technical parameter

Warm tips: our company reserves the right to improve the products and instructions. We are subject to change without notice. The appearance of the products shall be subject to the actual products. If there is any difference between the products and the real products due to product upgrading or other reasons, please refer to the real products.

Product warranty card

Dear users:

Thank you for using our products. We will provide you with the following services with this warranty card in accordance with the relevant provisions of the consumer protection law:

1. During the warranty period, if the fault is caused by the quality problem of the product itself, please bring the filled warranty card to the repair center authorized by our company.

Certificate OF Qualification

delivery in strict accordance with the indicators of inspection, allowed to

leave the factory.

Inspection number

date of manufacture

The company's products before

- 2. Once the warranty card is altered, the warranty will be invalid immediately.
- Keep the warranty card as the warranty certificate of this machine. Please keep it properly.

Maintenance service guarantee

Please contact our customer service center if there is any problem with this product.

This product is guaranteed for one year.

One of the following conditions is not covered by the warranty:

- Damage caused by improper use, storage and maintenance of consumers.
- Damage caused by assembling, disassembling and repairing by the company's designated maintenance department.
- 3. Damage caused by force majeure.
- 4. Leather cover, manual controller and consumable accessories are not covered by the warranty.
- 5. Our company is not responsible for the quality accident caused by using our non-standard gifts.
- 6. This product is used for non home use and will not be covered by warranty.
- 7. Failure caused by human or improper use is not covered by warranty.
- 8. The machine failure caused by the parts that do not conform to the product parameters purchased without permission is not within the scope of warranty, and the accidents caused are not within the scope of our company's responsibility.
- 9. For products not covered by warranty, our customer service center will still serve you warmly.

This volume has been carefully checked, but it does not exclude possible printing errors or misunderstandings. We reserve the right of interpretation, please understand.

User warranty certificate

(saved by the user and presented to the maintenance site during maintenance)

Product name:		
m o d e l :		
Place of Origin:		
Warranty period:		
Purchase date:		
Maintenance records:		
Date of repair:		
Failure, maintenance and treatment		
Maintenance unit:	Signature of maintenance personnel:	

Four, mode switching

Automatic mode: According to the automatic mode, there are 5 automatic programs to choose from.

Manual mode: In automatic mode, press other function buttons to switch to manual mode, and you can choose single

or multiple massage functions.

Five, Bluetooth connection instructions

1 The bluetooth is turned on by default when it is turned on and the voice prompt is given.

Note: Pillow, hand control bracket, bluetooth music, foot rollers, only available for high-end models!

Seven, daily maintenance

- (1) The massage chair should be kept clean and dust–free at all times and placed in a non–damp place.
- (2) If you will not use it for a long time, please cover it with a cloth.
- (3) Do not place the massage chair in the sun or in a place with high temperature, which will cause the leather of the massage chair to fade and accelerate aging.
- (4) To clean the massage chair, please turn off the main power switch and pull out the power plug.
- (5) Do not use detergents containing organic solvents, such as benzene, to clean the massage chair, otherwise it will cause the leather to discolor, age, or crack.
- (6) If the power cord is damaged, it must be replaced with a special cord or special components purchased from its manufacturer or maintenance department.

Eight, Technical parameters

product name: Luxury massage chair

Rated voltage: 110V~ Rated frequency: 60Hz Rated power: 120W

Rated working time: 20min

Executive standard: GB4706. 10-2008

GB4706.1-2005

Product safety design: I

Two, Safety precautions

1. Use environment

- (1) Do not use or keep this machine in particularly humid environments such as bathrooms, saunas, hot springs, etc, to avoid mold, electric shock, fire or mechanical failure.
- (2) Do not use in an environment where the room temperature is above 40 degrees Celsius.
- (3) Do not use this machine outdoors.
- (4) Do not place the machine in an environment with too much dust, oil, or lack of oxygen.
- (5) Do not place the machine in a hot air stove, stove or a place exposed to direct sunlight. This will cause the parts in the massage chair to overheat and cause fire.
- (6) Do not use this machine on uneven places. Please place the bracket on a level place such as the floor.
- (7) To prevent electric shock, please confirm whether the socket is grounded. Please consult the sales store when installing the ground wire in the socket.
- (8) Do not use when smoking.
- (9) When the airbag is inflated, do not pull out the limbs such as arms and legs, which will cause the airbag to fall off and need to return by itself.
- (10) Do not step on the sole rollers or airbags, please pay attention to getting in and out of the massage chair! If it falls off, you need to fix it back.







2. Those who are not suitable to use this appliance

The following people please consult a doctor before using (may cause physical discomfort or even accidents and cause danger)

- (1) Patients with malignant tumors or malignant tumors.
- (2) Patients with severe heart disease.
- (3) Patients with severe skin diseases.
- (4) Patients with severe bone hyperplasia.
- (5) Those who are pregnant.
- (6) Being recuperating under the instructions of a doctor, especially those who feel abnormalities in their body.
- (7) Those who have abnormal spine or curved back due to accident or disease.
- (8) Those who need silence.
- (9) Those with joint deformities.
- (10) Those with medical devices such as pacemakers.
- (11) Those with acute symptoms such as visceral diseases (such as gastritis, enteritis, dysentery, hepatitis, etc).
- (12) Those with severe blood circulation disorders in the legs.
- (13) People with sensory impairments, the surface of the hot air piece becomes hot, and people who are not sensitive to heat must be careful when using it.
- (14) Those with high fever symptoms.
- (15) This product is not recommended to be used by people (including children) who are physically impaired, sensory or mentally impaired, or lack relevant experience and knowledge, unless someone responsible for their safety supervises and guides their use of this product.
- (16) Children should be taken care of and ensure that they do not play with this product.
- (17) If the power cord is damaged, it must be replaced with a special cord or special component obtained from the manufacturer or its maintenance department.




WARNING

Don't let people under 18 years old and those who can't control their behaviorPeople (such as: mental patients, mentally retarded people, paralyzed patients, etc) are aloneOperate massage chair or touch all parts of massage chair. It's possibleCausing electric shock or injury to users or machine failure.

.2.

Three, preparation before use

1, Cushion installation



2. Seat adjustment

To adjust the seat back, press and hold the hand control adjustment switch to adjust the tilt angle of the seat back.

Requirement: When adjusting the backrest and leg cushions, make sure that there is enough space before and after the massage chair.

Six, Massage program operating instructions

Standby key: press" (1) "to turn on / off the massage function of the whole machine.

When the power is on, press this key to massage the chair line to the initial angle, and the body detection will be carried out automatically.

After that, the first automatic program will be run by default.

The default working time of leisure massage is 20 minutes.

Automatic massage program key: according to your body state and massage time, you can choose "leisure and relaxation", "fatigue recovery", "relaxation of meridians and activating collaterals", "impr-ovement of pain" "Sedative sleep", any one of the five massage pro-cedures for targeted massage. (see the LCD screen for details)

Back adjustment:

Press the "Backup" key, the back of the chair will start to rise slowly, at the same time, the tripod will slowly descend. After the angle is

in place, release this key, and the seat back and foot rest will be locked.

Press the " Back down " key, the back of the chair will start to descend slowly, at the same time, the tripod will rise slowly. When the angle is in place, release this key, and the seat back and foot rest will be locked.

Manual massage: press" [Manual]" to select "massage", knead", "pat", "thump", "finger press", "knead", "knead hammer", "Rubbing and scraping" massage method.

Position adjustment: in manual mode, adjustable back massage position moves up and down. (press " Up " to move position every 2 seconds).

Automatic air pressure: press " This key can turn on or off the air pressure.

Manual air pressure: press" [Vanual pressure] "to turn on or off the air pressure manually.

Air pressure intensity: press the "Air intensity" key to adjust the air bag strength (1-3).

Foot roller: press "Sole roller "key to turn on or off foot roller massage.

Massage speed: press" [Speed] "to adjust the massage speed.


Width adjustment: press" Width "to adjust the width.

Whole process local massage: press" [Fartitle Attle] "to turn on or off the whole local massage.

Heating: press" Heating "to turn on or off heating massage.

Zero gravity: press " [Zero gravity]" key to make massage chair in zero gravity state.

Five Brief introduction of control panel function



3. Moving method of massage chair

When moving, lift the armrest on both sides and move it.

be careful! Don't move people.

Don't use small pulleys to move on easily damaged floors.

4, Placement of massage chair


Please leave space around the massage chair when you are preparing for massage

- (1) There should be enough space for the massage chair to lie on the back and lift the foot rest.
- (2) Make sure there is at least 80 cm in the back and 50 cm in front of the chair.
- (3) Make sure there are no obstacles in front of and behind the massage chair.
- (4) In order to prevent the ground from being damaged, please place a carpet under the massage chair to avoid damaging the floor.

Insert the plug into the power socket and turn on the power switch.

be careful

- ①. Please check whether the power cord is pressed under the massage chair.
- 2. Whether the ground wire is well connected.
- ③.Before inserting the plug, make sure that all operation buttons (including the main power switch) are turned off.



6. FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found tocompy with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These

limits are designed to provide reasonable protection against harmful interference in a residentia installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions. may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particulan

installation. f this eauipment does cause harmfulinterference to radio or te evision reception.

which can be determined by turning the equipment off and on, the user is encouraged to try to

correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- --Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.