

Warranty terms

Heart of Loulan--Myth Beast-LT1

Please reading the TWS informations carefully and keep it properly before use



Bluetooth pairing on/off

1. Connect to the IOS/ Android phone for the first time (make sure the Bluetooth connection function is enabled)



(1)Open the top cover of the Bluetooth earbud

Bluetooth connection Bluetooth connection Find True Wireless Stereo Find True Wireless Stereo Heart of Louian--Myth Beast

②Open the Bluetooth pairing list to find 3 Click on the pairing name to connect

- 1: After there is a pairing record, open the top cover of the charging case and the earbuds will automatically It the earbuds back in the charging case and close the top cover of the charging case. The earbuds will be harged automatically. If the earbuds is connected, it will be disconnected automatically, 2.1: When the levice turns off Bluetooth or is beyond the range of earbuds connection, the earbuds enters the e. If the device is not connected for more than 5 minutes, the earbuds will automatically shut dow
- Due to the connection characteristics of the Bluetooth signal, in places where the electromagnetic signal of 2.4GHz interferes dense, it may occasionally intermittently disconnect or no sound.
 After use, please put the Earbuds back into the charging case in time to extend the service life and

Touch operation 1. Music playing

Left/right Earbuds

Left/right Earbuds





Double-click the touch position on right earbuds Single press the touch position on left or right earbuds

2. Call operation Single press the touch position on the left or right earbuds





3. Basic operation


Long press the left or right earbuds touch position for 3 seconds Long press the left or right earbuds touch position for 5 seconds

Triple-click the touch position on the left or right earbuds

I1 Game/music mode switching Long press the left or right earbuds touch position for 2 seconds 12 Disconnect and enter pairing mode Five click left/right earbuds touch position

13 Factory data reset Long press the left or right earbuds touch position for 10 seconds


Charging mode of charging case&Earbuds



insert the TYPE-C cable into the charging port of th

loss of the charging case caused by a long ti charged or not fully charged for a long time.

is fully charged(* When the charging case is low: the



The battery capacity, playing time, and charging time are obtained from standard charger tests at room emperature in the laboratory. The actual data may vary due to factors such as using environment and ndividual charger differences. Product specifications and parameters are laboratory test data, this manual is for reference only, specific functions and product pictures may be slightly different from If the charging case is not used for a long time, charge it at least once a month to avoid over-discharge or power loss of the charging case caused by a long time of unused use. As a result, the charging case may fail to be

case will blink for 15 seconds. There is no indicator ligi

during charging (Check, the charging case has power

Specification

Product model	Heart of LoulanMyth Beast-LT1
Operation mode	Touch operation
Speakersize	φ 13mm, 32 Ω
Charging port	TYPE-C
Bluetooth version	BlueTooth V5.3
Bluetooth protocol	A2DP AVRCP HFP HSP SPP
Earbuds battery capacity	3.7V / 40mAh
Charging case battery capacity	3.7V /400mAh
Noise Canceling	Dual microphone environment noise canceling (Dual ENC)
Low latency	<30mS
Earbuds charging time	< 1 hours
Charging case charging time	About 2 hours
Earbuds play time	About 6 hours (50%volume)
Standby time	About 24 hours
Bluetooth distance	≥10M(without any obstacle)
Rated input voltage/current of charging case	5V±0.5/1A
Rated output voltage/current of charging case	5V±0.5/1A
Working temperature	-10°C ~ 60°C

Problems caused by accidental operation errors or unknown reasons and solutions

Question 1	After the earbuds are connected to the mobile phone, one of the earbuds has a sound while the other one has no sound
Possible causes	The single earbuds no power The single earbuds damged . The single earbuds are not paired. Please repair them. The left and right earbuds are not paired. Please repair them. The elastic pin of the charging case corresponding to the silent earbuds is not in good contact. As a result, the earbuds cannot be turned on
Processing method	A. For reasons 1, you can charge the earbuds; B. For reasons 4, you can check whether the tail plug of the earbuds and the spring pin of the charging case are dirty. C. For reasons 2 and 3, after-sales treatment should be carried out after testing and confirmation;
Question 2	Can't search the bluetooth pairing name
Possible causes	The Hall effect sensor of the charging case is faulty. As a result, the earbuds cannot be turned on after the cover is opened 2. The charging case or earbuds are not connected, so the earbuds cannot be turned on 3. The earbuds is in poor contact with the metal spring pin in the charging case. As a result, the earbuds cannot be turned on after the cover is opened 4. The charging case or earbuds are damaged 5. The earbuds is unpaired, so that the earbuds is always in TWS pairing mode after the earbuds is opened.
	A. For reasons 3, you can detect whether the earbuds tails and charging casees are dirty.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver

-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction. Correct Disposal of This Product (Waste Electrical & Electronic True Wireless

Stereo)(Applicable in countries with separate collection systems) This marking on the product, accessories or literature indicates that the product and its electron ries should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them esponsibly to promote the sustainable reuse of material resources. Household users shou ontact either the retailer where they purchased this product, or their local government office for details of where and how they can take these items for environmentally safe recycling siness users should contact their supplier and check the terms and conditions of the urchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

of serious expansion, leakage and other abnormal conditions, please stop using. Do not use in high temperature environment

ompany Name: BETWEEX COSMETIC CO. LTD. Address: B01, 3rd Floor, Makerspace, No. 368, South Jiangnan Avenue Haizhu District, Guangzhou City, Guangdong Province, China Email: topbeauty@info-top.cn Website: www.heartofloulan.com Official Tmall Store: Loulanzhixin Digital Flagship Store Tel: 17328314605




Installation diagram







3. Install 3 on the main body




4. Install 4 5 socket head cap screws on the main body and fix them with a










special socket head cap screwdriver

Installation diagram



5. Install (6) at the bottom of the body 6. Install (7) 8 on the left and right sides of the main body



7. Buckle the 9 upper cover onto the main body buckle (as shown in the above diagram), and then use the special hexagonal socket screwdriver to fix the @ 11/12 hexagonal socket screws on the back of 9


Installation diagram





8. The installation is complete





*(3), (4), (5), (6), (7) The above screws are quincunx type non removable screws. Do not remove them, which may cause damage to the product

After-sales Service Description

Dear users, thank you for using our products.

We will provide you with no less than the national three guarantees policy of after-sales service, service content is as follows: . Within 7 days from the date of purchase, if the product fails to meet the conditions

listed in the list, the product can be returned or replaced free of charge upon detection 2. Within 8 to 30 days from the date of purchase, if the product fails to meet the conditions

listed in the list, the product can be replaced or repaired free of charge upon detection

3. Within 12 months from the date of purchase, if the product fails to meet the conditions listed in the list, it can enjoy free maintenance service after detection and confirmation;

Product performance Fault list	Charging case	1.The charging case cannot be charged
		2. The open cover does not work or the Hall effect sensor is faulty
		3. The button is stuck or no effect
		4. Damaged to charging interface (non-man-made)
		5.Main body damaged caused by structural or material factors
	Earbuds	1.Speaker no sound.
		2.Microphone damaged
		3.The touch/pressure operation no effect
		4.The earbuds cannot be charged
		5. The functions listed in the manual fail
		6. Damaged of the main body caused by structural or
		material factors

n the process of user use, one of the following conditions is not within the scope of

- . Beyond the warranty period; . There is a time limit for more than three packages;
- . Failure to meet the requirements listed in the Product Performance Fault List;
- . Performance faults listed in the "Product Performance Fault List" occur due to human causes 5. Damage caused by irresistible factors (such as fire, earthquake, lightning strike, etc.):
- 3. Unauthorized maintenance, misuse, collision, negligence, abuse, liquid injection, accident, change, incorrect use of non-product parts, or tear down, alter label stickers security marks, damaged bar codes, relevant vouchers;

Safety instructions

Before using and operating the True Wireless Stereo, please read and observe the following precautions to ensure the best performance of the True Wireless Stereo and avoid dangerous

Electronic True Wireless Stereo

Do not use this True Wireless Stereo in places where it is expressly prohibited to use wireless True Wireless Stereo, otherwise it will interfere with other electronic True Wireless Stereo

Impact on medical True Wireless Stereo

In medical and health care places where the use of wireless devices is prohibited, please observe the regulations of the place and turn off the True Wireless Stereo.

The radio waves generated by the True Wireless Stereo may affect the normal operation of the implantable medical True Wireless Stereo or personal medical True Wireless Stereo, such as the arm puller, cochlear implant, hearing aid, etc. If you use these medical devices, please consult their manufacturers for restrictions on using this device.

Hearing protection When you listen to music or call with headphones, it is recommended to use the minimum

Prolonged exposure to high volume may cause permanent hearing loss.

Exposure to high volume while driving may distract attention and cause accidents.

Please observe the relevant regulations of your country or region, and do not use this product when driving. Remember that safe driving is your primary responsibility. Do not engage in activities that may

e electronic True Wireless Stereo of the car may fail due to the radio interference of the rue Wireless Stereo. Please contact the manufacturer for details.

Wireless True Wireless Stereo may interfere with the flight system of the aircraft. Please comply with the relevant provisions of the airline. Do not use wireless True Wireless Stere where it is prohibited Operating environment

Do not use the True Wireless Stereo in a damp place or near the magnetic field, so as to avoid internal circuit failure of the True Wireless Stereo.

Do not use this True Wireless Stereo in thunderstorm weather, which may cause True Wireless Stereo failure or electric shock to the face.

Please use the True Wireless Stereo within the temperature range of 2 °C ~45 °C , and store the ue Wireless Stereo and its accessories within the temperature range of - 10 °C ~50 °C When the ambient temperature is too high or too low, it may cause device failure. When the temperature is lower than $5\,^{\circ}$ C, the battery performance will be limited.

Do not place the True Wireless Stereo in direct sunlight, such as the dashboard or window sill. o not place the True Wireless Stereo near heat source or exposed fire source, such as electric heater, microwave oven, oven, water heater, furnace fire, candle or other places

o not place sharp metal objects, such as pins, near the earpiece or loudspeaker of the device prevent metal objects from attaching and causing harm to you.

that may generate high temperature.

he real object, please refer to the real object

his device and its accessories may contain some small parts. Please keep the device and its accessories out of the reach of children.

Children may unintentionally damage this True Wireless Stereo and its accessories, or swallow small parts to cause asphyxiation or other hazards. This device is not a toy. Children should use the device under the supervision of adults.

Requirements for accessories Only use the accessories approved by the True Wireless Stereo manufacturer and matcher with this type of True Wireless Stereo. If other types of accessories are used, it may violate the warranty terms of the True Wireless Stereo and the relevant regulations of the country where the True Wireless Stereo is located, and may lead to safety accidents. For approved accessories

Please contact the authorized service center.

not disassemble or modify the battery, insert foreign matters, or immerse in water of other liquids to avoid battery leakage, overheating, fire or explosion. Do not drop, squeeze or proucture the battery. Avoid exposing the battery to external pressure, which may cause internal short circuit and overheating of the battery.

ne device is equipped with a non removable built-in battery. Do not replace the battery Ti reless Stereo with non removable built-in battery. Do not replace or remove the battery Dispose of used batteries according to local instructions.

Processing

method

When the earbuds is not in use, please put it back into the charging case to prevent loss and

B. For reasons 2, you can check whether the tail plug of the earbuds

C. For reasons and 4 need to be tested and confirmed, after -sales

and the spring pin of the charging case are dirty.:

Please keep the True Wireless Stereo and its accessories dry. Do not use external heating True Wireless Stereo such as microwave oven or hair dryer to dry them.

on ot place the True Wireless Stereo and its accessories in areas where the temperature is bo high or too low, otherwise the True Wireless Stereo may malfunction, catch fire or explode. efore cleaning and maintenance, please stop using this device, close all applications, and isconnect all connections or cables with other devices.

Do not use strong chemicals, cleaning agents or strong detergents to clean the True Wireless Stereo or its accessories. Please use a clean, dry soft cloth to wipe the True Wireless Stereo or

to not touch the magnetic strine card (such as bank card, telephone card, traffic card, etc. with the device for a long time, or the magnetic stripe card may be damaged by the magnetic ield. Do not disassemble or modify the True Wireless Stereo and its accessories without horization, otherwise the True Wireless Stereo and accessories will not be covered by

In case of True Wireless Stereo failure, please contact the authorized service center.

o not swallow headphones. Children and minors should use this device under the supervision of their guardians to prevent swallowing

environmental protection Do not treat this True Wireless Stereo and its accessories as ordinary household garbage

Please comply with the local regulations on the disposal of this True Wireless Stereo and its accessories, and support the recycling action.

True Wireless Stereo Warranty Card

Name/contact phone/address/email/QQ/WeChat

Product Information Model/SN code/purchase date/purchase address /contact number/invoice information

Please ensure that the above information can help us quickly understand the product related information and timely contact you in the follow-up service.

Contents of product warranty

Contents of product warranty	

