







Band38-10MHz-16QAM-38000-1RB#0-20000-27000-PASS




Band38-10MHz-16QAM-38200-1RB#0-0.009-0.15-PASS



Band38-10MHz-16QAM-38200-1RB#0-0.15-30-PASS



Band38-10MHz-16QAM-38200-1RB#0-30-1000-PASS



Band38-10MHz-16QAM-38200-1RB#0-1000-20000-PASS



Band38-10MHz-16QAM-38200-1RB#0-20000-27000-PASS

