

AYAERI WIRELESS EARBUDS

INSTRUCTION

Earbuds Specification

Bluetooth Version : v5.0

Battery : 30mAh Lithium Battery*2

Protocol Support: HSP/HFP/A2DP/AVRCP

Codec : SBC/AAC

Signal Range : 10m、Class 2

Playtime : 4-5 Hours

PLEASE NOTE:

1. Once connected to a Bluetooth device, pairing will be performed automatically the next time you open the charging case.
2. If the earbuds have not connected to any Bluetooth devices, they will automatically turn off.
3. When using for the first time or after not using for a long time, please charge the charging case for about 2 hours.


Charging Case Specification

Battery : 500mAh Lithium Battery

Charging Voltage : DC 5V,500mAh

Charging Time : 2 Hours

Charging Port : USB-C



CONNECT TO BLUETOOTH DEVICES

① POWER ON


Take the earbuds out of the charging case, the power will automatically turn on and the earbuds prompt "Power ON".

② PAIRING

While the pairing of the left and right earbuds is completed, the earbuds beep once.


③ CONNECT TO BLUETOOTH

Connect to the device of "J11" in the smartphone's Bluetooth settings. (While the connection is completed, earbuds prompt "Connected")




CHARGING

① Charge the earbuds



When charging the earbuds, the pilot lamps of earbuds turn to red and they will turn off after the charging is finished.

② Charge the charging case



When charging the charging case, the pilot lamp of charging case flashes in red and it will stay in red after the charging is finished.

The Operations of Earbuds

POWER ON : 1. Take out the earbuds from charging case, they will automatically turn on;
2. Long press each of the touch sensor of earbuds for about 3 seconds.

POWER OFF : 1. Put the earbuds into the charging case directly, the power will turn off;
2. Long press either of the touch sensors for about 3 seconds;
3. Leave the earbuds in pairing mod(unpaired) for about 3 minutes ;

Play/Pause/Answer/Hang up : Press either of the touch sensors once.

Reject the phone call/Voice assistant : Long press either of the touch sensors for about 3 seconds;

Next song/Previous song: Double-press/Triple-press either of the touch sensors.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.