

3 in 1 Function Video Remote & Remote Shutter & Phone Holder

Bluetooth connection



User manual Model: TP-1

01

NOTE:About iPhone


In the case of iOS you must make the following settings before connecting to Bluetooth

About iPhone Special reminders for iPhone user: Open the iPhone Settings - Accessibility Touch Assistive Touch, set it to on See below:



02


until the following icon appears



You need make sure the IOS software is above V14.8.5.

04

Package




Charging box Remote controller

Type-C charging cable User manual

05

Use diagrams




LED indicator Type-C charging port


Button Charging

06

Turn On




Press and hold the middle button for 1 second till the blue light turn on




07

Turn off




Press and hold the middle button for 5 seconds till the blue light flashes rapidly




08

Pairing





In the off state, press and hold the middle for 1 second till the blue light flashes rapidly, the controller is in pairing state



09

Connect mobile phone

Mode 1: Manually





In the off state, press and hold the middle for 1 second till the blue light flashes rapidly, the controller is in pairing state, then turn on the Bluetooth of the mobile phone and search for the mobile phone, the Bluetooth menu shows : TP-1 and click to complete the Bluetooth connection. If you can't find it, please try to turn off the mobile phone's Bluetooth and turn it on again until the connection is completed.

10

Connect mobile phone


Mode 2: Auto pairing



Turn on your mobile phone, the controller will automatically connect to the last mobile phone you connected before (make sure the Bluetooth of the mobile is turned on)

11

Mobile phone stand




Take bottom shelf slides out as phone stand

attery level display for the charging case

12

Button function




Double click: swipe to right video Short press: previous video Long press: volume down

Short press: next video Long press: volume+ Double click: swipe to left video

Press and hold the for 1 second: Power on Short press: Pause Double Press: Like Press and hold for 1 second and release: turn off the screen Press and hold for 5 seconds: power off

13

Take photos and record videos




In photo or video mode, press and hold any of these 2 keys will start or end take pictures or video recording


Short press the middle button for focusing

14

Charging diagram



DC 5V




Charging Fully charged

Red light flashing Red light on

15

Charging diagram



Charging Fully charged

Blue light on Blue light off

16

Automatic shutdown function

1. Normal pairing or disconnecting from the mobile phone to enter the pairing.If the mobile phone is not connected within 5 minutes, it will automatically shut down

2. If there is no operation after 30 minutes it will automatically shut down

17

Parameter

Remote controller	
bluetooth version	Ver.5.0
transmit power	classII(-6dBm~ +4dBm)
Frequency (Hz)	2.40GHz~ 2.48GHz
bluetooth name	TP-1
password	0000
distance	10m
battery capacity	25mAH
charging time	1h

Charging box	
battery capacity	200mAH
charging time	1.5h

18

Frequently Asked Question (FAQ)

Q: Why it doesn't work or scroll?

Please check if there are any of the following problems

1. We're advising you to try using on opposite the direction of Ring.

a) When you just open TikTok, it will refresh when you press the up button for the first time.

b) Then if you need to go back to the previous video, just press the down button.

c) If you need to go back to the previous video, press the up button.

d) When you go back to the first video, press the up button, and it will refresh again.

e) Press the down button again, and other new videos will appear.

2. Make sure your phone has been connected to the remote ring via bluetooth. If your phone is an iPhone, you also need to pay attention to the following issues

a) The assistive touch button must be turned on when using the iPhone or iPad, it will leave a circle on the screen all the time

b) The specific settings: open Settings>Accessibility>touch>turn on Assistive touch.

c) You need to make sure the IOS software is above V14.8.5.

Q: Can it work on a kindle?

A: It doesn't work for kindle devices, But it can be work for kindle App.

Q: Can it create Tik Tok videos?

A: Can not, It can't be used to create videos, it can scroll up and down the video, like videos, adjust the volume, And you can control your phone to take photos and videos remotely.

Q: Can it be used to start and stop "live" on Tik Tok?

A: It can't start and stop "live" on Tik Tok.

Q: Does this phone remote control also work for facebook and instagram?

A: It doesn't work for facebook and instagram.

Q: Does work with spotify?


A: It doesn't work for spotify.

MADE IN CHINA

19


The iOS system cannot utilize the user manual

When the up or down buttons on the remote control for the iOS system are not functioning, please follow the steps below for troubleshooting.



20

Adjust the slider to position the screen cursor closer to the center of the screen. Note: If the cursor is positioned in the top left corner or bottom right corner of the screen, it can cause the remote control function to malfunction.



In the novel app mode, when pressing the down button, if the content scrolls too quickly, you can adjust the slider closer to the turtle icon to slow down the scrolling speed

20

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.