






NTNV-n41-PC2-30-10-M-CP-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-10-M-CP-256QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-10-H-DFT-BPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-10-H-DFT-QPSK-Outer_Full-Ant1-
PASS






NTNV-n41-PC2-30-10-H-CP-16QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-10-H-CP-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-10-H-CP-256QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-15-L-DFT-BPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-15-L-DFT-QPSK-Outer_Full-Ant1-1
PASS



NTNV-n41-PC2-30-15-L-DFT-16QAM-Outer_Full-Ant1-1
PASS




NTNV-n41-PC2-30-15-L-DFT-64QAM-Outer_Full-Ant1-1
PASS



NTNV-n41-PC2-30-15-L-DFT-256QAM-Outer_Full-Ant1-1
PASS



NTNV-n41-PC2-30-15-L-CP-QPSK-Outet_Full-Ant1-PASS




NTNV-n41-PC2-30-15-L-CP-16QAM-Outet_Full-Ant1-PASS




NTNV-n41-PC2-30-15-L-CP-64QAM-Outet_Full-Ant1-PASS



NTNV-n41-PC2-30-15-L-CP-256QAM-Outet_Full-Ant1-PASS




NTNV-n41-PC2-30-15-M-DFT-BPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-15-M-DFT-QPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-15-M-DFT-16QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-15-M-DFT-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-15-M-DFT-256QAM-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-15-M-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-15-M-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-15-M-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-15-M-CP-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-15-H-DFT-BPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-15-H-DFT-QPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-15-H-DFT-16QAM-Outer_Full-Ant1-
PASS






NTNV-n41-PC2-30-15-H-CP-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-15-H-CP-256QAM-Outer_Full-Ant1-
PASS





NTNV-n41-PC2-30-20-L-DFT-BPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-20-L-DFT-QPSK-Outer_Full-Ant1-
PASS









NTNV-n41-PC2-30-20-M-DFT-QPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-20-M-DFT-16QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-20-M-DFT-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-20-M-DFT-256QAM-Outer_Full-Ant1-
PASS








NTNV-n41-PC2-30-20-H-DFT-256QAM-Outer_Full-Ant1-PASS



NTNV-n41-PC2-30-20-H-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-20-H-CP-16QAM-Outer_Full-Ant1-PASS



NTNV-n41-PC2-30-20-H-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-20-H-CP-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-30-L-DFT-BPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-30-L-DFT-QPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-30-L-DFT-16QAM-Outer_Full-Ant1-
PASS







NTNV-n41-PC2-30-30-L-CP-64QAM-Outer_Full-Ant1-1-
PASS




NTNV-n41-PC2-30-30-L-CP-256QAM-Outer_Full-Ant1-1-
PASS



NTNV-n41-PC2-30-30-M-DFT-BPSK-Outer_Full-Ant1-1-
PASS




NTNV-n41-PC2-30-30-M-DFT-QPSK-Outer_Full-Ant1-1-
PASS





NTNV-n41-PC2-30-30-M-CP-16QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-30-M-CP-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-30-M-CP-256QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-30-H-DFT-BPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-30-H-DFT-QPSK-Outer_Full-Ant1-1
PASS




NTNV-n41-PC2-30-30-H-DFT-16QAM-Outer_Full-Ant1-1
PASS




NTNV-n41-PC2-30-30-H-DFT-64QAM-Outer_Full-Ant1-1
PASS




NTNV-n41-PC2-30-30-H-DFT-256QAM-Outer_Full-Ant1-1
PASS



NTNV-n41-PC2-30-30-H-CP-QPSK-Outer Full-Ant1-PASS



NTNV-n41-PC2-30-30-H-CP-16QAM-Outer_Full-Ant1-
PASS

NTNV-n41-PC2-30-30-H-CP-64QAM-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-30-H-CP-256QAM-Outer_Full-Ant1-
PASS

