






NTNV-n41-PC2-30-70-H-DFT-QPSK-Outer_Full-Ant1-1
PASS



NTNV-n41-PC2-30-70-H-DFT-16QAM-Outer_Full-Ant1-1
PASS




NTNV-n41-PC2-30-70-H-DFT-64QAM-Outer_Full-Ant1-1
PASS




NTNV-n41-PC2-30-70-H-DFT-256QAM-Outer_Full-Ant1-1
PASS




NTNV-n41-PC2-30-70-H-CP-QPSK-Outet_Full-Ant1-PASS




NTNV-n41-PC2-30-70-H-CP-16QAM-Outet_Full-Ant1-PASS




NTNV-n41-PC2-30-70-H-CP-64QAM-Outet_Full-Ant1-PASS




NTNV-n41-PC2-30-70-H-CP-256QAM-Outet_Full-Ant1-PASS





NTNV-n41-PC2-30-80-L-DFT-256QAM-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-80-L-CP-QPSK-Outer_Full-Ant1-PASS





NTNV-n41-PC2-30-80-L-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-80-L-CP-64QAM-Outer_Full-Ant1-PASS












NTNV-n41-PC2-30-80-H-CP-16QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-80-H-CP-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-80-H-CP-256QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-90-L-DFT-BPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-90-L-DFT-QPSK-Outer_Full-Ant1-1
PASS




NTNV-n41-PC2-30-90-L-DFT-16QAM-Outer_Full-Ant1-1
PASS





NTNV-n41-PC2-30-90-L-DFT-64QAM-Outer_Full-Ant1-1
PASS




NTNV-n41-PC2-30-90-L-DFT-256QAM-Outer_Full-Ant1-1
PASS













NTNV-n41-PC2-30-90-H-DFT-64QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-90-H-DFT-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-90-H-CP-QPSK-Outer_Full-Ant1-PASS



NTNV-n41-PC2-30-90-H-CP-16QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-90-H-CP-64QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-90-H-CP-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-100-L-DFT-BPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-100-L-DFT-QPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-100-L-DFT-16QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-100-L-DFT-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-100-L-DFT-256QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-100-L-CP-QPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-100-L-CP-16QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-100-L-CP-64QAM-Outer_Full-Ant1-
PASS





NTNV-n41-PC2-30-100-L-CP-256QAM-Outer_Full-Ant1-
PASS






NTNV-n41-PC2-30-100-M-DFT-BPSK-Outer_Full-Ant1-
PASS







NTNV-n41-PC2-30-100-H-DFT-256QAM-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-100-H-CP-QPSK-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-100-H-CP-16QAM-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-100-H-CP-64QAM-Outer_Full-Ant1-
PASS



Band Edge for SA

Test Graphs

