






NTNV-n77(3450-3550)-PC2-30-10-M-DFT-64QAM-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-10-M-DFT-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-10-M-CP-QPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-10-M-CP-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-10-M-CP-64QAM-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-10-M-CP-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-10-H-DFT-BPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-10-H-DFT-QPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-10-H-DFT-16QAM-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-10-H-DFT-64QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-10-H-DFT-256QAM-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-10-H-CP-QPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-10-H-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-10-H-CP-64QAM-Outer_Full-Ant1-PASS







NTNV-n77(3450-3550)-PC2-30-10-H-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-L-DFT-BPSK-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-15-L-CP-QPSK-
Outer_Full-Ant1-PASSNTNV-n77(3450-3550)-PC2-30-15-L-CP-16QAM-
Outer_Full-Ant1-PASSNTNV-n77(3450-3550)-PC2-30-15-L-CP-64QAM-
Outer_Full-Ant1-PASSNTNV-n77(3450-3550)-PC2-30-15-L-CP-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-DFT-BPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-DFT-QPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-DFT-16QAM-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-15-M-DFT-64QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-DFT-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-CP-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-H-DFT-BPSK-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-15-H-DFT-QPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-H-DFT-16QAM-
Outer_Full-Ant1-PASS







NTNV-n77(3450-3550)-PC2-30-15-H-CP-64QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-H-CP-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-L-DFT-BPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-L-DFT-QPSK-
Outer_Full-Ant1-PASS









NTNV-n77(3450-3550)-PC2-30-20-M-DFT-QPSK-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-20-M-DFT-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-DFT-64QAM-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-20-M-DFT-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-H-DFT-BPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-H-DFT-QPSK-
Outer_Full-Ant1-PASS





NTNV-n77(3450-3550)-PC2-30-20-H-DFT-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-H-DFT-64QAM-
Outer_Full-Ant1-PASS












NTNV-n77(3450-3550)-PC2-30-30-L-CP-64QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-L-CP-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-M-DFT-BPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-M-DFT-QPSK-
Outer_Full-Ant1-PASS








NTNV-n77(3450-3550)-PC2-30-30-H-DFT-BPSK-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-30-H-DFT-QPSK-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-30-H-DFT-16QAM-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-30-H-DFT-64QAM-Outer_Full-Ant1-PASS

