





NTNV-n77(3450-3550)-PC2-30-70-M-CP-QPSK-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-70-M-CP-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-70-M-CP-64QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-70-M-CP-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-70-H-DFT-BPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-70-H-DFT-QPSK-
Outer_Full-Ant1-PASS





NTNV-n77(3450-3550)-PC2-30-70-H-DFT-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-70-H-DFT-64QAM-
Outer_Full-Ant1-PASS














NTNV-n77(3450-3550)-PC2-30-80-M-DFT-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-M-DFT-64QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-M-DFT-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-M-CP-QPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-M-CP-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-M-CP-64QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-M-CP-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-
Outer_Full-Ant1-PASS







NTNV-n77(3450-3550)-PC2-30-80-H-CP-QPSK-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-CP-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-H-CP-64QAM-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-CP-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-90-L-DFT-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-90-L-DFT-64QAM-
Outer_Full-Ant1-PASS




NTVN-n77(3450-3550)-PC2-30-90-L-DFT-256QAM-
Outer_Full-Ant1-PASS




NTVN-n77(3450-3550)-PC2-30-90-L-CP-QPSK-
Outer_Full-Ant1-PASS



NTVN-n77(3450-3550)-PC2-30-90-L-CP-16QAM-
Outer_Full-Ant1-PASS




NTVN-n77(3450-3550)-PC2-30-90-L-CP-64QAM-
Outer_Full-Ant1-PASS






NTNV-n77(3450-3550)-PC2-30-90-M-DFT-64QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-90-M-DFT-256QAM-
Outer_Full-Ant1-PASS





NTNV-n77(3450-3550)-PC2-30-90-M-CP-QPSK-
Outer_Full-Ant1-PASS





NTNV-n77(3450-3550)-PC2-30-90-M-CP-16QAM-
Outer_Full-Ant1-PASS
















NTNV-n77(3450-3550)-PC2-30-100-M-DFT-BPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-100-M-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-100-M-DFT-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-100-M-DFT-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-100-M-DFT-256QAM-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-100-M-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-100-M-CP-16QAM-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-100-M-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-100-M-CP-256QAM-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-100-H-DFT-BPSK-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-100-H-DFT-QPSK-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-100-H-DFT-16QAM-Outer_Full-Ant1-PASS

