

- the power delivered by the charger must be between min [1]Watts required by the radio equipment, and max [3] Watts in order to achieve the maximum charging speed.




This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



英语/EN wireless earbuds manual

1. Power on

Automatically start up (first time use)

Take out the earphones. At this time, the earphones will automatically power on and match. The blue lights of the two earphones will flash slowly, waiting to be connected to the mobile phone.

Manual power on

The earphones are not in the earphone compartment. Press and hold the left and right earphones for 3 seconds to power on.

2. Wireless connections

1. Take the earphones out of the earphone compartment.
2. Turn on mobile phone wireless.
3. Find the wireless name of the headset.
4. Click to connect.

Product : Wireless Bluetooth Earphones

Model : C9

3. Operation instruction

Answer/hang up the call

Short press the earphone once to answer/hang up the call.
Long press the earphone to refuse to answer the call

Pause/play music

Short press the earphone during music playback to pause/play music

Volume addition and subtraction

Press the left ear twice times in succession to decrease the volume.
Press the right ear twice times in succession to increase the volume.

Previous song

Press and hold the left headset for 1 second

Next song

Press and hold the right headset for 1 second

Activate the mobile voice assistant.

Touch the button three times to activate the Siri voice assistant

4. Precautions

1. The headphones need to be stored in a dry and ventilated environment, and avoid contact with oil, water vapor, and distilled water to avoid affecting product performance.
2. Avoid using irritating, organic solvents or items containing these ingredients for cleaning.
3. Please do not disassemble the headset body and its accessories without permission, otherwise the warranty will be void.
4. To charge the earphones, please use the standard charger or the charger specified by our company that meets the requirements.