


i33 Wireless Bluetooth Earphones  
User manual  
Imported Wireless 5.3 chips



Compatibility:


This product is compatible with all Bluetooth-enabled mobile phones (iOS/Android/Windows Phone), tablet PCs, smart watches, notebooks and desktop computers.

Product illustration:



Powering ON:

**Method 1:** Take out the earphones from the charging case, and they will "power on".



**Method 2:** When the headset is turned on, touch and hold the touch location of the headset for about 3 seconds, the red and blue lights flash alternately after the blue light is lighting for 1s, and with the power on prompt sound "power on".



Powering OFF:

**Method 1:** The earphones will switch off when put into the charge case.

**Method 2:** When the headset is turned off, touch and hold the touch location of the headset for about 3 seconds, the red and blue lights flash alternately after the blue light is lighting for 1s, and with the power on prompt sound "power on".


**Note:** If the earphones were disconnected with the device, the earphones will be turned off automatically after 5mins.

Headphone use:



Headset pairing:

**Method 1:** When the headset was taken out of the charging case, the headset automatically turns on and enters the pairing state, and the red and blue lights flash alternately.



**Method 2:** When the headset is turned on, touch and hold the touch location of the headset for about 3 seconds, the red and blue lights flash alternately after the blue light is lighting for 1s, and with the power on prompt sound "power on".



Powering OFF:

**Method 1:** The earphones will switch off when put into the charge case.

**Method 2:** When the headset is turned off, touch and hold the touch location of the headset for about 3 seconds, the red and blue lights flash alternately after the blue light is lighting for 1s, and with the power on prompt sound "power on".

**Note:** If the earphones were disconnected with the device, the earphones will be turned off automatically after 5mins.

Play Music:

**1** Click the MFB key to play and pause.

Headset pairing:

**1** Long press the "+" button for the next song, long press the "-" button for the last song

**2** Click the "+" button for volume up, click the "-" button for volume down

Voice Assistant:

Touch the button three times to activate the Siri voice assistant.

Calling:

**1** Click the MFB key to answer the call and long press the MFB key to reject the call.

**2** During a headset call, click the headset MFB key to hang up the call.

**3** User can adjust the calling volume by cellphone when calling

**4** To redial the last phone number, press the button "+" and the button "-" at the same time.

Headset charging:

When the power of the headset is low, the headset red light will flashes, and the headset will have "Please charge" sound, please charge the headset. The headset have a TYPE-C charging port, you can charging the headset with the data cable directly, or put it in the charging case for a charging. The red light will always lighting when charging. And the blue light will always on when fully charged.

**Note:** If the earphones were disconnected with the device, the earphones will be turned off automatically after 5mins.

**1** Click the MFB key to play and pause.

Specifications:

- Bluetooth version: V5.3
- Voltage rating and energy capacity: 3.7V/400mAh
- Battery capacity: 13.7V/95mAh
- Earphone Charge time: 2hour
- Music playing time: About 15h\*3Times
- Bluetooth version: HFP/A2DP/AVRCP
- Operating frequency: 2.40 GHz-2.48 GHz
- RF Sensitivity: -92dBm
- Working temperature range: -10~50°C
- Maximum transmission range: ≤15M

Packing list:

Earphones \*1  
Charging case \*1  
USB cable \*1  
User manual \*1  
Earcaps 2(L,S)

Important:

**1** When not connected to any device, the earphones will power off automatically after 5 minutes.

**2** On phones the battery level of the earphones will be displayed in real time.

**3** When the earphones and the charge case are not used for long periods of time, it is recommended to keep them in a dry place and to recharge them at least every 2 months.

**1** It is recommended to gently wipe the spring needle and copper column with a cotton swab on a regular basis to achieve a cleaning effect. Never use liquids to clean the earbuds.



**Note:** When the earbuds is not charging, you can use a cotton swab to gently wipe the spring needle and copper post.

**2** Reset to factory settings: Quickly 5-click the touch location to clear the pairing record and turn off.

Fault:

Fault	Cause	Solutions
Can't power on	Earbuds are low battery	Charge the Earbuds/Keep the earphones touch button pressed for 5 seconds
No charging indication	The Earbuds are not well put into the charging case	Adjust Earbuds position/Keep the earbuds touch the spring needle and copper column
Automatically shut down	Earbuds are low battery	Charge the Earbuds
The Earbuds have a high volume	The volume is too high or there is a feedback	Adjust the volume or turn off the feedback
The Earbuds are noisy	Outside environment interference or too far away from mobile phone	Change position or move closer to the mobile phone
Small sound	weak sound/Earbuds Incompletely or the volume is too low	Adjust the Earbuds position or the mobile phone volume
Signal intermission	Outside environment interference or too far away from mobile phone	Change to better environment or move closer to the mobile phone

**Warning:**  
This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

Warning: This equipment may cause interference to radio communications and should not be located near other equipment.

**NOTE:** If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.  
-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

**NOTE:** This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## i33无线蓝牙耳机 使用指南


进口蓝牙5.3芯片



### 兼容性：

兼容市面上所有带有蓝牙的手机（iOS/安卓/WindowsPhone）、  
平板电脑、笔记本等。

### 产品图示：



### 耳机使用：



### 开机：

方法1：把耳机从充电仓取出即可开机，开机提示音“power on”



方法2：耳机在关闭状态下，长按耳机的触摸键约3秒，蓝灯亮15后红蓝灯交替闪，并伴有开机提示音“power on”



### 关机：


方法1：耳机放回充电仓内充电，耳机会自动充电关机。

方法2：长按耳机的触摸键大约3秒，红灯亮1秒后熄灭，并伴有开机提示音“power off”

注：开机后耳机未连接设备，或者耳机与设备断开连接后，如无任何操作，约5分钟后将自动关机。

### 耳机配对：

① 耳机从充电仓取出，耳机自动开机即进入配对状态，红蓝灯交替闪。



② 打开手机蓝牙界面，搜索“i33”选择配对，耳机连手机蓝牙以后LED灯灭。



注：耳机与主设备配对（手机、智能手表、笔记本电脑等），蓝牙开启状态下，耳机开机后自动连接最近连接的设备。

### 播放音乐：

① 单击触控键，即可播放/暂停

② 长按“+”键下一曲，长按“-”键上一曲

③ 单击“+”键音量加，单击“-”键音量减

### 语音助手：

单击触控键三次唤醒Siri语音指令。

### 耳机通话：

① 来电时，单击耳机触控键，即为接听电话，若长按即为拒听来电。

② 电话中，单击耳机触控键，将挂断电话，恢复之前状态。

③ 电话过程中，通过手机调节通话音量。

④ 未号重拨，同时按音量加+音量减。

### 耳机充电：

当耳机电量不足时，红灯闪烁，耳机会有“Please charge”的提示音，请将其充电。耳机自带TYPE-C充电口，可以用数据线充电，也可以通过充电盒给耳机充电。耳机在充电时红灯长亮，充电后蓝灯长亮。

### 基本参数：

蓝牙版本：V5.3

充电舱电池电压/容量：3.7V/400mAh

耳机电池容量：1\*3.7V/95mAh

耳机充电时间：约2小时

播放歌曲时间：15小时\*3次  
支持协议：HFP/A2DP/AVRCP

频率：2.4GHz-2.48GHz

接收灵敏度：-92dBm

工作温度：-10~50°C

距离：≤15M

### 配件明细：

耳机 \*1

充电盒 \*1

数据线 \*1

耳帽 \*2(大/小)

使用说明书 \*1

### 注意：

① 耳机5分钟内未与任何设备连接，会自动进入关机状态。

② 苹果手机实时显示电压较低的耳机的电池电量。

③ 建议在耳机长时间不使用情况下，请将其放在干燥通风区域并每隔两月充电一次。

④ 建议定期用棉签轻轻擦拭弹针和铜柱，达到清洁的效果，切勿使用液体清洁耳机。



注意：当耳机不充电时，可以用棉签轻轻擦拭弹针和铜柱。

⑤ 恢复出厂设置：快速5击触控键，可以清除手机和耳机之前的配对记录，清除对记录后关机。

### 故障：

故障	原因分析	解决方法
不开机	耳机电量不足	对耳机进行充电
充电盒提示	耳机未正确摆放/弹针和铜柱有异物/清洁弹针和铜柱	调整耳机摆放位置/清洁弹针和铜柱
自动关机	耳机电量不足	对耳机进行充电
耳机有杂音	音量过大或者环境太吵杂	调节音量或更换环境
耳机有杂音	外界干扰严重或距离手机太远	更换地点或靠近手机
对方声音小	耳机佩戴不正确或音量太小	调节耳机佩戴或音量大小
信号断续	外界干扰严重或低电量	选择无干扰环境或充电