

FEIYANG

Bluetooth Speaker FG208-16



INSTRUCTION MANUAL

For correctly operating, please read this manual carefully before using. We are not responsible for consequence caused by fault or oversight of this manual.

FEATURES :

- Outdoor HIFI Bluetooth Radio
- Output very clear sound and dynamic sound effect
- With A2DP/AVRCP Bluetooth, wireless stream music from any Bluetooth-enabled device such as your mobile phone, notebook, iPhone or iPad
- Secure simple pairing for user-friendly operating
- 10 meters operating range
- With USB and Micro TF supporting
- With Line-in function, suitable for PC/MID/TV and other audio device
- Built-in lead-acid rechargeable battery 12V 7.5Ah
- With FM Radio
- TWS function
- RGB music beat light


ACCESSORIES:

- User manual *1pc
- Power cord *1pc
- Remote controller *1pc

SPECIFICATION:



Bluetooth range up to 10 meters
Speaker: Woofer Size:2x8 inch
Output: 80W
Connections: USB disk, TF card reader, Microphone input jack
Aux-in 3.5mm jack connection, Guitar input jack
Power supply: Built-in rechargeable lead-acid battery 12V 7.5Ah
Play time: Deep bass in an hour with 50% volume/deep bass around two hours with 100% volume
Recharge power: DC12V from battery, AC110-240V
Product size: 330(L) *330(W) * 740(H) mm
Charge time: 7-8hrs (20V 5A)
Bluetooth version : 5.0
Support mode: AUX mode, USB mode, Bluetooth mode, FM mode, Recording mode
Frequency : 2480

INSTRUCTION FOR APPEARANCE AND KEY :



REMOTE FUNCTION DECLARATION:

1. MUTE/MODE(LINE IN/USB/TF/AUX/BLUETOOTH/FM)
2. 0-9
3. ECHO+/ECHO-/ EQ/ GUITAR VOLUME+/GUITAR VOLUME- PREVIOUS SONG/CHANNEL PAUSE/PLAY NEXT SONG/CHANNEL
4. TREBLE+/TREBLE-
5. VOLUME+/VOLUME-/MIC VOLUME+/ MIC VOLUME-/LIGHT SW
6. BASS+/BASS-
7. MIC TREBLE+/TREBLE- MIC BASS+/BASS-
8. MIC PRIORITY/REPEAT/REC/FOLDER



AUX-IN:

For other compatible music devices or your MP3/MP4 players, use the audio cable (not included) to connect from the device's "Line Out" to the "Aux In" of this device to enjoy playing music.

Under any playing mode, When you use the audio cable to connect the device, it will auto switch to the AUX mode.

Under AUX mode, all functions can be controlled by external device.

Battery Charging:

1. Power off the unit, put the provided adapter into the charge slot of unit, the red charging indicator keep lighting.
2. Charge time should be 5-6 hours. When charging full, the indicator light will switch off.
3. In order to prolong the life of battery, please do not charge more than 8 hours.

Note:

1. The playtime depends on how hard the unit is working. Heavy, loud, bass music will use more energy.
2. The built-in rechargeable battery is not replaceable. Do not remove or replace it, do not throw in the trash or in the fire.
3. When cleaning the product, use a soft dry cloth. For more severe stains, please dampen the cloth with water only. Anything else has the chance of dissolving the paint or damaging the plastic.

Recording function:

1. Make sure the unit is switched on, and there is a USB memory stick or TF card inserted in the slot.
2. Plug and test the microphone upon plugging. The device is ready to record once your voice is audible from the speaker.
3. Press the button 'REC' on the remote controller to start/stop recording, you are freely to rec what you want.

Playing music from USB disk and Micro SD card:

1. Turn the Power button to "ON". In the front panel, press the mode button to launch the Bluetooth application. The system voice of the device will say "Bluetooth mode".
2. Activate Bluetooth of mobile phone and search for device name "BT SPEAKER" then connect it. The system voice says "Bluetooth connected" once connected successfully.
3. Play the music from your mobile phone and enjoy.
4. Press Previous or Next button on the device or on Mobile phone to select songs you like.
5. Press Play/pause button on the device or on Mobile phone to play/pause the music.
6. Use the Bluetooth device to adjust volume up and down. Or turn knob to adjust volume down and up.

TWS FUNCTION :

1. Turn on two identical speakers you want to pair, please noted they must be the same BT paring name, both under BT mode. Only need to set one of the two units;
2. Long press "NEXT" button until you hear the system voice "Bluetooth connected", then successfully paired;
3. Make Bluetooth connection with your mobile phone, play music and enjoy true wireless stereo sound effect.

How to Use FM Radio:

1. Turn the power button to "ON", press the "MODE" button to FM radio mode.
2. Under playing mode, short press "Play/pause" button to auto search the FM Channel and store it automatically.
3. Press Previous or Next button to change the stored FM channel.

Under FM radio state, to get a better FM signal, please insert a audio cable (not included) as antenna.

FCC Compliance Statement:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

The distance between user and product should not be less than 20cm.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.