DOG TRAINING COLLAR

Manual

COMPONENTS

❶ Handheld Remote ❷ Receiver

❸ Charging Cable ❹ Wrist Strap ❺ User Manual

❻ Test Light Tool ❼ Long Contact Points ❽ Shorter Cats

(Components ❶ ❷ ❸ ❹ refer to Page10 for more information)

OVERVIEW

Handheld Remote

OVERVIEW

Receiver



Important Safety Information

This is the safety alert symbol. It is used to alert you to potential injury hazards. Obey all safety messages that follow this symbol to avoid possible injury.

⚠ WARNING!

WARNING! Indicates a hazardous situation which, if not avoided, could result in serious injury.

Not for use with aggressive dogs. Do not use this product if your dog's sense to aggressive behavior. Aggressive dogs can cause severe injury to their owners and other animals and people. Please contact a trainer right for your dog's habit to your veterinarian or an animal behavior.

⚠ CAUTION

CAUTION, used with the safety alert symbol, indicates a hazardous situation, which, if not avoided could result in minor or moderate injury.

- Safety during a dog's training: It is vitally important that you and your dog remain safe during training sessions. Please be sure to read the instructions in this manual thoroughly and familiarize yourself with the product before use. Learn how to properly adjust the collar for a snug fit and how to operate the unit. Be sure to maintain your dog where he has to close.
- This pet training device is not a toy. Keep away from children.

⚠ CAUTION

CAUTION, used without the safety alert symbol, indicates a hazardous situation, which, if not avoided could result in minor or moderate injury.

Electronic devices: Pacemaker wearers should consult with their doctor(s) before using. Those wearers should maintain a safe distance from the receiver of Aspire 55 of this collar is important. A collar worn for too long or made too tight on the pets neck can cause irritation or discomfort. Please follow instructions to prevent skin the conditions commonly known as bed sores.

- Avoid leaving the collar on the dog for more than 12 hours per day.
- Check the collar fit at least twice daily to ensure a snug, safe fit.
- Check the fit system exercises process.(follow the instructions in the manual).
- Never connect a leash to the electronic collar; it will cause excessive pressure on the dog's throat.
- Never leave the collar on a dog when not in use. Remove the collar when not in use.
- Never let dog to have access to the contacts of the collar socially with a dog walk.
- Check the contact area daily for signs of a sore or a rash.
- If the collar gets wet, dry it thoroughly before use. Do not use the unit has leaked.
- If the condition persists beyond 48 hours, see your veterinarian.

❶ Charge the Collar and Remote

Magnetic charging port

When charging is completed, the green light will appear.

❷ Fit the Receiver Collar

Note: - A- The Contact Points must have direct contact with Dog's skin on the underside of neck. Check the tightness of the Collar by inserting one finger snugly between the collar and neck.

- If the initial dog you may need to cut of the extra collar, please refer to Troubleshooting at Page 14.

❸ To turn the Remote and Receiver on

When not using the collar, turn it off to increase the battery life. Long press the button 3 sec to turn off the Receiver.

❹ Keypad Lock

Security Keypad - lock or unlock

❺ Beep Tone command

Delivers a beep tone with non-adjustable volume to the collar.

❻ Vibration command

Delivers vibration to the collar. Vibration intensity adjustment: Press and hold the vibration Level button B, at the same time, rotating the level regulator A of the remote.

❼ Static Stimulation command

- Static button Delivers currently selected level Static stimulation to the collar.
- Static + button: That is 10% higher than the currently selected level. Some consumers would like to instant access to a higher level of Static. This button provides that instant access.
- Static Intensity adjustment: Press and hold the static Level button A, at the same time, rotating the level regulator A of the remote.

⚠ How to find the Best Static Level for Your Dog ?

⚠ Don't change dog on a small dog, please choose level 01 and 02 to start. Please don't choose level 03 and above.

Have 1 to 99 different Stimulation Levels. Follow the steps below to find the best Level.

- Step 1: Starting at Level 1 on the Digital Display, press the static button and feel the stimulation.
- Step 2: Move up through the Stimulation levels until your pet responds to the stimulation.
- Step 3: If your dog continues to show no response at Level 20, check the fit of the collar and contact points. If you feel that a fit change is a longer set of Contact Points, or dog's hair will need to be trimmed around the Contact Points.
- Step 4: Remember, if your dog still continues to show no reaction, see the **"how to do test Light tool"** section.

Main Features

- Vibration, Tone and Static training model
- 3 adjustable vibration level and 99 adjustable static level
- Dual batteries status display for Remote and Receiver
- Receiver collar IP67 waterproof (Remote non-waterproof)
- Remote range: Up to 2600 foot
- Long life Lithium Polymer battery
- Big digital display
- Support maximum 4 receiver collars with one remote
- Magnetic charging port

How to Use Test Light Tool

1. Make sure the Remote and Receiver Collar on.
2. Make sure the Contact Points touch the Contact Points.
3. Press a Static button on the Remote Transmitter. The Test Light will be lighted.

If, As a tool to tighten or loosen the contact points.
For dog with thicker coats, use 2pcs longer contact points. Or install the conductive Silicone.

Training Tips

If you want to eliminating unwanted behavior – For examples barking. Please follow three training steps.

1. Put a separate non-metallic collar on your dog's neck above the Receiver Collar, and secure it. It is the Training Collar. Make Sure the extra collar does not put pressure on the Contact Points.
2. Attach a leash to the Training Collar.
3. Choose your pet's Reinforcement Level.
4. As soon as your pet is barking, press the Stimulation button and hold it down until your pet stops barking.
5. Release the Stimulation button immediately once your dog stop barking, and verbally praise him.
6. If your dog ignores the stimulation, increase the Intensity Level by 2 to 3.
7. Practice this exercise in several different areas.

Pairing

Factory Tips may skip this step because the set is already paired by the factory.

1. Make sure the Receiver is turned off.
2. Press and hold Switch for 3 secs until the green light is flashing fast.

3. Press the remote Pairing/Channel Select button D to pairing the receiver.

4. Pairing successful the receiver will beep and the green light flash slowly.

Two,three, Four Receiver System

- Make sure the Receiver is turned off.
- Press and hold Switch for 3 secs until the green light flashes fast.
- Press and hold channel button C at the same time, hold the Receiver and Remote within 6 inches apart. (Keep the Receiver and Remote on the flat surface).
- Release the Pairing/Channel Select button D to pairing the receiver.

Part B - Receiver Pairing:

- Able to train 2 dogs at the same time.
- Press and hold channel button C at the same time, rotating the level regulator A of the remote.

Part B1 - Reset all paired receiver collar.

- Make sure the remote is ON".
- Press and hold channel button C and vibration level button B, at the same time, turning the regulator switch A 360° to ON. All paired receiver will be removed and the dog 1 scan will flash.
- Pairing the receiver again.

Question & Answer

How to change for longer prongs for this collar? I don't think they are long enough my Labs thick hair.

Answer:

Just part the hair or trim it a bit, I have a dog with very thick curly of Contact Points, and I have to trim the hair around the Contact Points to have setting and work your way up. If no response repeat steps of reaching prongs this not remember to turn off or lock remote.

Troubleshooting

1. My pet is not responding when I press a beep vibration or static button.

- Make sure the Receiver Collar if it is On.
- Please check to see if the battery is low in either the Remote Transmitter or Receiver Collar.
- Check the Static Level (Including Stimulation to your pet by placing the Test Light, and touch in your kit, on the Receiver Collar.
- Increase the correction level. Refer to "Find the Best Stimulation Level for Your Dog".
- Make sure the Receiver Collar's Contact Points are placed snugly against your pet's skin.

2. The Receiver Collar will not turn on.

- Make sure the Receiver Collar has been charged.

3. The Receiver Collar is not responding to the Remote Transmitter.

- Verify the Receiver Collar has been turned on.

4. Adjust for all size dogs.

- For small dogs, you may need to cut off the extra collar (position A for reference), then it is necessary to use a lighter to fuse the interface (position A) of collar to prevent from coming apart.

Compliance

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution Notification or changes to the equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult a dealer or an experienced radio/TV technician for help.

Training Tips

Wearing Points