

# Size:65mmx110mm 128g铜版纸 双面四色印刷 单网口不带RJ11



**FIRSTNUM** 







### Insert the SIM card (1) Prepare one nano-SIM card.




(2) There is a place for inserting a SIM card at the bottom of the CPE.




3 Insert the SIM card in the direction shown by the icon at the slot, simply push forward when inserting, hear a "click" sound, Indicates that the SIM card is inserted. **FIRSTNUM** 




② On the top of the CPE, press and hold the power button for 3 seconds, and the power



**FIRSTNUM** 



Before use CPE Router Please read the User manual carefully and Keep it.



management page to prevent unauthorized users from changing the router's settings.

① After the CPE is connected to the computer, Open the browser on the computer.

Printed with initial username



**FIRSTNUM** 

② After successfully logging into the background, click My Wi-Fi. You can change the wifi name and password



3) After the setting is completed, please connect to the WiFi again

### 5.Connect CPE and Internet through network cable

When your SIM card uses up data traffic, you can connect the WAN in the ONU through a network cable to connect to the Internet.



### PRODUCT SPECIFICATIONS

Colour	White			
Dimensions	183X120X40mm			
Weight	About 340g with battery; About 248g without battery			
Network and Standard	3GPP: R8,R9			
	WCDMA/HSPA: B1/B5/B8			
	TDD-LTE: B34/B38/B39/B40/B41			
	FDD-LTE: B1/B3/B5/B7/B8/B20/B28			
Data Rates	CAT4 DL 150Mbps, UL 50Mbps			
WIFI	2.4G, 802.11b/g/n			
WIFI users	Max 10 concurrent connected users			

POWER PORT

### 1. How to restore the factory default Settings?

After the router is turned on, use a pointed object (paper clip, pen tip, etc.) to insert it into the reset hole, and all the indicator lights are off. 3 seconds later, the device restarts. A factory reset will erase all custom settings, please exercise caution

### 2. How to use WPS to connect the Router?

1. Press the WPS button on top of the CPE for 3 seconds, and the wifi indicator Starts to flash 2.Enable WPS on other device within 2 minutes to connect to the CPE

### 3. Why can't I access the router's web-based management page?

1.Ensure that your computer is connected to the router through an Ethernet cable or Wi-Fi. 2 Ensure that your computer is set to obtain an IP address and DNS server address automatically

3.Restart your browser, or try using another browser.

Before using and operating the equipment, please read and observe the following precautions to ensure the best performance of the equipment and avoid dangerous or illegal situations.

impact on medical equipment

in medical and health care facilities where the use of wireless devices is expressly prohibited, please abide by
the regulations of the facility and turn off the device. The radio waves generated by the device may affect the
normal operation of implantable medical devices or personal medical devices, such as pacemakers, cochlear implants, and hearing aids. If you use these medical devices, pleaseconsult their manufacturers about the

- restrictions on the use of this device.

  When using this device, please keep a distance of at least 15 cm from implanted medical devices (such as pacemakers, co-chiear implants, etc.). Flammable and explosive area.

   Do not use this equipment in gas stations (maintenance stations) or near any flammable and explosive areas
- such as flammable materials and chemicals, and follow all graphics or text instructions. In or around fuel or
- such as summated installants and uffernisses, and otherwise disputation to the installants and or all obtained are chemical storage and transportation areas for explosive areas, the equipment may cause an explosion or fire.

   Do not store or transport the device and its accessories in the same box as flammable liquids, gases, or explosive materials. Traffic cafely
   Observe the relevant regulations of your region or country, and do not use this device while driving.
- Remember that safe driving is your first responsibility, and do not engage in activities that will distract you
- The electronic equipment of the car may malfunction due to the radio interference of the equipment. Please
- Otherwise, when the safety airbag is inflated, the equipment will be pushed by a strong external force and One wore, when the salety artury or integrate, the explainent will be placed by a strong external indice and cause serious injury to the occupants in the car.

  • Wireless devices may interfere with the flight system of the aircraft. Please abide by the relevant regulations of the airlines. Do not use this device in places where the use of wireless devices is prohibited.

**FIRSTNUM** 

- The power plug is used as a device to disconnect the power
- The power plug is based as a care to cascumer, or in power.
  The power socket should be enstalled near the equipment and should be easily accessible.
  When the device is not in use, please disconnect the power supply from the device and unplug the power.

- - Please do not drop or hit the power source. When the power source casing is damaged, please contact the
- \*rease or not orgo or in the power source. Wrein the power source using to dartagete, pease contact the authorized service center for replacement.

  If the power plug or power cord is damaged, do not continue to use it to avoid electric shock or fire.

  Do not touch the power cord with wet hands, or pull the power cord to unplug the power source.

  Do not touch the device or power supply with wet hands to avoid short-crount, malfunction or electric shock.
- When the power supply is exposed to rain, liquid, or severely damp, please stop using it and contact an
- when the power supply is exposed to fair, indust, or severely damp, prease stup using it and contact an
  authorized service center for replacement.
   The power supply must meet the requirements of "2.5 Restricted Power Supply" in the standard. (GB4943.1
  Safety of Information Technology Equipment).

Children may inadvertently damage the device and its accessories, or swallow small parts, causing suffocation

This device is not a toy. Children should use the device under adult supervision.

### MAINTENANCE SERVICE TERMS

Within one year of the shipment of the goods, if there is a fault that is proven to be caused by a defect

- the manufacturer will repair or replace it free of charge.

   The warranty period of all repaired or replaced parts is 90 days from the date of dispatch of the goods . Under normal use (non-human damage), the warranty period of all parts is one year from the date of
- Failures caused by force majeure (such as war, earthquake, lightning, etc.), improper use, abnormal accidents are not covered by the warranty.
- . The manufacturer's compensation for breach of contract, negligence or infringement related to the product shall not exceed the amount of the product sold.

  For goods that need to be repaired during the warranty period, the buyer will provide the following

product information with the goods when returning it for repair

- (3). Describe the failure phenomenon in detail If there is a dispute about the repair of a product not covered by the above warranty terms, please attach a written explanation when returning it.

For faulty products that exceed the warranty period, our company implements paid maintenance

### . In order to speed up the repair of returned goods, please do not use parcels for mailing, and the

. During the product return and replacement period, please keep the packing box and accessories

## CPE WARRANTY CARD

# User profile

Name	Phone number	
Mailing Address		
Outlets		
Device model	Product name	
Sales Order No.		•

### Maintenance record

PHENOMENON	

# FCC:

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.