



网易严选

尺寸：折叠后75*140mm
材质：105g双铜
印刷：风琴折，正反印刷

TRYFUN

FUN BEYOND VISION

- Packing List**
- 1.Messenger
 - 2.USB Charging Cable
 - 3.Instruction Manual
 - 4.Storage Bag
- ※This product does not include an adapter, so please use your usual phone adapter.
※If there is any error in this manual for reference only, refer to the actual product.


Product Specifications

Brand: TRYFUN
Product Name: TRYFUN Rose Scapler Smart Adjustable Telescopic Wand
Product Model: TF-22042-01P
Product Structure: Rechargeable Electric
Product Materials: Silicone, PC (polycarbonate), ABS (acrylonitrile-butadiene-styrene copolymer)
Rated Voltage: 3.7V == Rated Power: 5W
Charging Voltage (V): 5V Charging Current (mA): 600 mA
Battery Capacity: 1000mAh
Product Size: 220x42.3x46mm
Product Weight: About 300g
①Charging Time: About 150 minutes
②Operating Time: About 10 to 15 minutes
③Waterproof Rating: IPX7
④Working Noise: Below 65dB
CMIT ID: 202302195800

※The above data are test results under normal conditions of use, and may vary depending on actual usage.

Function Description

Hardware Function Description:



1.Power On
When the device is in the power off state, press and hold the main control button for 5 seconds to turn it on. The product will shake twice, heat up and start working. The intelligent pressure-sensitive button indicator light will flash red, and the Bluetooth broadcast will be turned on and the Bluetooth indicator light will flash blue.

2.1P Power-on State
(1) In the power-on state, press and hold the main control button for 5 seconds to turn it off. The product will shake twice, heat up and start working. The intelligent pressure-sensitive button indicator light will flash red, and the Bluetooth broadcast will be turned on and the Bluetooth indicator light will flash blue.
(2) If the telescopic function does not work within 15 minutes in any state, it will automatically shut down.
3. Telescopic Function
(1) In the power-on state, press the main control button briefly to enter the first gear. Continuous pressing briefly to switch gears. There are a total of 7 gears, and 152 gears are variable speed. 4-6 gears are variable frequency, and the 7th gear is the intelligent pressure-sensitive mode, which cycles without any stop.
(2) In gear 1-4, quickly double-click the main control button to pause the current telescopic working state. Double-click again to resume the previous working state. Double-click the main control button has no effect in the intelligent pressure-sensitive mode.
(3) In the 7th gear, enter the intelligent pressure-sensitive mode. The intelligent pressure-sensitive button indicator light will flash green for 10 times. When you hold the pressure-sensitive button, the telescopic function will start working and the speed will change according to the force applied. The lighter the force, the slower the speed, and the heavier the force, the faster the speed. The green light indicates high power, the orange light indicates medium power, and the red light indicates high power.

4. Inflation
(1) In the power-on state, press and hold the inflation button to inflate. It takes about 20 seconds to inflate to the maximum state. There will be a sound of the air pump during the inflation process, and there will be no sound after inflating to the maximum state.
(2) Quickly double-click to release the air completely. If you need to inflate again, please press and hold the inflation button again.
(5. Heating)
(1) After power on, heating is started by default. The intelligent pressure-sensitive button indicator light will flash red. After reaching the set temperature, it will maintain constant temperature, and the red light will stay on. After "heating constant temperature" for 7 minutes, the heating function will be automatically turned off. To turn it on again, press the main control button 3 times quickly.
(2) In the heating working state, quickly press the main control button 3 times to turn off the heating function. The red light will change to white. Press the main control button 3 times to turn off the heating function, and the indicator light will flash red.
(3) In the power-off state, press and hold the main control button and the inflation button at the same time, the product will shake twice, and the device will be automatically turned on. Press and hold the main control button and the inflation button for 5 seconds, the product will shake twice, and the device will be turned off successfully.
※In the travel lock mode, you need to unlock it before turning on the device.

App Connection Instructions

- 1.Download the App and turn on the phone's Bluetooth.
- 2.Turn on the massager, and the Bluetooth indicator light will flash blue. When the Bluetooth connection is successful, the indicator light will stay blue.
- 3.If the App is not connected within 10 minutes after power on, the Bluetooth broadcast will be turned off and the Bluetooth indicator light will go out. If you need to connect to the App, please turn off the massager and then turn it on again to connect to the App.

User Instructions

- 1.Apply enough lubricant to the private area before use to make the entire process smoother and more enjoyable.
- 2.Turn on the stretching function to stimulate the inside of the vagina. Turn on the inflation function to adjust the size of the toy and feel different feelings of filling. Find your most comfortable mode according to personal preference and feel the pleasure of your body.

Friendly reminders:

- 1.Before experiencing physical and mental pleasure, you can play relaxing music and turn on soft lighting to enjoy with a beautiful atmosphere!
- 2.It is recommended to charge the product before first use and clean it before use.

Charging Instructions

- 1.During charging, the indicator light of the smart pressure-sensitive button flashes red in a breathing rhythm. The massager cannot be used during charging.
- 1.Please ensure that the charging cable and charging pins are fully connected.
- 2.When plugging or unplugging the charging cable, keep your hands dry.
- 3.The charging time is about 150 minutes. Do not overcharge for a long time. Please use a power adapter with an output parameter of 5V 1A to charge during charging. Do not use a power adapter with an output power greater than 5W to charge.
- 5.The massager cannot be used during charging. Please unplug the power after charging is completed before use.

Low Battery Warning

When the battery level is below 20%, the indicator light of the smart pressure-sensitive button flashes red. The red light will change to white. Please the immediately turned off and cannot be recycled. When the battery level is below 10%, the massager will automatically shut down. Please recharge the battery before use. Please keep the battery level above 20% to avoid the battery from being damaged. Please keep the battery level above 20% to avoid the battery from being damaged.

Cleaning and Storage

- 1.Clean the item before use.
- 2.Clean promptly after use in order to prevent contamination.
- 3.Avoid using cleaning fluids and disinfectants that contain alcohol or corrosive ingredients. Instead, use body wash to clean, then rinse with warm water. Do not use harsh detergents. Be sure to avoid the area around the button.
- 4.Do not immerse in water since it could cause malfunction!
- 5.Upon cleaning, use a soft cloth to dry off the water and place in a cool, dry place out of direct sunlight. Only put into storage after device is completely dry.
- 6.Do not put into dryer or heaters to dry product or place it in direct sunlight. High temperatures may cause irreversible damage.

Warnings

- This product is suitable only for ages 18 and above. To avoid infections, keep for personal use only and do not share device.
- Avoid using this product if you are not feeling well.
- Those who are using medical electronic devices (such as pacemakers), pregnant women, or people who are not feeling well should avoid using this product.
- Do not disassemble any part of this product. It could damage the product or lead to injury.
- When bringing product outside, store it separately to avoid scratches or contamination.

When using this product outside, store it separately to avoid scattered contamination.

List of harmful substances in product

Parts list	Toxic or harmful substances					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr ⁶⁺)	Polybrominated Biphenyl	Polybrominated Diphenyl Ether (PBDE)
Silicone Unit	0	0	0	0	0	0
Plastic Inner Case	0	0	0	0	0	0
Main Substrate	0	0	0	0	0	0
Battery Pack	0	0	0	0	0	0
Motor	0	0	0	0	0	0
Wires	0	0	0	0	0	0

This form prepared according to the provisions of SJ/T11364.
 0 Indicates that the content of the harmful substance in all homogeneous materials of the parts is below the limit specified in GB/T 26572.
 ※ Indicates that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirement specified in GB/T26572.

Recycling Instructions

In order to protect the environment, when disposing of the product or its parts, please refer to the following instructions:

1. Do not dispose of the product or its parts in the general waste disposal system. Please dispose of them in a designated recycling system.
2. Do not dispose of the product or its parts in the general waste disposal system. Please dispose of them in a designated recycling system.
3. Do not dispose of the product or its parts in the general waste disposal system. Please dispose of them in a designated recycling system.

Basic Information

Company: TRYFUN PTE. LTD.
Address: 887 Serangoon Road, Singapore
Contact: 328147
Email: service@tryfun.com
Customer service email: service@tryfun.com

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable equipment without restriction.

包装清单

- 1.按摩器
- 2.USB充电线
- 3.产品说明书
- 4.收纳袋

※本产品包装内没有提供适配器，请您使用自己常用的智能手机适配器。
※如有疑问请联系在线客服。

产品规格

品牌名称: TRYFUN
产品名称: 玫瑰权杖智能可调节伸缩棒
产品型号: TF-D2-MG-01P
产品材质: 硅胶、PC (聚碳酸酯)、ABS (聚氨基甲酸酯)、丁腈-苯乙烯共聚物
额定电压: 3.7V == 额定功率: 5W
充电电压: 5V == 充电电流: 600 mA
电池容量: 1000mAh
产品尺寸: 220x42.3x46mm
产品重量: 约300g
充电时间: 约150分钟
※使用时间: 约40分钟
※防水等级: IPX7
CMIT ID: 202302195800

※以上数据为正常使用条件下测试结果，根据实际使用情况可能会有不同。



使用说明

- 1.开机
关机状态下，长按主控制按钮5秒，产品会振动下，加热启动，且智能按钮按灯显示红色呼吸灯效，并开启蓝牙，蓝牙指示灯显示蓝色呼吸灯效。
- 2.关机
(1) 在开机状态下，长按主控制按钮5秒，产品会振动下，加热关闭，且智能按钮按灯显示红色呼吸灯效，并关闭蓝牙，蓝牙指示灯显示蓝色呼吸灯效。
- 3.伸缩
(1) 在开机状态下，短按主控制按钮1秒，伸缩棒可伸缩1段，一按一个档位，1-4档为伸缩，4-6档为伸缩，7档为智能模式，循环往复。
- 4.充气
(1) 在开机状态下，短按主控制按钮1秒，伸缩棒可充气1段，一按一个档位，1-4档为充气，4-6档为充气，7档为智能模式，循环往复。
- 5.加热
(1) 在开机状态下，短按主控制按钮1秒，伸缩棒可加热1段，一按一个档位，1-4档为加热，4-6档为加热，7档为智能模式，循环往复。

使用说明

- 1.使用时的估计处选择足够的润滑液，可以让整个过程更加顺畅。
- 2.开始使用功能，长按主控制按钮5秒，产品会振动下，加热启动，且智能按钮按灯显示红色呼吸灯效，并开启蓝牙，蓝牙指示灯显示蓝色呼吸灯效。
- 3.关机
(1) 在开机状态下，长按主控制按钮5秒，产品会振动下，加热关闭，且智能按钮按灯显示红色呼吸灯效，并关闭蓝牙，蓝牙指示灯显示蓝色呼吸灯效。
- 4.伸缩
(1) 在开机状态下，短按主控制按钮1秒，伸缩棒可伸缩1段，一按一个档位，1-4档为伸缩，4-6档为伸缩，7档为智能模式，循环往复。
- 5.加热
(1) 在开机状态下，短按主控制按钮1秒，伸缩棒可加热1段，一按一个档位，1-4档为加热，4-6档为加热，7档为智能模式，循环往复。

充电说明

- 1.充电时，智能按钮按灯显示红色呼吸灯效，充电中，按摩器无工作。
- 2.关机时，智能按钮按灯显示红色呼吸灯效，充电中，按摩器无工作。
- 3.充电时，智能按钮按灯显示红色呼吸灯效，充电中，按摩器无工作。
- 4.充电时，智能按钮按灯显示红色呼吸灯效，充电中，按摩器无工作。
- 5.充电时，智能按钮按灯显示红色呼吸灯效，充电中，按摩器无工作。

清洁说明

- 1.使用前后，建议清洁产品后再使用。
- 2.使用前后，建议清洁产品后再使用。
- 3.使用前后，建议清洁产品后再使用。
- 4.使用前后，建议清洁产品后再使用。
- 5.使用前后，建议清洁产品后再使用。

TRYFUN
FUN BEYOND VISION

电脑颜色显示略有差异
具体颜色以潘通色号为准

材料

专色+四色印刷
覆哑膜

色号

材料

专色+四色印刷
覆哑膜

商品环节确认人

设计师： 廖可钰

BU商品：

品控：

法务合规：

版本更新

设计师： 廖可钰

BU商品：

品控：

法务合规：

版本更新

设计师： 廖可钰

BU商品：

品控：

法务合规：