

QUICK START GUIDE

QUICK START GUIDE (EN)


Please read carefully before use

SPECIFICATIONS:


THD: 1%
Working Range: 100ft
Audio output: 2*25W
Charging Time: 5h

Input: 5V/2A
Weight: 2.27kg
Size: 363.6*93*174mm
Bluetooth Version: V5.0


IN THE PACKAGE:



BUTTONS:



-1-



Bluetooth Mode

1. Increase the volume: Short press the volume+button
2. Decrease the volume: Short press the volume-button
3. Next: Long press the volume +button
4. Previous: Long press the volume-button
5. Bluetooth indicator. Blue light lit when speaker is on. Blue light flashing quickly: Speaker is in pairing mode. Blue light solid: Speaker is connected.
6. Charging indicator. White light lit when charging.
 - 1 Light flash(500ms): Power<30%;
 - 1 Light solid+1 light flash:30%<Power<50%;
 - 2 Light solid+1 light flash:50%<Power<75%;
 - 3 Light solid+1 light flash:75%<Power<100%;
 - 4 Light solid: Power=100%.
- Support PD Quick Charge Protocol Adapter(9V 2A)
7. 3.5mm line-in indicator. 3.5mm audio cable insert in, white light is on.
8. Play/Pause: Under the non bluetooth mode, double press it, then the speaker will be ready to pair with other MOTOR BOOM speakers.
9. EX-BASS Button: Short press to open the "EX-BASS"function or close the "EX-BASS"function. When in "EX-BASS"mode, the red light will turn on.
10. Bluetooth Button: Long press to disconnect or reconnect your device under the bluetooth mode.

-2-

Turn On the Power & Turn Off the Power

Turn on the power:Press and hold the button for 2 seconds
Turn off the power:Press and hold the button for 2 seconds
Double-click the power button to turn on/off the power on/off prompt.
Click the power button one time, the light will show you the current battery.

Connect a Non-Bluetooth Audio Device with the 3.5mm Cable


1. Make sure your MOTOR BOOM battery has enough power and turn on the Bluetooth speaker.
 2. Plug one end of the cable into your device's headphone jack and insert the other end into MOTOR BOOM, the white light is on, and you can start playing music.
- Note: When the audio cable is plugged into the speaker, the Bluetooth function will not be available.

Sync Pairing Multi Speakers

You can pair 2 or more MOTOR BOOM Bluetooth speakers at the same time.

1. Open your phone and connect one MOTOR BOOM first. This one is as the Main Speaker.
 2. Double press the "Play/Pause"button of the Main Speaker, ready to pair with other MOTOR BOOM Speakers.
 3. Open other MOTOR BOOM Speakers, double press the "Play/Pause"button. Other speakers are as the Slave Speakers. Slave speakers will receive the pairing signal from the Main Speaker. Then Sync Pairing Process complete.
- Warm Tips: You can control the the volume and music by pressing the "+" / "-" buttons on either speaker. For Better listening experience, please put the speakers within 82 feet between each other.

-3-



Sync Pairing Multi Speakers

Hands Free Calling Function

Hands-free calling is only available for Bluetooth-enabled smartphones.

- Answer/Hang up a call: Short press the Play/Pause button
- Reject Call: Long press the Play/Pause button

Note: In Sync Pairing mode, the call will only be transmitted to the master speaker.

Connect your Bluetooth Device

Please make sure your MOTOR BOOM has enough battery power or it cannot be connected when the battery is too low.

1. Turn on your MOTOR BOOM to prepare for pairing.
 2. Turn on your device's Bluetooth and search for MOTOR BOOM When the connection is successful you will be able to play your music.
 3. When the MOTOR BOOM is turned on, it will automatically try to connect to the last device used.
- Note: When you are pairing different devices, disconnect the existing device.

-4-

Safety Precautions

1. Do not charge near a water source or in the rain to prevent electric shock.
2. Please follow the instructions for all operations and use.
3. Do not damage the cable, especially at the connection.
4. Unplug the USB charging cable when it is not in use or during a thunderstorm.
5. Please keep the speaker away from heat sources(including all equipment that generates heat), such as stoves.
6. Do not attempt to disassemble the speaker.


SYNC PAIRING MULTI SPEAKERS

- Step1
Turn on your Speaker A.

- Step2
Pair the Speaker A with your mobile phone.

- Step3
Double-click the "Play/Pause" button, the speaker A will enter multi sync mode.

- Step4
Turn on your Speaker B, double click the "Play/Pause"button, and the speaker B will enter multi sync mode.



-5-

- Step5
Wait for 3-5s, when the Speaker B emits a prompt tone "synced", the Speaker A and Speaker B are synchronized.

- Step6
To connect 3 or more MOTOR BOOM Bluetooth Speakers together, please first power on and then double-click the "Play/Pause"button, repeat these steps on desired speakers one by one. Wait patiently for 5-10 seconds, all speakers will be synchronized.

Note:

- (1) The speaker that is first successfully paired with the mobile phone's Bluetooth will become the host in the multi-sync mode. When multiple speakers are successfully synchronized, only the green light on the panel of the host will flash; the indicator lights of other speakers will remain on. We strongly advise you to label the host speaker.
- (2) To adjust volume or use other control buttons, you can use your mobile phone or any one speaker to control. When you power off the host, all connected speakers will power off.
- (3) If you want to switch the host, you will need to delete all the paired Bluetooth speakers on the mobile phone and repair your new host speaker.
- (4) It is not recommended to switch the host.
- (5) Any questions, please feel free to contact us.



Scan this code if you are still confused about how to operate Sync Pairing or EX-Bass.

-6-

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



Email: support@dbsoars.net
Web: www.dbsoars.shop

DBSOARS

YouTube DBSOARS

【Please watch tutorial videos on Youtube if any problem to use the speaker】