

User Manual

Veelips



support@toendi.com



+1 (888) 688-5368 (US/CA)

Explore More Pleasure



1-Year Warranty



Body-Safe



Discreet Packaging



Free fast shipping

*Amazon Prime Members Enjoy Free Shipping

Table of Contents

First-Time Use Checklist 01
Discover The JOYHUB App 03
How To Use 04
Connect With The JOYHUB App 05
JOYHUB Smart Control Guide 06
Charging Instructions 07
Cleaning & Safety Tips 08
Usage Scenarios Guide 09
Troubleshooting & Customer Support 10
Warranty & Brand Commitment 11

First-Time Use Checklist



①

CHARGE THE DEVICE FULLY

The indicator light will flash during charging. It will turn solid when fully charged (approximately 2 hours).



②

POWER ON THE DEVICE

Press and hold the power button for 3 seconds to turn on. (A quick press will not activate the device.)



Before Use, Please Verify:


BOTH CONTROL BUTTONS ARE FUNCTIONAL

The tongue swinging and vibration functions operate independently. Experiment with both buttons to find your preferred settings.

4

SAFETY PRECAUTIONS

Never use while charging
Do not immerse in water



5

WANT ENHANCED FEATURES?

Download the JOYHUB App to access:

- Remote control functionality
- Music mode
- Custom vibration patterns and more (see next page for detail)


Toll-Free Support (US/CA): +1 (888) 688-5368
Email: support@toendi.com

If you run into any issues while using the product,
feel free to reach out to us.

Discover The JOYHUB App

**Enhance your Veelips experience
with the JOYHUB App**


Enjoy remote control, custom vibration patterns, and more.



DOWNLOAD NOW

**From the iOS App Store, or scan the QR code.
(Full connection guide on page 5)**

How To Use



► VIBRATION BUTTON


Short press to switch between 9 vibration modes.

► POWER BUTTON

Press and hold to turn ON/OFF.
Short press to switch between 9 swinging modes.

*Fully charge the toy before first use.


Connect with the JOYHUB App



1

TURN ON THE TOY


Press and hold the power button for 3 seconds until the light turns on.



2

OPEN THE JOYHUB APP

Ensure wireless connection is enabled on your phone.



4

PLAY

You can now explore multiple vibration modes, patterns, and remote control options.



3

CONNECT

If not, try restarting the toy or refreshing BT in the app.

Tips for successful connection:


- Fully charge the device before pairing
- Keep the toy powered ON during pairing
- Close and reopen the app if BT fails
- Restart your phone if needed

DOWNLOAD



JOYHUB *Smart Control Guide*


Unlock Veelips's Full Potential



With JOYHUB, enjoy Veelips games and rankings,
explore recommended modes and videos,
draw your own waveforms, chat remotely,
and experience mutual control in private rooms.

Bold Pleasure. Your Rhythm.
Shake things up—anytime, anywhere.

Charging Instructions



Connect the USB cable to the charging port on the device.



Plug the USB end into a power adapter or a USB port.



Charging takes approximately 90 minutes.



While charging, the indicator light will flash.



When fully charged, the light will stay on.



CHARGING TIPS

Do not use the product while charging.

Use only the included charging cable.

Ensure the charging port is dry before connecting.

Please use a certified charging adapter.

Cleaning & Safety Tips



**Wash before
and after use**



**Clean with soap
/neutral detergent**



**Wipe dry after
washing**



**Use water-based
lubricants**



**Do not clean with
alcohol, petroleum,
acetone, or harsh
chemicals**



**Keep away from
heat/fire**



**Store separately
from other toys**



**Avoid silicone-
based lubricants**




SAFETY TIPS

Do not use the product while charging.
Keep away from sharp objects or extreme temperatures.
Store in a cool, dry place.
This product is for personal use only.

Usage Scenarios Guide

To enhance your experience with Toendi products, we've prepared the following usage scenarios for your reference.




SOLO

Let Veelips gently vibrate and swing—shake away the day on your clit and G-spot.



COUPLE PLAY

Connect and shake together — let Veelips thrill your clit and G-spot while your partner controls the pulses, deepening your shared pleasure.



REMOTE PLAY

Link to the JOYHUB APP. Let your partner tease you with real-time vibrations and thrusts.



SELF-CARE RITUAL

Light a candle, relax, and let slow waves of pleasure awaken your most sensitive zones.

FIND YOUR SHAKE WITH VEELIPS.
Discover your rhythm. Own your pleasure.

Troubleshooting & Customer Support

Troubleshooting



MY TOY WON'T TURN ON

Ensure the device is fully charged.
If the issue persists, contact support.



CANNOT CONNECT TO THE APP

Verify that the wireless connection is enabled and the toy is powered on.
If the connection fails, try uninstalling and reinstalling the app.



VIBRATION, THRUST, OR PULSE NOT WORKING?

Switch to a different mode or increase the intensity setting.
If there's still no response, the product may be defective.
Contact us for assistance.

Customer Support



WE'RE HERE FOR YOU!

If you have any issues with the product, our customer support is here to help — feel free to reach out anytime.

Toll-Free Support (US/CA): +1 (888) 688-5368
Email: support@toendi.com

Warranty & Support Commitment

We hope your Toendi Veelips brings you joy, confidence, and unforgettable pleasure. This isn't just a product—it's an invitation to love yourself louder.

OUR COMMITMENT

We stand behind the quality of every Toendi product. If your toy has a manufacturing defect within 12 months of purchase, we'll provide a free replacement or full refund—no questions asked.

WARRANTY COVERAGE

12-month replacement warranty

Warranty Coverage

Excludes damage from misuse, improper cleaning, or storage

Toll-Free Support (US/CA): +1 (888) 688-5368
Email: support@toendi.com



Shake it Shake it Shake it
Shake it Shake it Shake it
Shake it Shake it Shake it



Shake it Shake it Shake it
Shake it Shake it Shake it
Shake it Shake it Shake it
Shake it Shake it Shake it



Thank you for choosing Toendi.

"Shake" is more than vibration—
it's feminine energy and unapologetic joy.

Together, let's shake the world.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.