

105克铜版纸

正面西语说明书尺寸:80×110mm、中间黑线不要、风琴折页

THORA

AUT250

Manual de Usuario

AUDÍFONOS INALÁMBRICOS

Descripción de funciones

① "EQ": Cambio de modo EQ (clic simple) / Asistente de voz (mantener pulsado 2 segundos)

② "+/-": Siguiente canción (mantener pulsado) / Aumentar volumen (clic simple)

③ "-/+": Canción anterior (mantener pulsado) / Disminuir volumen (clic simple)

④ "⏻": Encendido/apagado (mantener pulsado) / Reproducir/pausar (clic simple)

⑤ Luz indicadora de Bluetooth

⑥ Puerto de carga USB-C

⑦ Conector de audio de 3.5 mm

⑧ Agujero del micrófono

Instrucciones de operación

Encendido/Apagado

Mantenga pulsado el botón de encendido durante 2 segundos, las luces roja y azul parpadearán alternativamente, luego los audífonos entrarán en modo de emparejamiento. Active la función Bluetooth en su teléfono (computadora, iPad, etc.) y busque el dispositivo Bluetooth con el nombre: THORA-AUT250. Haga clic en el nombre del dispositivo para conectar, después de una conexión exitosa, la luz azul parpadeará una vez cada 6 segundos.

Emparejamiento

Mantenga pulsado el botón de encendido durante 2 segundos, las luces roja y azul parpadearán alternativamente, luego los audífonos entrarán en modo de emparejamiento. Active la función Bluetooth en su teléfono (computadora, iPad, etc.) y busque el dispositivo Bluetooth con el nombre: THORA-AUT250. Haga clic en el nombre del dispositivo para conectar, después de una conexión exitosa, la luz azul parpadeará una vez cada 6 segundos.

Ajuste de Volumen/Canciones

Subir volumen: Presione una vez +
Bajar volumen: Presione una vez -
Siguiente canción: Mantenga pulsado + durante 1 segundo
Canción anterior: Mantenga pulsado - durante 1 segundo

Reproducir/Pausar

Presione una vez la tecla de reproducción/pausa para controlar la reproducción de música o pausar.

Realización de Llamadas

Contestar la llamada: Al recibir una llamada, presione una vez el botón de encendido.
Rechazar la llamada: Durante una llamada, presione una vez el botón de encendido para finalizar la llamada.
Cancelar la llamada: Mientras marca, presione una vez el botón de encendido para cancelar la llamada.
Rechazar la llamada: Al recibir una llamada, Mantenga pulsado el botón de encendido durante 2 segundos para rechazar la llamada.
Volver a marcar el último número: Doble clic en el botón de encendido para volver a marcar el último número del registro de llamadas.

Eliminar Registros de Emparejamiento

Mantenga pulsados simultáneamente los botones + y - durante 3 segundos. Después de que las luces roja y azul parpadecen alternativamente, se borrarán los registros de emparejamiento de los audífonos.

Asistente de Voz

Presione una vez el botón EQ durante 2 segundos para activar a Siri o al Asistente de Google.

Cambio de modo EQ

Presione una vez el botón EQ para alternar entre tres modos de EQ: modo de bajos, modo vocal, modo pop.

Indicaciones luminosas

Conexión exitosa	La luz azul parpadeará una vez cada 6 segundos
Modo de emparejamiento	Las luces roja y azul parpadearán alternativamente
Registro de emparejamiento eliminado	Las luces roja y azul parpadearán alternativamente
Escuchando música	La luz azul parpadeará una vez cada 6 segundos
Completamente cargado	La luz azul permanece encendida
Apagado	La luz roja parpadeará durante 1 segundo y luego se apagará
Carga	La luz roja permanece encendida

Especificaciones Técnicas

Modelo del producto	AUT250
Conexión inalámbrica	5.3
Alcance de Bluetooth	≥10m
Rango de Frecuencia	2402-2480MHz
Voltaje de Entrada	5V=1A
Tiempo de Carga	Aproximadamente 3 horas
Duración de reproducción	Aproximadamente 100 horas (El tiempo real de reproducción puede variar según el nivel de volumen y el contenido de audio)
Puerto de Carga	Puerto de carga USB-C
Especificaciones del Alavoz	40mm/18Ω

Preguntas Frecuentes (Q&A)

1. Los audífonos no se encienden

(1) Asegúrese de que los audífonos estén cargados.

(2) Desconecte el cable de audio de la fuente de audio y luego intente presionar el botón de encendido otra vez.

2. Emparejamiento Bluetooth sin éxito

Asegúrese de que los audífonos estén encendidos y en modo de emparejamiento, mantenga una distancia de emparejamiento de 1 metro y vuelva a intentar emparejar.

3. Reconexión automática

Se reconectan automáticamente al último teléfono móvil emparejado después de encenderlos.

4. Interrupciones de sonido/Sin sonido

(1) Verifique si los audífonos están encendidos.

(2) Verifique si el volumen del dispositivo está en el mínimo o silenciado.

(3) Verifique si la distancia de conexión excede el rango efectivo o si hay obstáculos entre el dispositivo y los audífonos.

5. Métodos de carga

Utilice un cargador de corriente continua de salida de 5V/1A, cargador para automóvil o batería externa para cargar.

Advertencia

*No desmonte ni modifique los auriculares, ya que puede causar fallas o daños permanentes en los auriculares.
*No coloque los auriculares en entornos con temperaturas extremas.
*No exponga los auriculares a la humedad ni los sumerja en líquido.
*Evite caídas, impactos, perforaciones excesivas u otras acciones que puedan afectar la funcionalidad de los auriculares.
*Este producto contiene una batería de iones de litio recargable. No la desmonte, aplaste ni la desheche en el fuego.

Declaración de Garantía

Ofrecemos un servicio de garantía de 12 meses para este producto, pero las siguientes situaciones no están cubiertas por la garantía.

1.El período de garantía ha expirado.

2.La tarjeta de garantía ha sido alterada y no coincide con el código y el cuerpo del producto.

3.Malfuncionamiento o daño causado por un uso inadecuado, abuso, transporte inadecuado, uso, mantenimiento o almacenamiento.

4.Malfuncionamiento o daño causado por fuerza mayor (como terremotos, guerras, incendios, etc.) o accidentes.

5.Daño a cremalleras o hebillas debido a una fuerza excesiva.

6.Costuras rotas o desgarradas causadas por sobrecarga.

7.Daño causado por cualquier objeto afilado.

8.Productos con signos de quemaduras o inmersión en agua.

9.Daño causado por desmontaje o modificación no autorizados.

10.Envejecimiento, decoloración, desgaste, agrietamiento y otros desgastes que ocurren durante el uso normal del producto.

11.Si se cambia o daña la etiqueta de identificación original del producto, esta garantía quedará anulada. La integridad y apariencia del producto y los materiales acompañantes no están cubiertos por la garantía. Por favor, inspeccione y presente objeciones en el acto al recibir el producto.

Servicio al Cliente

support@thora.com www.thora.com

反面英语说明书尺寸:80×110mm、中间黑线不要、风琴折页

Function Overview

1

2

3

4

5

6

7

8

1

2

3

4

5

6

7

8

① "EQ": EQ mode switch (single click) / Voice assistant (long press 2s)

② "+/-": Next track (long press) / Volume Up (single click)

③ "-/+": Previous track (long press) / Volume Down (single click)

④ "⏻": Power on/off (long press) / Play/pause (single click)

⑤ Bluetooth Indicator Light

⑥ USB-C Charging Port

⑦ 3.5mm Audio Jack

⑧ Microphone Hole

Operation Instructions

Power On/Off

Long press the power button for 2 seconds, the red and blue lights will flash alternately, and then power on. The headphone will enter pairing mode or reconnect to the last paired Bluetooth device. Long press the power button for 3 seconds, the red light will stay on for 1 second, then power off.

Pairing

Press and hold the power button for 2 seconds, the red and blue lights flash alternately, and the device enters pairing mode. Turn on the Bluetooth function of your phone (computer, iPad, etc.) and search for the Bluetooth device name: THORA-AUT250. Click the device name to connect. After the connection is successful, the blue light flashes once every 6 seconds.

Bluetooth

Bluetooth

THORA-AUT250

THORA-AUT250

THORA-AUT250

THORA-AUT250

THORA-AUT250

THORA-AUT250

Volume/Songs

Volume up: Single press "+"
Volume down: Single press "-"
Next track: Long press "+" for 1 second
Previous track: Long press "-" for 1 second

Play/Pause

Single press the play/pause key to control music playback or pause.

Making Phone Calls

Answer the call: When receiving a call, single click the power button.
End the call: During a call, single click the power button to end the call.
Reject the call: When receiving a call, long press the power button for 2 seconds to reject the call.
Redial the last number: Double click the power button to redial the last number from the call log.

Clear Pairing Records

Simultaneously long press the "+" button and "⏻" button for 3 seconds. After the red and blue lights flash alternately, the headphone pairing records will be cleared.

Voice Assistant

Long press the EQ button for 2 seconds to activate Siri or Google Assistant.

EQ Mode Switching

Single click the EQ button to switch between three EQ modes: bass mode, vocal mode, pop mode.

Line-in Mode

After plugging the audio cable into the headphone's 3.5mm audio jack, you can directly connect a playback device to listen to music. At this time, the headphones are in Line-in Mode.

Note: When inserting the audio cable while the headphones are powered on, the headphone will automatically power off. In order to power it on, please remove the audio cable from the audio jack.

Light Indications

Successful connection

Blue light flashes once every 6 seconds

Pairing mode

Red and blue lights alternate flashing

Pairing records cleared

Red and blue lights alternate flashing

Listening to music

Blue light flashes once every 6 seconds

Fully charged

Blue light stays on

Power off

Red light flashes for 1 second then turns off

Charging

Red light stays on

Technical Specifications

Product Model

AUT250

Wireless Connection

5.3

Bluetooth Range

≥10m

Frequency Range

2402-2480MHz

Input Voltage

5V=1A

Charging Time

Approximately 3 hours

Playback time

Approximately 100 hours (Actual playback time may vary depending on volume level and audio content)

Charging Port

USB-C charging port

Speaker Specifications

40mm/18Ω

Frequently Asked Questions (FAQs)

1. Headphone can't be turned on

(1) Please ensure the headphone has been charged.

(2) Disconnect the audio cable from the audio source, and then try to press the power button again.

2. Bluetooth Pairing Failed

Ensure the headphone is powered on and in pairing mode, maintain a pairing distance of 1 meter, and try pairing again.

3. Auto Reconnection

Automatically reconnect to the last paired mobile phone after powering on.

4. Sound interruptions/No sound

(1) Check if the headphone is turned on

(2) Check if the device volume has been set to minimum or muted

(3) Check if the connection distance exceeds the effective range or if there are obstacles between the device and the headphones.

5. Charging Methods

Use a direct current output of 5V/1A charger, car charger, or power bank for charging.

Warning

*Do not disassemble or modify the headphones, as it may cause malfunctions or permanent damage to the headphones.
*Do not place the headphones in environments with extreme temperatures.
*Do not expose the headphones to moisture or submerge them in liquid.
*Avoid excessive dropping, impacts, piercing, or any actions that may affect the functionality of the headphones.
*This product contains a rechargeable lithium-ion battery. Do not dismantle, crush, or dispose of in fire.

Warranty Statement

We provide a 12-month warranty service for this product, but the following situations are not covered by the warranty.

1.Warranty period has expired.

2.Warranty card has been altered and does not match the product code and body.

3.Malfunction or damage caused by misuse, abuse, improper transportation, use, maintenance or storage.

4.Malfunction or damage caused by force majeure (such as earthquakes, wars, fires, etc.) or accidents.

5.Damage to zippers or buckles due to excessive force.

6.Stitching or tearing caused by overloading.

7.Damage caused by any sharp object.

8.Products with signs of burning or water immersion.

9.Damage caused by unauthorized disassembly or modification.

10.Aging, discoloration, wear and tear, cracking, and other wear and tear that occur during normal use of the product.

11.If the original identification label of the product is changed or damaged, this warranty will be void.

Completeness and appearance of the product and accompanying materials are not covered by the warranty. Please inspect and raise objections on the spot when receiving the product.

Customer Service

support@thora.com

www.thora.com

FCC Warning

FCC ID:2A9HV-AUT250

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.