

中文

GS380使用说明书

1.外观说明

摄像头

闪光灯

按键

Type-C充电接口

扬声器

2.操作说明

触控区

后按键

前按键

提示：仅右镜腿设有触控区与按键。

如何开机/关机？

长按后按键2秒

开机/关机

如何进入配对状态？

开启眼镜，即可进入配对状态

如何使用眼镜拍摄？

单击前按键

拍照

双击前按键

录制视频

如何播放音乐？

单击触控区

播放/暂停

向前滑动触控区

下一首

向后滑动触控区

上一首

3.充电说明

当眼镜连接充电线后，将充电线的 USB 端接入标准充电器，仅需 60 分钟即可充满。

4.无线配对

打开手机无线搜索眼镜名“GSXXX ”，在手机端点击配对即可。

5.安装连接APP

1.手机扫描二维码下载并安装APP。

支持系统：iPhone10.0、Android9.0 及以上版本

2.在APP中登录帐号，选择连接绑定眼镜。

提示：请确保手机无线处于开启状态，连接过程中需将眼镜靠近手机。

6.产品参数

产品类型：智能眼镜

扬声器：高保真

电池容量：260mAh

无线连接：5.4

麦克风：语音降噪

充电时间：60分钟

续航时间：10小时以上

7.主要功能

播放音乐

无线通话

语音助手

计步

距离

控制眼镜拍摄

提示：若您使用HarmonyOS系统手机，无线设备音量与手机同步，可按以下步骤操作：打开手机“设置”，点击“无线”；在已配对设备列表中，点击无线设备右侧的设置图标；开启“无线设备音量与手机同步”即可。

8.注意事项

1.切勿严重撞击眼镜。

2.切勿接触苯、稀释剂等化学物品。

3.请不要靠近强磁场、电击站。

4.请避开直射光线或发热器具。

5.切勿自行拆卸、修理、改造。

6.废弃包装、电池、旧电子产品，请分类妥善处理。

英语

GS380 User's Manual

1. Appearance description

Camera

Flash

Buttons

Type-C Charging Port

Speaker

2. Operating Instructions

Touch Zone

Rear button

Front button

Tip: Only the right lens leg is equipped with a touch area and buttons.

How to turn on/off the camera?

Press and hold the rear button for 2 seconds

Power on/off

How to enter pairing status?

Turn on the glasses to enter pairing status.

How to shoot with glasses?

Click the front button

Take a picture

Double-click the front button

Record video

How to play music?

Click on the touch area

Play/Pause

Swipe forward on the touchpad

Next song

Swipe backward

Previous

3. Charging Instructions

When the glasses are connected to the charging cable, connect the USB end of the charging cable to a standard charger and it will take only 60 minutes to fully charge.

4. Wireless Pairing

Turn on your cell phone and search for the name of the glasses "GSXXX" wirelessly, then click pairing on the cell phone.

5. Installation of Connection APP

1. Scan the QR code on your cell phone to download and install APP.

Support system: For iPhone10.0, Android9.0 and above.

2. Log in your account in APP and choose to connect the bound glasses.

Tips: Please make sure the wireless of your cell phone is on, and keep the glasses close to your cell phone during the connection process.

6. Product Parameters

Product type: smart glasses

Speaker: Hi-Fi

Battery capacity: 260mAh

Wireless connection: 5.4

Microphone: voice noise reduction

Charging time: 60 minutes

Battery life: more than 10 hours

7. Main Functions

Play music

Wireless call

Voice assistant

Step counting

Distance

Control glasses shooting

Tip: If you are using HarmonyOS cell phone, the volume of the wireless device is synchronized with the cell phone, you can follow the steps below: open the "Settings" of the cell phone, click "Wireless"; in the list of paired devices, click the Settings icon on the right side of the wireless device; turn on the "Synchronize the volume of wireless devices with the phone" can be turned on.

8. Precautions

1. Do not hit the glasses severely.

2. Do not contact with chemicals such as benzene and thinner.

3. Do not approach strong magnetic fields, electric shock stations.

4. Avoid direct light or heat generating appliances.

5. Do not disassemble, repair or remodel by yourself.

6. Please categorize and properly dispose of discarded packages, batteries and old electronic products.

**FCC Warning:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.