




n41 SCS=30kHz CP_QPSK BW=20MHz Channel=535998 RB=51@0




n41 SCS=30kHz CP_QPSK BW=20MHz Channel=535998 RB=1@0




n41 SCS=30kHz CP_QPSK BW=20MHz Channel=535998 RB=1@50




n41 SCS=30kHz CP_QPSK BW=60MHz Channel=505200 RB=162@0




n41 SCS=30kHz CP_QPSK BW=60MHz Channel=505200 RB=1@0




n41 SCS=30kHz CP_QPSK BW=60MHz Channel=505200 RB=1@161




n41 SCS=30kHz CP_QPSK BW=60MHz Channel=531996 RB=162@0




n41 SCS=30kHz CP_QPSK BW=60MHz Channel=531996 RB=1@0




n41 SCS=30kHz CP_QPSK BW=60MHz Channel=531996 RB=1@161




n41 SCS=30kHz CP_QPSK BW=100MHz Channel=509202 RB=273@0




n41 SCS=30kHz CP_QPSK BW=100MHz Channel=509202 RB=1@0




n41 SCS=30kHz CP_QPSK BW=100MHz Channel=509202 RB=1@272




n41 SCS=30kHz CP_QPSK BW=100MHz Channel=528000 RB=273@0




n41 SCS=30kHz CP_QPSK BW=100MHz Channel=528000 RB=1@0




n41 SCS=30kHz CP_QPSK BW=100MHz Channel=528000 RB=1@272




n41 SCS=30kHz CP_QPSK BW=20MHz Channel=518598 RB=51@0




n41 SCS=30kHz CP_QPSK BW=20MHz Channel=518598 RB=1@0




n41 SCS=30kHz CP_QPSK BW=20MHz Channel=518598 RB=1@50




n41 SCS=30kHz CP_QPSK BW=60MHz Channel=518598 RB=162@0




n41 SCS=30kHz CP_QPSK BW=60MHz Channel=518598 RB=1@0




n41 SCS=30kHz CP_QPSK BW=60MHz Channel=518598 RB=1@161



n41 SCS=30kHz CP_QPSK BW=100MHz Channel=518598 RB=273@0



n41 SCS=30kHz CP_QPSK BW=100MHz Channel=518598 RB=1@0



n41 SCS=30kHz CP_QPSK BW=100MHz Channel=518598 RB=1@272

