


< PREFACE >

To make your experience with the remote control car as easy and convenient as possible, please read the instructions provided before using the product. Enjoy and have fun with the product while keeping the manual for future maintenance and reference.


- In order to protect the legitimate rights and interests of users, please be sure to carefully read the contents of the manual before using the product.
- When using the product, please be sure to strictly observe and perform the requirements which include but are not limited to the instructions and safety guidelines. For any personal injury, accident, property loss, legal dispute or any other adverse event, causing a conflict of interest resulting from the use of the product or any inevitable factors that are in violation of the safety instructions, the user that uses the remote-controlled car, DEERC will not take any responsibility.
- Once you start using the product, you are deemed to have read, understood, recommended, and accepted all terms and contents of the instructions including disclaimers, safety instructions, warning instructions, etc. included with this product.
- In case you are having challenges on any aspect of the product, may be a question or maintenance, please contact your local sales agent or contact customer support of DEERC.

1

< PACKAGE CONTENTS >




< RC CAR'S DETAILS >



2

< REMOTE CONTROL FUNCTIONS >




< BATTERY INSTALLATION >

- 1. RC Car Battery**
 - Uncover and open the battery cover.
 - Connect the battery cable to the cable in the battery compartment.
 - Close the battery cover and lock it.If the car will not be used for a long time, make sure to take out the battery.

3

2. Remote Control Battery



< CHARGING >


- Plug the USB charging cable into the USB charging port of the computer, power bank or USB adapter (DHL 05-2000).
- Connect the battery cable to the USB charging cable.
- Charging time about 90 minutes.
- The red indicator light on the USB charging cable will turn on when it is charging and will turn off once fully charged.

4


Attention:
Please keep the battery in sight when charging. Do not put the battery on a flammable surface.
If battery pack and USB charging cable are damaged, immediately stop using it and replace the accessories as soon as possible.

< OPERATION >

- 1. Parking**
Once the car is started to the car and the remote, turn on the car following the remote. Both will automatically park. The remote power indicator will flash while waiting for the parking position and will turn off once parking has been achieved.
- 2. Forward, Backward, Turn left and Turn right**



< TRIMMER FUNCTION >



< SPECIFICATIONS >

Climbing Time: < 45 minutes
Driving Time: < 15 minutes
Battery Type: Ni-MH 3.7V 100mAh
Charging Time: about 90 minutes
Max. Control Distance: 50m
Battery Type for Remote Control: 1.5V AA battery
USB Charging Cable: Voltage 5V
Rated Power: < 10W
Operating Temperature Range: 32°F to 104°F (0°C to 40°C)

5


< PREFACE >

To make your experience with the remote control car as easy and convenient as possible, please read the instructions provided before using the product. Enjoy and have fun with the product while keeping the manual for future maintenance and reference.


- In order to protect the legitimate rights and interests of users, please be sure to carefully read the contents of the manual before using the product.
- When using the product, please be sure to strictly observe and perform the requirements which include but are not limited to the instructions and safety guidelines. For any personal injury, accident, property loss, legal dispute or any other adverse event, causing a conflict of interest resulting from the use of the product or any inevitable factors that are in violation of the safety instructions, the user that uses the remote-controlled car, DEERC will not take any responsibility.
- Once you start using the product, you are deemed to have read, understood, recommended, and accepted all terms and contents of the instructions including disclaimers, safety instructions, warning instructions, etc. included with this product.
- In case you are having challenges on any aspect of the product, may be a question or maintenance, please contact your local sales agent or contact customer support of DEERC.

1

< PACKAGE CONTENTS >




< RC CAR'S DETAILS >



2

< REMOTE CONTROL FUNCTIONS >




< BATTERY INSTALLATION >

- 1. RC Car Battery**
 - Uncover and open the battery cover.
 - Connect the battery cable to the cable in the battery compartment.
 - Close the battery cover and lock it.If the car will not be used for a long time, make sure to take out the battery.

3

2. Remote Control Battery



< CHARGING >


- Plug the USB charging cable into the USB charging port of the computer, power bank or USB adapter (DHL 05-2000).
- Connect the battery cable to the USB charging cable.
- Charging time about 90 minutes.
- The red indicator light on the USB charging cable will turn on when it is charging and will turn off once fully charged.

4


Attention:
Please keep the battery in sight when charging. Do not put the battery on a flammable surface.
If battery pack and USB charging cable are damaged, immediately stop using it and replace the accessories as soon as possible.

< OPERATION >

- 1. Parking**
Once the car is started to the car and the remote, turn on the car following the remote. Both will automatically park. The remote power indicator will flash while waiting for the parking position and will turn off once parking has been achieved.
- 2. Forward, Backward, Turn left and Turn right**



< TRIMMER FUNCTION >



< SPECIFICATIONS >

Climbing Time: < 45 minutes
Driving Time: < 15 minutes
Battery Type: Ni-MH 3.7V 100mAh
Charging Time: about 90 minutes
Max. Control Distance: 50m
Battery Type for Remote Control: 1.5V AA battery
USB Charging Cable: Voltage 5V
Rated Power: < 10W
Operating Temperature Range: 32°F to 104°F (0°C to 40°C)

5


< PREFACE >

To make your experience with the remote control car as easy and convenient as possible, please read the instructions provided before using the product. Enjoy and have fun with the product while keeping the manual for future maintenance and reference.


- In order to protect the legitimate rights and interests of users, please be sure to carefully read the contents of the manual before using the product.
- When using the product, please be sure to strictly observe and perform the requirements which include but are not limited to the instructions and safety guidelines. For any personal injury, accident, property loss, legal dispute or any other adverse event, causing a conflict of interest resulting from the use of the product or any inevitable factors that are in violation of the safety instructions, the user that uses the remote-controlled car, DEERC will not take any responsibility.
- Once you start using the product, you are deemed to have read, understood, recommended, and accepted all terms and contents of the instructions including disclaimers, safety instructions, warning instructions, etc. included with this product.
- In case you are having challenges on any aspect of the product, may be a question or maintenance, please contact your local sales agent or contact customer support of DEERC.

1

< PACKAGE CONTENTS >




< RC CAR'S DETAILS >



2

< REMOTE CONTROL FUNCTIONS >



< BATTERY INSTALLATION >

- 1. RC Car Battery**
 - Uncover and open the battery cover.
 - Connect the battery cable to the cable in the battery compartment.
 - Close the battery cover and lock it.If the car will not be used for a long time, make sure to take out the battery.

3

2. Remote Control Battery



< CHARGING >


- Plug the USB charging cable into the USB charging port of the computer, power bank or USB adapter (DHL 05-2000).
- Connect the battery cable to the USB charging cable.
- Charging time about 90 minutes.
- The red indicator light on the USB charging cable will turn on when it is charging and will turn off once fully charged.

4



Attention:
Please keep the battery in sight when charging. Do not put the battery on a flammable surface.
If battery pack and USB charging cable are damaged, immediately stop using it and replace the accessories as soon as possible.

< OPERATION >

- 1. Parking**
Once the car is started to the car and the remote, turn on the car following the remote. Both will automatically park. The remote power indicator will flash while waiting for the parking position and will turn off once parking has been achieved.
- 2. Forward, Backward, Turn left and Turn right**



< TRIMMER FUNCTION >



< SPECIFICATIONS >

Climbing Time: < 45 minutes
Driving Time: < 15 minutes
Battery Type: Ni-MH 3.7V 100mAh
Charging Time: about 90 minutes
Max. Control Distance: 50m
Battery Type for Remote Control: 1.5V AA battery
USB Charging Cable: Voltage 5V
Rated Power: < 10W
Operating Temperature Range: 32°F to 104°F (0°C to 40°C)

5

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.