

V13 Pro Quick Start Manual

Product Overview



Important Reminder:
Before installing the headset, please connect your mobile phone according to the quick manual guide to test the sound effect and volume.
If there is a big difference in sound effect and volume after installing into the helmet, please adjust the position of the speaker inside the helmet.

Power on/off

Double click to switch language broadcasting(Disconnect wireless)



Power on tone

Press and hold for 3 seconds to power on/off



LED blinks rapidly

Wireless connection



Wireless mode tone



Successful wireless pairing: LED flashes slowly

Intercom pairing



Simultaneous short press 'intercom key + volume up key' to switch the light mode (13 kinds)



After switching to the last light mode, then short press at the same time to switch off the light (default on)



After the machine is switched on, the two devices short press the intercom button to enter the intercom mode, intercom LED light flashes rapidly, accompanied by a tone 'intercom pairing', pairing success will be prompted by a tone to indicate that the pairing is successful 'connected', at this time you can 'two people talk to each other', short press again to exit the intercom mode

Turn on/off RGB lighting




After switching to the last light mode, then short press at the same time to switch off the light (default on)




RGB Lighting

Telephone function


Double-tap to toggle manual/automatic answer(when not connected to wireless, intercom)



Music function



Music Sharing Pairing/Intercom and Music Sharing Coexistence



Music Share Pairing Status: Music Share Pairing Successful: While Indicator Light Long On

After the two devices are turned on, when the intercom connection is successful, if you want to connect to the mobile phone to play music, and double-click the intercom button to turn on the mixing mode. At this time, music sharing and intercom exist at the same time (mixing mode) (at this time, the intercom green LED light and the music sharing while LED light are on at the same time), then double-click the intercom button to switch to separate music sharing (music sharing mode) (at this time, the intercom green LED light and the music sharing while LED light are off at the same time). In music sharing mode, press and hold the volume plus or minus button to adjust the volume of music sharing mode, press and hold the volume plus or minus button to adjust the volume of wireless music at the same time

Mixing function



Intercom and wireless can work independently without affecting each other, when the intercom and wireless are connected, the two sounds can be mixed out to the speaker end, you can hear the sound of the two at the same time. When the intercom is successfully connected, the volume up and down keys operate as follows: 1: Short press the volume up and down keys to adjust the volume size of the wireless music; 2: Long press the volume up and down keys to adjust the volume size of the intercom; 3: Double-click the 'volume up and down keys' to switch the next and previous songs of the wireless music.

Dating mode (connecting third parties)




Dating Mode Waiting for Pairing: Wireless LED light flashes super fast

Successful pairing in dating mode: Wireless LED lights up long time

Voice assistant




Charging function



Intercom reset

Introduction to wireless intercom connection operation (Intercom and music sharing are switched off by default every time you switch on the computer):
I. If there are two machines, when the two machines are switched on, short press the intercom key to enter intercom mode, and short press the corresponding pairing key on the host to connect back to the other corresponding machines.
II. If there is one machine, when the machine is switched on and the machine is connected to the wireless, no matter which mode the machine is in, when the machine is calling or going to the phone, it will take priority to enter the phone mode automatically and resume the corresponding mode after hanging up.
III. Once the machine is connected to the wireless, when the machine is connected to the wireless, power on without connecting wireless and intercom, long press the volume down and volume up buttons at the same time for 5S, clear the wireless pairing information, the indicator light flashes fast.

Product List



Caveat

1. To avoid explosion, please do not put the product into the flame;
2. Please do not disassemble the product to avoid damage to the electronic components of the product;
3. Please keep away from sharp objects to avoid damage to the product;
4. Please keep in a dry place and not expose to direct sunlight for long time;
5. Before using the device, please charge it;
6. If the red light does not come on while charging, it may be the voltage is too low;
7. To extend the life of the built-in lithium polymer battery, please charge the device at least once a month.

Instruction warning

NOTE: This product has been tested, meet the restrictions of Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.
-Reorient or relocate the receiving antenna.
-Increase the separation between the device and receiver.
-Connect the device into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.
This device complies with Part15 of the FCC Rules. The operation needs to fullfil the following two conditions.
(1)This device may not cause harmful interference.
(2)This device must accept any interference received, including interference that may cause undesired operation.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.