

V80使用说明书



产品概览



重要提醒：
耳机安装前请按快速手册指引连接手机试听音效和音量。
如安装到头盔后音效和音量有较大的差异请调整喇叭在头盔内的位置。

开机/关机

开机

双击切换中英文语音播报
(断开蓝牙)



长按3秒开机



开机提示音



LED灯快闪

配对



蓝牙未连接灯光快闪



蓝牙模式 提示音



蓝牙连接成功
LED灯慢闪

灯光开启与关闭



长按AI语音键，灯光开启与关闭



灯效



灯光

音乐功能

暂停/播放音乐



短按



(音乐暂停时)



播放



(音乐播放时)



暂停


音量-键



(音乐播放时)



短按上一曲



(音乐播放时)



长按音量减少


音量+键



(音乐播放时)



短按下一曲



(音乐播放时)



长按音量加大

Eq 音效模式

EQ 音效
模式切换



音效自然模式

音效重低音模式

音效 3D 环绕模式

音效3D环绕+重低音模式

音效键指示灯关闭

音效键指示灯红灯长亮

音效键指示灯绿灯长亮

音效键指示灯蓝灯长亮

电话功能



接听模式切换
自动模式(≤10秒后)自动接听




(未连接蓝牙时)



双击音量+键 切换
手动接听/自动接听



自动模式



(来电中)


(≤10秒后)自动接听



自动接听



手动接听“短按”




(来电中)

接听



长按2秒




(来电中)

拒绝接听



通话时“短按”




(通话中)

挂断电话




双击



未码重播



短按



(通话中)

取消去电

充电模式



充电时
红灯



充满电时
灯灭


物品清单




Y80主机*1




喇叭麦克风*1



夹式底座*1



魔术贴安装包*1



Type-C充电线*1



使用说明书*1

注意事项

1. 请勿将产品投入明火中，避免发生爆炸；
2. 请勿靠近尖锐器，物对产品造成损坏；
3. 请勿拆卸产品，避免产品电子器件损坏；
4. 长时间不用，请放置于干燥处。

V80 QUICK INSTRUCTION MANUAL

Product overview



Important Notice:

Before installing the headphones, follow the Quick Manual instructions to connect your phone and listen to the sound and volume. If there is a large difference in sound effect and volume after installing it on the helmet, please adjust the position of the speaker in the helmet.

Power on/off

Power on

Double click to switch between Chinese and English voice broadcasting (Disconnect Wireless)



Long press for 3 seconds Power on



Power-on tone



LED light flashing fast

Charging mode



Wireless Unconnected Light Flash



Wireless mode prompt tone



Wireless connection successful
LED light flashing slowly

灯光开启与关闭



Long press the AI voice key
Light on and off



Lamp effect



lighting

Telephone function



(When Bluetooth is not connected)



Answer mode switching
Automatic mode (after 10 seconds)
Automatic answer

Double click volume+key switch
Manual answer/automatic answer



Automatic mode



Incoming call
(>10秒后)自动接听

Auto Answer



Manual answer
Short press



Incoming call

answer




Long press for 2 seconds



Refuse to answer



Short press during a call



ring off




double click



End code replay



Short press



Cancel power outage

Music features

Pause/play music



Short press



Music Pause



play



Music playback

suspend



Volume - Key



Music playback



Short press the previous song



Music playback



Long press to decrease volume



Volume+key



Music playback



短按下一曲



Music playback



长按音量加大

EQ Sound mode



EQ sound effect
Mode switching

Natural sound mode
Sound effect bass mode
Sound 3D surround mode
Sound 3D surround+ bass mode

Sound effect key indicator light off
The sound effect key indicator light is red and permanently on
The sound effect key indicator light remains green for a long time
Sound effect key indicator light blue light permanently on

charge mode



Red light when charging



When fully charged
Lamp out



Y80Host*1




Speaker microphone*1



Clip-on base*1



Velcro installation package*1



Type-C charging cable*1



Instruction manual*1

Notes

1. Do not put the product into the open flame to avoid explosion;
2. Do not disassemble the product. Avoid damage to product electronics;
3. Do not approach the sharp object, the object will cause damage to the product;
4. Do not use for a long time, please place in a dry place.

instruction warning

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF warning statement: the device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

MADE IN CHINA