


# Brighttown®

S14 PATIO SOLAR STRING LIGHTS



## IMPORTANT SAFETY INSTRUCTIONS




1. Do not mount or place near gas or electric heaters, fireplace, candles or other similar source installation.
2. Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails, Install only using the mounting kits provided.
3. Do not let the product rest on the power supply cord or on any electric cord.
4. Do not use this product for other than its intended use.
5. Do not hang other decoration or objects on cord, wire or light string.
6. Do not close doors or window if clamping or damaging the products or cord.
7. Do not cover the product with cloth, paper or any material not part of the product when in use.
8. Read and follow all instructions on this products.

**⚠ WARNING:** This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm, for more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).



PLEASE READ THIS MANUAL CAREFULLY AND KEEP IT FOR FUTURE REFERENCE

## INSTALLATION ON WALL



1. Install on brick or concrete wall, mark the installing position, using electric drill to drill three holes. Hammer the plastic plugs into the holes. Using screw driver to drive firmly.



2. Install on wooden wall, using the same way as above but no need to use plastic plugs.



3. Adjust the joint bolt to fix the solar panel direction.




## PLUG IN THE GROUND



1. Insert the stake firmly



2. Plug in the ground




## CLIP ON DECK




## OPERATIONS

1. Connect the string lights with solar panel and hang up with cable ties.




2. Press the button on the back of panel to switch on, the indicator will turn blue.  
The string light will be on at dusk and will be off at dawn automatically.
3. Use the button on remote to set timer(the lights will flash once when timer set), brightness, speed or modes.




## RECHARGING THROUGH USB PORT

Uncover the USB charging port on the side of the panel. Recharge the the built-in batteries if the weather is poor, such as in rain or cloudy day. The indicator on panel will turn red during charging or in low power, it will turn green when the battery is fully charged.



## BULB REPLACEMENT

- Step 1: Screw out the old one from the holder counterclockwise.  
Step 2: Screw up a new one properly clockwise.  
Step 3: Complete.



## TROUBLESHOOTING

1. If the string lights do not work, make sure the solar panel is switched on.
2. If the string lights do not work, make sure the solar panel is not covered by other things.
3. If the string light do not work, recharge the solar panel or place it in the sunlight.
4. The light flashes, do not make the solar panel sensing the bulb light.
5. If the remote does not work, the battery may exhaust, replace with new battery.
6. If the above cases do not work, ask a professional electrician for help or contact us.

## SPECIFICATION

1. Solar panel: 3.4W/5.5V(19% efficiency)
2. Charging time: 8-12H(solar), 7H(USB charger 5V 1A)
3. RF Remote working range: 32-96 feet

## PACKAGE

String Lights with Solar Panel  
1 x Remote  
User Manual

**FCC statement:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC warning:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## 1 Year Limited Warranty

The product is warranted against defects in materials and workmanship under normal use and service for a period of one year from the date of original purchase when delivered to you in new condition in its original container, warranty repair or replacement shall not extend the original warranty period of the product, a dated proof of purchase is required at the time of warranty service, a copy of your dated bill of sale will satisfy this requirement.

This warranty does not cover accessories or consumables, such as light bulbs, as to which there shall be no warranty or replacement.

This limited warranty covers all defects encountered in normal use of the product and does not apply to the following cases:

1. Loss or damage of the product due to abuse, neglect, mishandling, improper packaging, alteration, accident, electrical current fluctuation, improper use, failure to follow operating or maintenance instructions prescribed in Brightown safety instructions or other documentation, dropping, scratches and abrasion will be presumed to generate from misuse, abuse or failure to operate as set forth in the user's manual or other documentation for the product.
2. Use of other parts or supplies (other than those sold by Brightown) that cause damage to the product
3. If the product's model number or dating defaced, altered or removed

For customer service and warranty, contact us here

-  [www.brightown.com](http://www.brightown.com)
-  [support@brightown.com](mailto:support@brightown.com)
-  US +1 (888) 550 1319  
Mon-Fri 8AM-10PM(EST)