





Operating Instructions



Reset:

- Short press to restore the original password "8888".
- Long press to restore factory settings.

Indicator:

- When it is on, it means the machine is working during the defined period.
- When bluetooth connects and operates successfully a "beep" sound is emitted by the machine.

CONNECT YOUR DIFFUSER TO THE NEW AROMAPLAN APP.
MORE CONVENIENT AND INTELLIGENT.

Connectivity Instruction




Important Notes:

- 1 - This device is compatible with devices that support Bluetooth wireless technology. Make sure the function on your phone is **turned ON**.
- 2 - Ensure the location services on your mobile phone are enabled.

Where to download the AromaPlan app:

Scan the QR Code to download the app on your phone.
Available on the App Store and Play Store.

Attention: Your Scent Diffuser Smart Plug-in can only be configured using the app.



Setting Up Your Device with the App

1

SIGN UP
Open the AromaPlan app and **create an account**, or **log in** quickly using **Google** or **Apple**.

2

APP DASHBOARD
After signing in, access the main dashboard. Tap **"Add New Device"** to pair your diffuser.






3

PAIR YOUR DEVICE
Verify if the Bluetooth is **turned on**, on your device.

4

SELECT YOUR MODEL
Choose the correct model and color of your diffuser from the list.



5


ASSIGN A LOCATION

Select or name the location where your scent diffuser will be installed.

6

DEVICE SETTINGS

Once the setup is complete, you can easily turn your diffuser **ON** or **OFF** directly from the app.



7



ADVANCED SETTINGS

Tap **"Add Schedule"** to access advanced features, including adjusting the intensity of diffusion. Select from **10 intensity levels** and customize your settings. You can also **define specific days of the week**, **start and end times**, and the intensity level for each scheduled session.

8

SCHEDULING

Set up to **5 custom schedules** for your diffuser. You can **delete existing schedules** and **create new ones** as needed. Additionally, you can **enable** or **disable** saved schedules at any time.



THIS STEP-BY-STEP GUIDE ENSURES YOUR AROMAPLAN DIFFUSER IS OPTIMIZED FOR YOUR SPACE AND PREFERENCES!

Versatile and Adaptable

Ideal for enhancing any space, from cozy homes to bustling commercial environments.



AromaPlan

USER MANUAL

Scent Diffuser
SMART PLUG-IN WHITE | BLACK

POWERFUL, SAFE AND EASY TO USE

FC CE RoHS Model AE103-BT



Introduction

Scent Diffuser **Smart Plug-in**
WHITE / BLACK

Fill any space with a strong, even fragrance in just a few minutes.
Our diffuser is **ECONOMIC & EFFECTIVE**, with **10 intensity levels** for **small to medium-sized rooms**.


- This device is compatible with devices that support Bluetooth wireless technology and **controlled via AromaPlan's exclusive app**, allowing you to adjust intensity levels and schedule usage easily from your smartphone.
- A fresh fragrance to enhance your everyday mood.

Plug in, connect, and transform your space effortlessly!

FEATURES


-  APP control
-  Heatless & waterless atomizer technology
-  Safe for Pets & Kids
-  Easily adjust scent intensity and schedules

Parameters



SIZE	W122*D65*H214(MM)
CAPACITY	100 ML
N.W.	0.30 KG
COVERAGE	500 SQ FT
OUTPUT	5.0V - 1.0A
POWER	1.75W
INPUT	AC100V-240V 50/60HZ

Installation Method



1. Unscrew the lower cover;
2. Unscrew the oil bottle to fill or change the fragrance oils;
3. Screw the oil bottle and the lower cover;
4. Plug in the sockets.

Troubleshooting

Before requesting repairs, please attempt to diagnose the issue by following the instructions below.

ISSUE	SOLUTION
No Diffusion	1- Verify if the machine is in its "non-working period" (e.g., programmed downtime). If it is, the diffuser will not spray.
Weak Spray	1- Inspect the gasket for damage or looseness. Adjust or replace it as needed. 2- Check if the atomization core is clogged; clean it with alcohol or replace it.
Oil Leakage	1- Verify if the bottle is attached correctly.
Oil Overflow	1- Ensure the oil bottle is securely installed. Tighten it if loose. 2- Verify if the sealing ring is damaged. 3- Always keep the machine upright. Tilting or laying it flat can cause oil to overflow.

Equipment Cleaning

The diffuser needs cleaning under the following conditions:
1 - When switching to a different type of fragrance.
2 - If the atomization output decreases significantly.

- Cleaning steps:**
- 1 - Remove the atomizer head and detach the oil bottle.
 - 2 - Prepare a container large enough to submerge the bottle. Fill it with 70% to 99% isopropyl alcohol (isopropanol).
 - 3 - Allow the bottle to air-dry completely before reassembling.

Caution

(PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLING AND USING THE DIFFUSER.)

AVOID ACCIDENTS AND PROPERTY LOSS.
PLEASE ALWAYS FOLLOW THE INSTRUCTIONS.

WARNING

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, property damage and injury to person, including the following:

INSTALLING

- Use the appliance only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, property damage, or injury.
- To avoid fire or shock hazards, plug the appliance directly into a safe electrical outlet.
- DO NOT plug in with wet hands.
- DO NOT modify, disassemble, or attempt to repair the machine.
- DO NOT use the diffuser in high-temperature or high-humidity environments.
- DO NOT allow the mist outlets to face the wall directly. Install the diffuser in a ventilated and adequate space.
- NEVER place the diffuser in an area accessible to children.
- DO NOT block the air outlet while the unit is running.
- DO NOT use inflammable, explosive, corrosive, or other hazardous solvents with the diffuser.
- Suggested average daily usage time should not exceed 14 hours.
- Shut down the unit in extreme weather conditions.
- Ensure the device is securely installed to avoid it falling. It is recommended to screw the device to the wall rather than using adhesive tape.
- Keep the device upright while plugged into the outlet to prevent oil overflow and ensure optimal performance. Tilting or placing the device flat may cause damage or malfunction.



ATTENTION

This diffuser should only be used with fragrance oil without adding water. For better performance, we recommend only using AROMAPLAN's scents.

FCC WARNING:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



DOWNLOAD THE
INSTALLATION MANUAL
FOR YOUR DIFFUSER BY
SCANNING THE QR CODE

AROMAPLAN UNITED STATES
DISTRIBUTED BY FULLYSENSE LLC

CONTACT US AT:
E-mail: support@aromaplan.com
Phone: +1 (407) 233-4143

@aromaplglobal | WWW.AROMAPLAN.COM

IC WARNING

ISED Statement

English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada. L'exploitation est soumise aux deux conditions suivantes:

- (1) Cet appareil ne doit pas provoquer d'interférences.
- (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

L'appareil numérique du clem conforme canadien peut - 3 (b) / nmb - 3 (b). This device meets the exemption from the routine evaluation limits in section 6.3 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance. Cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 6.3 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

