# GROWATT

## VITA 550

User Manual



CONTACT US


CATALOGUE

| | |
|---|---|
| Important Safety Instructions | 1 |
| Package Contents | 2 |
| Getting to Know the VITA 550 | 3 |
| LED Display | 4 |
| How to Use | 5 |
| How to Recharge | 6 |
| Wallet Feature | 11 |
| How to Connect to APP | 12 |
| Technical Specification | 16 |
| FAQ | 17 |
| Error Codes | 19 |
| Troubleshooting | 19 |


## IMPORTANT SAFETY INSTRUCTIONS

WARNING: Please read the instructions carefully before you use the product.

- You must follow the usage and precautions in the User Guide when using the product. Growatt is not responsible for any damage caused by improper use or not in accordance with the User Guide.
- Read all the instructions before using the product.
- Do not put the product in the mouth of pets or children to avoid choking hazard.
- Do not attempt any heavy objects on the product.
- Do not expose the product to direct sunlight or extreme heat, and they either than the cord when disconnecting the charger.
- Please avoid liquid, fats or corrosive substances when using the product. Do not use the product after it has been damaged, such as cracks, deformation, or broken.
- Do not use any additives or substances which may cause product short circuit.
- The use of unofficial components is strictly prohibited, which may result in a risk of fire, electric shock or injury.
- Please keep the product away from heat sources, such as radiators, heaters, stoves, or other heat-generating devices. Avoid exposing the product to environments with high temperatures.
- Please only use the accessories the officially provided by Growatt.
- Please only use the charging cable provided with the product. Do not use it with other objects.
- Please only use the machine to extract official knowledge in accordance with the user manual. Growatt is not responsible for any damage caused by unauthorized or incorrect operations.
- Avoid exposing the product to water. Do not immerse the product in water or get it wet. Do not use the product in humid environments, such as bathrooms, saunas, or near swimming pools.
- Please avoid using the product in environments with strong magnetic fields, as this may affect the product's performance.
- If a power outage occurs while the product is charging, unplug it from the power source and wait for at least 5 minutes before reconnecting it. This short protection should not have the impact and damage to the product.
- Please do not disassemble or modify the product, as this may cause damage to the product and void the warranty.
- Please only use the product in a well-ventilated area to prevent overheating. Do not cover the product or place it in confined spaces.
- Avoid exposing the product to water. Do not immerse the product in water or get it wet. Do not use the product in humid environments, such as bathrooms, saunas, or near swimming pools.
- Please avoid using the product in environments with strong magnetic fields, as this may affect the product's performance.
- If a power outage occurs while the product is charging, unplug it from the power source and wait for at least 5 minutes before reconnecting it. This short protection should not have the impact and damage to the product.
- Please do not disassemble or modify the product, as this may cause damage to the product and void the warranty.
- Please only use the product in a well-ventilated area to prevent overheating. Do not cover the product or place it in confined spaces.
- Do not use the machine to extract official knowledge in accordance with the User Guide. Growatt is not responsible for any damage caused by unauthorized or incorrect operations.
- Do not use the machine to extract official knowledge in accordance with the User Guide. Growatt is not responsible for any damage caused by unauthorized or incorrect operations.
- Use recommended to use a moisture-proof bag to avoid exposing to water. If it is used, it is to be and environment.
- Please only use the product in environments with temperatures between 0°C and 45°C. Avoid exposing the product to cold, overheated, and other extreme temperatures.
- Please only use the product in environments with temperatures between 0°C and 45°C. Avoid exposing the product to cold, overheated, and other extreme temperatures.
- Do not attempt to disassemble, repair, or modify the product yourself. Any unauthorized modifications may void the warranty and could result in damage or injury.
- Do not attempt to disassemble, repair, or modify the product yourself. Any unauthorized modifications may void the warranty and could result in damage or injury.
- Please only use the product in environments with temperatures between 0°C and 45°C. Avoid exposing the product to cold, overheated, and other extreme temperatures.
- Please only use the product in environments with temperatures between 0°C and 45°C. Avoid exposing the product to cold, overheated, and other extreme temperatures.
- Please only use the product in environments with temperatures between 0°C and 45°C. Avoid exposing the product to cold, overheated, and other extreme temperatures.
- Please only use the product in environments with temperatures between 0°C and 45°C. Avoid exposing the product to cold, overheated, and other extreme temperatures.

**Storage and Transportation**

- Please store the product in a dry, well-ventilated area with temperatures between 0°C and 45°C. Avoid exposing the product to cold, overheated, and other extreme temperatures.