



MUSIC

1. TAP THE LEFT BUTTON TO LOWER VOLUME ONE NOTCH, AND THE RIGHT BUTTON TO RAISE IT. WAIT A SECOND BETWEEN EACH TAP.
2. DOUBLE-TAP EITHER BUTTON TO PLAY/PAUSE MUSIC.
3. TRIPLE-TAP THE LEFT BUTTON TO GO BACK A TRACK, AND TRIPLE-TAP THE RIGHT TO SKIP AHEAD.


TOUCH CONTROLS

CALLS

1. DOUBLE-TAP EITHER BUTTON TO ANSWER A CALL, OR HOLD IT FOR TWO SECONDS TO DECLINE.
2. TAP EITHER BUTTON TWICE TO HANG UP.
3. WHILE ON A CALL AND A CALL IS INCOMING, SHORT PRESS EITHER BUTTON TO HOLD FIRST CALL AND SWITCH TO NEW CALL, OR HOLD FOR TWO SECONDS TO HANG UP AND SWITCH OVER, OR DOUBLE-TAP TO DECLINE THE NEW CALL."

VOICE ASSISTANT

1. HOLD EITHER BUTTON FOR TWO SECONDS TO ACTIVATE THE VOICE ASSISTANT. WAIT FOR THE MIC PROMPT AND THEN SPEAK. HOLD EITHER BUTTON FOR TWO SECONDS TO CANCEL.



CHARGING

1. CONNECT THE MAGNETIC CHARGING CABLE TO BOTH ARMS.
2. A RED LIGHT WILL SHOW ON EACH ARM WHEN CHARGING.
3. CHARGE FOR TWO HOURS UNTIL LIGHTS SHUT OFF.
4. GLASSES AUTOMATICALLY TURN ON AND BEGIN PAIRING WHEN DISCONNECTED FROM CHARGER.
5. STORE GLASSES ONLY IN INCLUDED CASE. INSERT UPSIDE-DOWN WITH LENSES FACING AWAY.


TUTORIAL
VIDEO



QUICK START GUIDE

PAIRING

1. HOLD BOTH BUTTONS ON THE UNDERSIDE OF THE ARMS UNTIL YOU HEAR “POWER ON” (SKIP THIS STEP IF JUST DISCONNECTED FROM CHARGER.)
2. TAP “LUCYD LYTE” IN YOUR BLUETOOTH MENU. GLASSES WILL PAIR AUTOMATICALLY WHEN TURNED ON AFTER FIRST TIME. TOGGLE BLUETOOTH OFF AND ON AGAIN IF IT DOES NOT APPEAR.
3. PRESS EITHER BUTTON FOR 6 SECONDS TO TURN OFF GLASSES.
4. TURN OFF BLUETOOTH ON DEVICE TO PAIR TO A NEW ONE, OR IT WILL ATTEMPT TO RECONNECT.



FCC WARNING

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.