





Magic Remote Control User Manual

1. Remove the batteries from the old remote control.
2. Insert two AA batteries into the new remote control, press and hold "Home"  and "Return"  for about 5 seconds to unpair the old remote control.
3. Press the scroll wheel "OK"  button, the TV screen will show "Registering Dynamic Remote", wait for the registration to complete and then you can use it normally.

After completing the pairing operation, you can use the scroll wheel function and voice function as you like. If you encounter any problems during the pairing process, please feel free to contact us, we are very happy to answer your questions.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction