

Pursue Your Pleasure

Product Specifications:

Material:Silicone&ABS Plastic

Battery:Lithium-ion battery cells

Voltage:working voltage 3.7V,charging voltage 5V

Vibration modes:10

User time:120 minutes

Sound Level:<50db

The Egg is a gorgeous and powerful massager . The sleek and simple Bullet bud design offers a contoured shape allowing you to find your pleasure with ease. The Egg is a compact massager that lets your desire blossom and your imagination bloom

FEATURES


Press the button “” 2 seconds to turn on/off
press shortly to change the working modes.

CARE INSTRUCTIONS

- Close case securely before use
- Wash toy after each use with liquid anti-bacterial soap and water
- Pat dry with soft cotton towel and allow to air dry completely
- For maximum pleasure,use lubricant with this product

⚠️ WARNINGS

To avoid injury or aggravation of pre-existing condition, this device should not be used on swollen or inflamed area of skin lacerations. No medical claims are warranted or implied by the use of this product



The indicator light is flashing when charging the light stays on after fully charged



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment