

MYKRONOZ 
SMARTWATCH DESIGNED IN SWITZERLAND

ZeWatch³

ENGLISH

CHARGING	06	SLEEP	15
PAIRING	07	GOALS	16
DISPLAYS	11	REMINDERS	17
CALLS	12	VOICE CONTROL	18
NOTIFICATIONS	13	MUSIC	19
ACTIVITY	14	ANTI-LOST ALERT	19

OVERVIEW



To get the most accurate data we recommend wearing ZeWatch³ on your non-dominant hand and not too loose

NAVIGATE THE TOUCHSCREEN

DOUBLE TAP light up the screen

SWIPE UP OR DOWN navigate through the activity and sleep screens

LEFT button

PRESS + HOLD activate pairing mode
PRESS 1 x reject incoming call
PRESS 1 x end current call
PRESS 1 x volume -
PRESS 2 x redial last number


RIGHT button

PRESS + HOLD turn ON / OFF
PRESS 1 x light up the screen
PRESS 1 x answer incoming call
PRESS 1 x volume +
PRESS 1 x home screen / exit
PRESS 2 x activate voice control



To reset ZeWatch³ to its original settings, press and hold the **RIGHT** and **LEFT** buttons simultaneously.

1. CHARGING



Charge ZeWatch³ for two hours before your first use.

1. Gently push the clasp of your ZeWatch³
2. Plug the USB end into the USB port of a computer

Tip: To easily connect ZeWatch³ to a power source, we recommend using the USB extension cable provided

3. A battery indicator will fill to indicate charging is in progress
4. Once ZeWatch³ is charged, the battery indicator will be full



A full charge takes 1h30. When the battery level gets low, a low battery indicator will appear

2. PAIRING

The first time you use ZeWatch³, a **SET UP** message will prompt you to set up your ZeWatch³ using a mobile device or a computer.

GET ZeWatch³ APP

[iOS & Android users] Search for ZeWatch³ App on the App store or Google Play Store.

[Windows Phone users] Search for ZeWatch³ App on the Windows Phone Store.



System Requirements

iOs

iOS 7+ devices with Bluetooth 4.0 BLE
iPhone 4s, 5, 5c, 5s, 6, 6 Plus, iPad (3rd, 4th and 5th gen) iPad Mini, iPod touch (5th gen)

Android

Select Android 4.3 + devices that support Bluetooth 4.0 BLE

Windows Phone

Select Windows Phone 8.1 that support Bluetooth 4.0 BLE

Visit www.mykronoz.com to get the latest compatibility list

Step 1 : Pairing through the application (Bluetooth Low Energy - BLE)

1. Enable Bluetooth on your mobile device
2. Open **ZeWatch App** on your mobile device. **Sign up** if you are a new member or **Log in** with your existing account. After entering your personal information, select your ZeWatch model and tap **Set up**
3. Make sure ZeWatch³ is nearby and select **ZeWatch³ BLE** in the list of devices
4. You will receive a pairing request on your mobile device. Press **Pair** to accept it
5. Then, a pairing request will appear on your ZeWatch³ display. Press ZeWatch³ **LEFT** button to accept the pairing 
6. When ZeWatch³ is successfully paired, you will be notified on ZeWatch³ and on your mobile device's screen 

This operation will allow you to synchronize time, date, activity and sleep data, reminders and notifications.




You can also set up your ZeWatch³ using our Mac or PC software available on MyKronoz website: <http://www.mykronoz.com/support/>
System requirements : Windows 7,8,XP – MAC OSX 10.8 and above

Step 2 : Manual Pairing (*Bluetooth Classic*)



1. From ZeWatch³ homescreen page, hold and press the **LEFT** button until a phone icon appears



2. Go to your mobile device's Bluetooth settings and select **ZeWatch³** in the list of devices



3. A phone icon will be displayed on ZeWatch³ and a beep will sound to confirm successful pairing

This operation will allow you to make and receive calls with ZeWatch³



If pairing fails repeat the same steps. Pairing is a one-time process. If you want to pair your ZeWatch³ with another account, you first need to unpair from the current one. On ZeWatch App, go to **Settings > Set up ZeWatch³ > Unpair**. Tap **Set up ZeWatch³** to pair a new device

3. DISPLAYS

Home screen



Syncing



Upgrading



Disconnected




Pairing



Failed pairing



Incoming call



Missed Call



Redial



Voice control on



Voice control off



Memory full



ZeWatch³ will automatically sync the time and date of your paired mobile device (iOS7 + / select Android 4.3 + / select Windows Phone 8.1 + only). You can set your preferred time and date format manually in the Settings tab of ZeWatch³ App. Make sure you keep the device charged to avoid the time being reset

SMS



Day mode



Distance



2.54

Email



Sleep mode



Sleep



Social Media



Steps



1254

Goal achieved



GOAL ACHIEVED

Calendar Event



Calories



242

Low power



LOW POWER

4. CALLS

After a successful Bluetooth pairing with your phone, Bluetooth call feature is on.

ANSWER AN INCOMING CALL

Press 1 X the **RIGHT** button

DECLINE AN INCOMING CALL

Press 1 X the **LEFT** button

MUTE AN INCOMING CALL

DOUBLE TAP the screen

END CURRENT CALL

Press 1 X the **LEFT** button

REDIAL LAST NUMBER CALLED

Press 2 X the **LEFT** button

ANSWER A NEW INCOMING CALL AND PUT ON HOLD ON THE ORIGINAL CALL

Press 1 X the **RIGHT** button

HANG UP THE ORIGINAL CALL AND ANSWER A NEW INCOMING CALL

Press + hold the **RIGHT** button

REJECT AN INCOMING CALL WHILE A CALL IS IN PROGRESS

Press 1 X the **LEFT** button

ADJUST THE VOLUME DURING A CALL

DOUBLE TAP to access volume control

Press the **LEFT** button to decrease -

Press the **RIGHT** button to increase +

5. NOTIFICATIONS

ZeWatch³ shows notifications of incoming and missed calls, SMS, email, social media activity, calendar events and anti-lost alert*. Open ZeWatch³ App, tap **Settings** > **Notifications** to select the notifications you want to receive onto your ZeWatch³. If you wish to disable certain notifications, swipe the selection button to the left.

Press ZeWatch³ button to dismiss the notification. If not dismissed, the notification will reappear next time you wake up the screen.

Setting up notifications for iOS users

- Setting up notifications for iOS users
- Go to "Settings" of your iOS device
- Tap "Notifications"
- Select which type of notifications you wish to receive on ZeWatch³
- Enable "Show in Notification Center" to receive the notification on ZeWatch³



*Windows Phones may not support those features, please contact support@mykronoz.com for more information

6. ACTIVITY

ZeWatch³ tracks the number of steps taken, distance travelled and calories burned throughout the day. You can view your daily activity in-real-time on ZeWatch³ display by swiping down the touchscreen.

STEPS	DISTANCE	CALORIES
 1254	 2.54	 232

You can also view your activity data and history on the [Activity](#) tab of ZeWatch³. On the main [Activity](#) screen you can check your performance level against your daily goals. Click on any activity bar to get a detailed graph of your daily, weekly and monthly performance.



ZeWatch³ show daily data. The activity tracker resets at midnight. To upload your latest activity data do not forget to tap the sync icon in the upper right hand corner of ZeWatch app

7. SLEEP

ZeWatch³ tracks the hours slept and the quality of your sleep (light sleep, deep sleep, awake times)

■ START/ EXIT SLEEP MODE

To start sleep mode, open ZeWatch³ App, tap on the bottom purple sleep bar, click on [Add sleep > Start Sleep now](#)

To end sleep mode, open ZeWatch³ App, tap on the bottom purple sleep bar, click on [Add sleep > Awake](#)

■ PRESET SLEEP

Open ZeWatch³ App > Go to [Settings](#) > [Advanced Settings](#) > Click on [Preset sleep](#) to enter your desired bed and wake up times. By default, ZeWatch³ will track your sleep from 11pm until 7am.



To upload your latest sleep data, do not forget to tap the sync icon in the upper right hand corner of ZeWatch³ App. If you forget to activate sleep mode, you can manually add sleep logs in ZeWatch³ App. Open ZeWatch³ App, click on [Add sleep > Add sleep](#)

8. GOALS

Tap the **Goals** tab of ZeWatch³ App to set daily goals for steps taken, distance travelled, calories burned and hours slept. Click on the sync button in the upper right corner to save your goals.

Once you hit one of your daily goal, ZeWatch³ will gently vibrate and display a Goal achieved icon



i You can modify your daily goals value at any time from ZeWatch³ App. Do not forget to tap the sync icon to save your new goals. [iOS users] Press ZeWatch³ RIGHT button to light up the screen and initiate syncing

9. REMINDERS

Tap the **Reminders** tab of ZeWatch³ App to add daily life reminders. You can set up to 6 daily reminders, and choose the type of reminder and preferred time and day. ZeWatch³ will gently vibrate and display the corresponding reminder icon to alert you. Press ZeWatch³ button to dismiss the reminder. If not dismissed, the same alert will repeat after two minutes.



SPORT



SLEEP



EAT



MEDICINE



WAKE UP



REMINDER

10. VOICE CONTROL

Use the voice control feature to voice command your mobile device remotely or search information from the Internet. Double press the **RIGHT** button to initiate voice control and speak your command. Press the **RIGHT** button to disconnect voice control

Examples of what you can ask or do:

- Call (name of your contact)
- Send a SMS to (name of your contact)
- What's the weather like ?
- Set an alarm for tomorrow 5 am



This feature is available with iOS 7+ devices that support Siri, Select Android 4.3 + devices that support Google Now or S Voice, Select Windows Phone 8.1+ with Cortana. To use voice control, your mobile device must have access to the Internet using either 3/4G or Wifi

11. MUSIC

Once Bluetooth pairing has been carried out, you can stream music stored on your paired mobile device through ZeWatch³.

12. ANTI-LOST ALERT

When your paired device leaves the Bluetooth operating range (5 meters) ZeWatch³ will trigger a vibrating notification to inform you that your device is away. Press ZeWatch³ button to dismiss the alert.



The features of ZeWatch³ and the contents of the user manual are subject to change. To get the latest instructions on how to use this product, please refer to the online user manual available on www.mykronoz.com

13. TECH SPECS

Size	14,7 x 8,6 x 5,8 cm
Weight	41 gr
Bluetooth	2.1 & 4.0
Battery type	Li-ion 200 mAh
Battery life	up to 4 days
Charging time	1h30
Memory	5 days of activity
Display	Touchscreen OLED 96 * 64
Sensor	3-axis accelerometer
Operating temperature	-10°C to +60°C
Water resistance	Sweat, rain and splash resistant
International warranty	1 year



If you have any question or require assistance regarding our product, please visit www.mykronoz.com/support or email us at support@mykronoz.com

SAFETY INSTRUCTIONS

Before using the device, read these instructions carefully.

- ZeWatch³ has one built-in battery. Do not disassemble the battery on your own. KRONOZ LLC is not responsible for any damage or personnel injury caused by the removal of the battery or any component.
- This device is not waterproof so keep it away from all sources of heat or humidity. Do not use it near sink or other wet areas. Do not place it in water.
- Charge the battery in a cool, ventilated room. Excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or even explosion.
- Avoid excessive temperatures. Do not expose this device to excessive smoke, dust, or direct sunlight for an extended period of time.
- Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid contact with skin or eyes. If this happens, immediately flush the areas with water (do not rub the eye) or seek medical help.

- Do not short-circuit. Short-circuiting can occur when a metallic object, such as coins, causes direct connection of positive and negative terminals of the battery. Short-circuiting may damage the battery.
- Do not use batteries that have been damaged or have been exhausted.
- Keep the batteries out of children's reach and in a safe place to prevent danger.
- Do not dispose of batteries in fire as they may cause explosion. Dispose of used batteries in accordance with your local regulations (such as recycling). Do not dispose as household waste.
- Use only the USB cable supplied to charge this battery. Do not charge for more than 24 hours.
- KRONOZ LLC is not responsible for any damage caused by improper use of the device.

REGULATORY NOTICES

USA



FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTIONS

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC NOTICE

This equipment complies within the limits of a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against radio and TV interference in residential areas. However, even during normal operation, this equipment may cause TV or radio interference. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try one or more of the following corrective measures:

- Reposition the receiving antenna
- Increase the distance between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID:2AA7D-ZEWH3

CANADA

INDUSTRY CANADA (IC) STATEMENT

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes (1) l'appareil ne doit pas produire de brouillage; (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC:12131A-ZEWH3

EUROPEAN UNION

CE DIRECTIVE



Declaration of conformity with regard to the EU Directive 1999/5/EC.

Kronoz LLC hereby declares that this device is in compliance with the essential requirements and other relevant provisions of the R&TTE Directive 1999/5/EC. The complete declaration of conformity is available on request via our customer service: support@mykronoz.com

Déclaration de conformité à l'égard de la directive européenne 1999/5/CE.

Kronoz LLC déclare que cet appareil est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive R&TTE 1999/5/CE. La déclaration de conformité complète est disponible sur demande auprès de notre service client: support@mykronoz.com

DISPOSAL AND RECYCLING INFORMATION

After the implementation of the European Directive 2002/96/EU in the national legal system, the following applies: Electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilizing old devices, you are making an important contribution to protecting our environment.

©2015 Kronoz LLC, all rights reserved. Kronoz LLC, Route de Valavran 96, 1294 Genthod, Suisse

All brands or product names are or may be trademarks of their respective owners.

Pictures and specifications are not contractual.Les marques citées sont des marques déposées par leur fabricant respectif. Photos et caractéristiques non contractuelles.

Designed in Switzerland - Made in China



www.mykronoz.com
© 2015 KRONOZ LLC. Tous droits réservés