

Instruction Manual
Bluetooth Speaker with LED Lamp

A. Outlook Appearance :



B. Function:

1. LED Lamp, 12 bright LED, adjustable brightness / Touch panel on/off interface
2. Speaker
3. Support Bluetooth 3.0 wireless connection, also support older version, 2.0, 1.5, 1.2 and 1.1
4. Built-in rechargeable Li-ion battery

C. Operation Instruction:

1. LED Lamp:
 - Switch the power to ON position
 - Turn on the lamp by touching the button on the top of the product. Press and hold the button to adjust the brightness of the LED.
2. Connect to speaker using the audio cable
 - Switch the power to ON position
 - Plug in the audio line to the audio socket located at the

backside of the product and connect the other end to MP3 or mobile phone audio socket. Then play music from the connected MP3 or mobile phone device.

- Adjust the volume from the MP3 or mobile phone device to the suitable sound level. The volume cannot be adjusted from the product for cable connection.
- If the sound quality is bad or the volume becomes lower, please recharge the battery
- Remove the audio cable and turn off the volume when the product is not in use

3. Connect to speaker through Bluetooth

I. Add Bluetooth connection with new device

- Switch the power to ON position, blue light will flash
- Turn on the Bluetooth and search for new device from your audio device.
- After your audio device has found the default name "TS3222B" follow the instructions of your audio device to pair it to the speaker.
- For older Bluetooth version, system may request to enter password for pairing. The default password is 0000.
- Play the music from your audio device, the sound will play from the speaker.
- Slowly adjust the volume to the appropriate level. If the volume is low when it is turned to maximum level, adjust the volume control on the audio device.

Remark:

- 1) Bluetooth connection mode will off automatically if no matching after 3 minutes.
- 2) While the music is playing through Bluetooth pairing with mobile phone, the product will shift to silent mode automatically if there are an incoming phone call, the music will resume automatically when the phone call is end.

II. Bluetooth connection with same device

- Switch the power to ON position , blue light will flash
- Turn on the Bluetooth and select "TS3222B" from your audio device.
- Play the music from your audio device, the sound will play from the speaker.

D. Battery Charging:

1. Plug in the USB charging cable to the audio socket located at the backside of the product, connect the USB side to USB socket of computer, the red light will turn on. The product is fully charged when the indicator light is very dim or off. Continue to charge around 1 hour after the indicator light is very dim or off to fully charge the battery.

2. The charging time is around 2 hours if the battery is fully exhausted.

3. All power should be used up before first charge

4. If the battery is fully charged, this product can keep play music for 2-8 hours depending on the volume of the music. LED light can run approximately 4.5 hours, at the brightest level.

5. The battery can also be charged through adaptor (not included), the specification of the adaptor must be DC 5V /500ma. The battery may damage if other specification is used.

E. Precaution :

1. Turn off the power when the battery is charging. Do not play speaker while charging
2. This product is not waterproof, store and put in cool place

15.105 Class B digital device or peripheral

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

Measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.