


Instructions

Parts



Guide

- 1、Start: open the phone interface, shake the ball to wake it up.
- 2、Operation: enter the interface A, click different functions to control the ball.
- 3、Shut down: quit the software in your phone, the ball will shut down after 1 min automatically.

A Interface


- 1、Bluetooth connection: click the bluetooth connection, password:1234.
- 2、The operation interface: click the ball face in your phone, there comes out the up and down arrows. when the ball face in the phone turns left and right, the physical ball will turn left and right.
- 3、Operation of configuration: LED mode, lightness, speed and turning degree configurations.
- 4、Musical function: Scanning all the music of MP3 format in your phone, and click start, the physical ball will dance accordingly with the ball in the phone.

B APP Games

- 1.Golf simulation
- 2.Playing piano and drum.
- 3.Trackbar
- 4.Gravity Ball
- 5.Automatic Ball
- 6.Billiards simulation.

The information contained in this user manual has been sought to be accurate and complete, but if any errors or omissions will bear no any liability, and reserve the rights to change all kinds of information of this manual at any time without prior notice.

© 2014 XIAOWA Intelligent



Parameters

Max Remote distance: 10 meters (Without obstacles)
 Max speed: 0.8m/s, running track more sensitive
 Compatible devices: Android/IOS devices
 Charging time: 1.5hours
 Power requirements: 110v/240v Utility power is available
 Using time after full charged: 1hour
 Ball diameter: 61mm
 Ball weight: 70g
 Software update support: Yes
 Accessories: User manual, Warranty card, Adapter.
 Battery capacity: 240mAh
 Operating temperature: 0°C~45°C
 Storage temperature: -10°C~55°C
 Item Name: SWALLE
 Model No: XWBall-02

Precautions

- 1.If the ball moves around with only one control point, the ball will rotate on one spot when steering key is pressed.
2. By the way of focusing the light position can recognize the rotating direction since it can't be identified by the appearance for the small toy ball's sake.
3. If the steering response is too sharp, it could be duller by turning down the rotating parameter in the configuration interface.
4. Some mobiles incapable of multi-point touch function or the CPU frequency is too low, which will cause the function of moving forward or backward and the function of revolution can't be made at the same time.
5. Please do not pound and impact of the product;
6. Please do not arbitrarily disassemble this product;
7. Please do not use chemical solvents to clean this product;

Contact

Xiao Wa Intelligent Technology(Guangzhou) Co.,Ltd
 Sales Center Address: 20th Floor, Pacific Trading Building, 4028 JiaBin Road, LuoHu District, ShenZhen, China.
 Email: md@excaid.com Skype:jt.zhai
 Tel: 86-755-83285153 Fax: 86-755-82539485
 Mobile: +86-18666478948

© 2014 XIAOWA Intelligent

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Hereby, XiaoWa Intelligent Technology(Guangzhou) Co., Ltd, declares that this Radio-Frequency peripheral is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

© 2014 XIAOWA Intelligent