

WIFI PowerBank

Your mobile device partner iT-1010

User Manual



Safety

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
-

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Radiation Exposure Statement Caution: This Transmitter must be installed to provide a separation distance of at least 20 cm from all persons.

Chapter 1: Product Appearance




Brief Introduction:


- 1. USB charging Port:** Charge Mobile Phone or Tablet PC products.
- 2. USB Data Share Port:** Plug the external USB flash on this port, Mobile Phone/Tablet PC can READ/COPY/DELETE the files in USB flash through App Software "U Client".
- 3. Reset Button:** Reset System
- 4. RJ45 LAN port:** Plug on LAN cable and access to Internet automatically.
- 5. AC Plug:** Support 110-240V 50/60Hz AC current input for built-in Li battery charging
- 6. Power Button:** Press the button and no-release for several seconds, unit will be powered on. Press the button again in the same way, unit will be turned off.
- 7. Battery Indication Light:** Three Green colour LED lights for battery level indication. Lights flash during the battery charging. When battery full charged, all three indication light on.
- 8. Built-in Li battery:** 4300mAh battery capacity, can be used to fully charge two iPhone minimum.

Chapter 2: APP Software Install

- 1) Enter App Store
- 2) Search the App Software which name as "U Client"



- 3) Install App Software Uclient



Chapter 3: Wireless Router Connecting

Search the wireless hot spot which names "CodeTek", then input the default password "12345678" to connect it.



Chapter 4: USB Data Share Feature operation

1) Plug on the external USB flash onto the "DATA" USB port.
Attention: USB flash file system must be FAT32 or ExFAT system.
USB capacity 3TB maximum

2) After connect to wireless router successfully, active the App software "U Client", and it will come up the below Main Menu page



Main Menu Description:

(a) My U Drive:

It means the External USB Flash plugging on the iT-1010 now.

(b) My iPhone:

It refers to iPhone(or iPad) which wirelessly connect to iT-1010 now

(c) Setting:

Router feature setting menu

(d) About:

Show iT-1010 product version number.

3) Sub menu description

(1) My U Drive



Sub Menu Description:

(a) Video

All video format files will show under this document automatically

(b) Photo

All photo format files will show under this document automatically

(c) Music

All audio format files will show under this document automatically

(d) Document

All TEXT format files will show under this documents automatically

(e) Folder

If users want to edit the files on USB, must enter "Document" Menu



Attention:

User can click and playback the files under Video/Photo/Music/Document menu directly.

But please make sure your iPhone/iPad have the right software to decode software for these files.

iT-1010 do not have any decode system inside, it is only a wireless connecting bridge for your mobile service and external USB flash.




Edit files on USB

(a) Click "FOLDER" document at first to enter sub menu


(b) Click "disk1" document and then all the files on USB flash show out

(c) Click "Manage Files" on the right up corner



(d) Select the files which you want to edit by tick the circle on right side

(e) User can have these edit operations: "CHANGE FILE NAME" / "CREAT NEW DOCUMENT" / "COPY" / "MOVE" / "DELETE" (see remarks on left picture)



Special instruction for "COPY" feature

- When use click "COPY" button, it will switch to left side menu page automatically
- Then click "My iPhone" option, enter the sub menu as left
- Select the right document which you want to copy the file to, then click "Copy to here" on the right down corner, then the file has been copied to here successfully.



(2) My iPhone

User may copy the file from iPhone/iPad to USB flash as well.
Operation steps as below:


1) Enter My iPhone menu as below and select the certain document name which exist the file you want to copy to external USB flash.

Remark:

Normally there will exist Photo/Video files in the document names "Photo Library", because when you use iPhone/iPad camera to take photo/videos, Photo pictures or videos will be stored in "Photo Library" document automatically.



2) Click "Manage Files" and select the right file you want to copy to external USB flash



3) Click "MY U Drive", then click "Copy to here", it will be done.

