SIZE:180(W) X 280(H)mm
COLOUR: BLACK
Ver. 2.1

## 2 IN 1 WATERPROOF BLUETOOTH SPEAKER + HANDSET ❋ Bluetooth™ INSTRUCTION MANUAL

This product in waterproof construction design with quality speaker sound can enrich and upgrade your lifestyle, enjoy your favor music at anywhere at anytime. Its Bluetooth wireless system can be able to pair with your devices (such as tablets, notebooks, smartphone) easily. Also, built-in microphone can let you talk over the phone while you are in bath.

(!) **Waterproof performance:**
The waterproof level of this product complys with IP47 standards, is designed to ensure normal operation in water at a specified conditions.

Product Description:

- Hanger
- Speaker
- Function key
- Restart the track
- Pause/ play
- Play next track
- Switch speaker ⇄ handset
- DC cable in
- Volume up
- Volume down

Before using this unit:

Please ensure that the watertight cap of the DC plug is completed closed before using this unit. Trouble attribute to water seeping into the unit from to loosely closed watertight cap are not covered by the warranty.
Water droplets that enter the speaker or microphone holes do not cause troubles. However, the product performance may temporarily decrease until the water droplets are dried. Problems may include unclear sound and difficulties in getting your voice clearly. If such circumstances exist, please remove water droplets and dry the product.

Product Specifications:

Bluetooth version	Bluetooth V2.1 +EDR A2DP and AVRCP
Operating range (maximum)	10 m (The transmission distance changed depending on the environment where the product is used.
SNR speaker	4Ω 36mm
SNR handset	8Ω 30mm
Speaker impedance / Output:	4ohm / 2W
Handset impedance/ Output	8ohm / 0.25W
Power supply	Built in Li-Polymer
Battery Capacity	3.7V / 800mAh
Current consumption:	200 mA (Max)
Continuous standby time:	180 Hours
Continuous transmission time:	8 hours

#The actual continuous standby/transmission times may become shorter than those in the specifications depending on the environment or conditions for keeping/using the unit, etc.
#Batteries are consumables. The battery service time gradually decreases after the charging and discharging cycles, even if the batteries are used properly.
#The battery performance deteriorates quickly if the unit is kept under high temperature conditions. Please keep the unit in a cool, well-ventilated location, away from direct sunlight.

Operating Temperature:	0 °C to – 40 °C
Operating humidity range:	20-80% (no condensation)
Product size:	65(W) x 151(H) x 40(D)mm
Weight:	138g
Waterproof performance:	IP47
Number of devices that can be registered	8

Charging the battery:
- Charging the battery from your PC via the USB charging cable included in the package.
- The LED lamp is lit red while the battery is charged.
- The LED lamp is lit green when the battery is fully charged.
- It takes around 1.5 hour to fully charge the battery
1. Connect the USB charging cable to the unit
2. Connet the USB charging cable to your PC
* when he battery power is used up, a beeping alarm will sound, with the LED lamp blinking red. After a while, product will turn off

Pairing the product with your device:

1. To turn on the product, hold ☊ON/OFF for 7 second, a signal will sound 'beep~' with red light and then sound 'popo' light is flashing, means it is ready to be paired.
2. At this first time to pair, use your device to search the product model "#Bluetooth-phone#".
3. When your device search the product model, press to connect, your device will show if it is successfully connected or not.
4. If it is successfully connected, you can play music through the product.
Noted: Terminate any connection between the product and any device before starting the paring procedure.
The pairing procedure cannot be started while a Bluetooth connection is established between the product and a registered device.
Terminate the connection and turn off the product.

Up to eight Bluetooth device can be registered:
When nine or more devices are registered, the previously registered devices will be deleted starting from the oldest, to register new ones. A device that is registered twice or more is identified as one device.

Play music:
Press Vol + to increase the volume. (when up to maximum, it will have 'Beep~' sound)
Press – Vol to decrease the volume. (when up to minimum, it will have 'Beep ~' sound)
Press ⏮ to restart the current track. Press twice to play previous track.
Press ⏭ to play next track.
Press ⏯ to pause/ play the track.

Press ☊
1. when it is lit green LED, sound source play via handset
2. when it is lit off, sound source play via speaker

Hold ☊ON/OFF for 7 seconds to turn off connection of Bluetooth

Part 1: pick up call
1. For incoming call, press ☊ON/OFF to pick up the call, you will hear sound via speaker
2. Press ☊ (with green LED on), you can hear the sound via handset. Press ☊ (with green LED light off) to switch the sound source to speaker
3. Whenever you are hearing sound source via speaker or handset, you can press Vol + or – Vol to adjust the sound source volume.
4. Press ⏯ once to have mute function, press ⏯ once again back to normal.
5. After finish the conversation, please ☊ON/OFF to hang up.

**Note: To avoid / reduce echo, please do not turn the speaker to maximum voume.
** The blue light will be blinking for all incoming call.
** The blue light will be blinking when talking via speaker
** The green light button will lit up when talking via handset

Part 2: Make a call
1. Hold ☊ for 2 seconds to redial the latest call you make.
2. Some smartphones have voice command, press ☊ once to enter voice command function with your smartphone. For detail, please refer your smartphone instruction. This performance is different depending on your smartphone setting.
3. After finish the conversation, press ☊ON/OFF to hang up.

Part 3: Pick up another incoming call
1. While you are talking over the phone with another incoming call, press ☊ON/OFF twice to pick up incoming call.
2. Press twice ☊ON/OFF to switch to another party.
3. Press once ☊ON/OFF to hang up the phone.

Part 4 reject incoming call:
1. While it is ringing with incoming call, hold ⏯ to reject the call.
2. If you are playing the song, press ⏯ once again to continuously playing the song.

Speaker & handset sound source switching:
Press ☊ (with green LED on), you can hear the sound via handset.
Press ☊ (with green LED light off) to hear the sound via speaker.

Initializing the registration history / resetting the hardware of product:
Under the Off mode, hold ☊ON/OFF & Vol + together until it sound a signal with red light.

Caution
- **Please take full precautions when setting the ringtone volume.**
When this product is paired with a mobile phone, a loud ringtone may give you a shock, which in turn may result in an accident or a heart attack. Gradually increase the volume from the minimum to set it appropriately.
- **Do not damage cables that are connected to this product.**
Fire and disconnection will result.
- **Never leave this product in a car.**
Leaving this product in a hot car cabin for many hours will result in rupture of the built-in battery, sparking, and other troubles, posing significant danger.
- **Do not leave this product under high temperature conditions.**
This product is a precision electronic device. Avoid using/keeping this product in a location that is subject to high temperature, high humidity or direct sunlight for many hours. When subject to significant temperature changes in the environment, this product may malfunction due to condensation inside the product.
- **Do not touch the metal parts of this product such as the power supply connectors and the charging cable's connector terminals.**
Static electricity or fouling may cause a malfunction or electric shock.
- **Do not disassemble this product.**
Do not repair, modify or disassemble this product on your own, unless operational instructions to the contrary are given in this user's manual. Electric shock, fire, or burns may result.
- **Make sure to close the watertight cap when using this product in a wet or damp environment. Make sure to remove any dust, hair, etc., that is present between the watertight cap and the main unit.**
- **Follow the user's manual instructions of devices (ex. iPhones and mobile phones) to be connected to this product.**
This product can be wirelessly connected to iPhones, mobile phones, etc. The setting procedures and precautions are different depending on the devices to be connected to this product. Carefully read the user's manual for these devices and observe any precautions.
- **Do not use/keep this product in a wet or damp environment for a long time if you do not use it.**
Any liquid entering this product may result in troubles, fire, or electric shock.
- **Do not keep this product within reach of small children.**
Unexpected accidents (ex. accidental ingestion) may result.
- **This product is a precision electronic device. Avoid using/keeping this product in an environment that is subject to impact/vibration, strong magnetic forces, static electricity, etc.**
- **Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.**

FCC Requirement

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

DISPOSAL ONLY
THROUGH APPROVED
OUTLETS !