

2.4G DIGITAL





VS TANK
2.4G

1/24 RC BATTLE TANK

CONTENTS

Airsoft		Infrared	
Transmitter & Tank	P2	Transmitter & Tank	P2
Caution	P3 P4	Caution	P3 P4
Quick Start	P5 - P8	Quick Start	P5 - P8
Functions	P9 - P10	Functions	P9 - P10
Battle	P11	Battle	P12
Changing Parts	P13	Changing Parts	P13
Warning	P14	Warning	P14

TRANSMITTER & TANK





Please read through the following cautions before using



Caution for the VsTank Pro Airsoft and Infrared series



This RC (remote controlled) battle tank is not a toy but a tank model controlled with radio signals. Please use carefully to avoid injury.

⚠ Caution: Do not shoot at people or animals.

To avoid injury, never aim the gun at or shoot at people or animals. Otherwise, you may possibly injure them.

⚠ Caution: Never look into the gun muzzle.

To protect your eyes, never look into the gun muzzle. Be aware that the gun might fire accidentally when the radio signal is weak or disrupted.

⚠ Caution: Do not operate the tank on roads.

Do not operate on road as that may cause traffic accidents. Also, do not operate on water, sand, or carpet, as these can cause the tank to damage.

⚠ Caution: Keep small parts away from small children.

Do not give small parts or plastic bags to children. They might be swallowed and cause choking.

⚠ Caution: Do not put your finger into the wheels or the crawler.

Do not put your finger into the wheels or the crawler. Touching the wheels or crawler when holding the tank could also lead to malfunction and injury.

⚠ Caution: Make sure the batteries are correctly install / remove to avoid burn. Turn off the tank and/or transmitter before inserting or removing batteries.

Alkaline batteries should be used carefully. Batteries that are identical or recommended can only be used. Different types of batteries, new and used batteries are not to be mixed and used. Do not charge any non-rechargeable batteries. Rechargeable batteries can only be used under parental guidance. Before charging, the rechargeable batteries should be removed from the toy.

Install the batteries with the polarities in the correct direction. The supplied terminals are not to be short-circuited. Otherwise, the battery may rupture and leak, causing danger of burns.

Consumed batteries are recommended to be removed from the toy.

Also if batteries are inserted or extracted while the transmitter or tank is turned on, it might not operate correctly.

⚠ Caution: What to do if the tank has lost control.

If the tank has lost control, or is not operating correctly, turn off the tank and the transmitter, repeat the pairing steps and connect the tank again. Also, low battery may affect the performance and functionality of the tanks.

Please keep this instruction manual as a reference



Caution for the VsTank Pro Airsoft series



⚠ Caution: Please wear goggles while playing.

All people nearby should have safety goggles on when the tank is shooting. Bullets may rebound when they hit the wall or the ground. Make sure you don't shoot when someone is passing by.

⚠ Caution: Set the shooting switch to OFF after use.

Set the main switch to OFF after playing

1. Set the shooting switch to OFF

2. Insert the protective cap into the gun muzzle

3. Remove the BB bullets by turning the tank upside down and pouring the bullets out

4. Remove the batteries (otherwise the batteries may discharge by themselves and cause leakage)

⚠ Caution: Be careful with the bullet hatch and the gun muzzle.

Bullets other than the specified BB bullets may cause blockage and join the shooting mechanism. Do not put different bullets or any other articles into the bullet hatch or the gun muzzle.

⚠ Caution: The company will not be responsible for any injury or accident caused by the misuse, alteration or disassembly of this product by the user. Products that have been altered or disassembled by the user will not be repaired.

• If you lose the operating instructions, please contact this company to request for another copy.

• Never try to disassemble or alter the product to avoid malfunction or danger.

• Because malfunction may be caused when the tank or radio controller is immersed in water or got wet, stop using them immediately if this occurs and remove all batteries. Contact our after-sales service center for further assistance.

• Do not expose the tank or the radio controller to strong sunlight. Otherwise, they may be deformed gradually and fail to function as expected.

QUICK START


5

1 INSTALLING THE BATTERY

Warning

Regular examination of transformer or battery charger for any damage to their cord, plug, enclosure and other parts, and that, in the event of such damage, toy must not be used with the transformer or battery charger until such damage has been repaired.


- 1 To install/ replace batteries on the transmitter, please unscrew the battery flap from the transmitter.



- 2 Please insert the AA batteries to the correct polarities.



- 3 Please screw the battery flap into the transmitter.



- 1 Pull out the button and remove the battery flap.



- 3 Pull out the button and fit the battery flap back to the battery box.



Install / Replace Batteries

- Non-rechargeable batteries are not to be recharged
- Different types of batteries or new and used batteries are not to be mixed
- Exhausted batteries are to be removed from the toy
- The supply terminals are not to be short-circuited

2 BEFORE PLAYING



The shooting switch (safety device) is normally kept OFF. Move the switch to ON only when you plan to use the airsoft BB bullet function. You can insert 6mm airsoft BB bullets into the hatch as shown in the picture on the left.



* Type 90 and King Tiger, turn the receiver in reverse direction as indicated.

PAIRING

1 Switch On the Transmitter



2 Press the Connect Button




3 Switch On the Tank

M1A2 ABRAMS / LEOPARD 2 /
TYPE 90 / T-72 M1 / TIGER 1



KV-1 / Pz753(r) / KV-2 / Pz754(r) /
M4A3 SHERMAN / KING TIGER



Volume control-mute, moderate, and loud



Please wait 10-20 seconds during connection, the Blue light will stop flashing after the Tank and Transmitter are paired.

CONNECTION



- If you play with 1 or more tank. Please connect the tank one by one, NOT at the same time.

- If you found the transmitter connected the wrong tank, please switch off both Transmitter and Tank. Then, follow the "Pairing" procedure and try again.

- The VTX-24 transmitter can connect ALL VsTank 2.4G models, it is NOT specific assigned to certain model.



The VsTank bottom with the [VRX-24] sticker can connect with the VTX-24 Transmitter

NO. OF PLAYER



Allow up to 16 players play together at the same game.

DISTANCE



outdoor 40-50m

indoor 25-30m




FUNCTIONS

9

MOVEMENT


The tank offers proportional speeds

Forward





STEERING & ROTATION

Turn Left



Turn Right



To center-rotate the tank, move the joy-stick either left or right. The tank also supports proportional turning and center-rotation by moving the stick with different angle.

HOLDING MANNER



To operate the VsTank effectively and properly, please hold the transmitter as above holding manner.

TURRET

Turret Left / Right

You may press the furthes/ shoulder buttons to turn the turret left / right. Your tank turret can rotate over 300 degrees.



Muzzle Up / Down



The muzzle will exercise up / down movement



10

BATTLE



Changing The Treads


In the event that the treads get loose, do not attempt to force movement or breakage will result. Please correctly reassemble the treads properly before operating again. VsTank Pro also offers hard plastic treads in place of rubber treads.

M1A2 ABRAMS / LEOPARD 2 / TYPE 90 / T-72M1 / KV-1 / Pz753(r) / KV-2 / Pz754(r) / M4A3 SHERMAN / KING TIGER



Long Tread

Short Tread




First you need to combine both treads into a longer treads for the tank. Turn the tank around, and insert the treads as shown in the picture on the left.

Pull two ends of the tread together and then insert the coupling pin as shown. If you are removing the tread, you will need to remove the pin first as well. Please do not use any sharp objects to remove the pin.



*For M4 Sherman and King Tiger treads, connect each segments by inserting the pin as above.

TIGER I



Please be careful with the teeth of the treads. They should be inside the rear wheel and not outside.



Please note that the side with holes on it should face the outside when you are inserting the tread into the tank.

Clip both ends of the tread together and the Tiger I should run well. Check for any loose connections before playing.

Please read the following notice as it contains important information

Warning: Changes or modifications made to this unit without express approval form by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.


However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user may try to correct the interference via one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Repair services required for the following reasons will not be covered by the quality guarantee:

1. Accidental fall or strong bumps, which leads to tank or transmitter damages.
2. The tank or transmitter is wet when running in wet places, which leads to malfunctions or breaks.
3. The tank runs in a place with too much sand, mud, dirt, or on any surface which leads to malfunctions or breaks.
4. Other malfunctions due to violation of warnings or cautions described in this manual.
5. Malfunctions due to misuses (reverse battery connections, wet parts, bumps etc).
6. Malfunctions due to improper assembly or restructuring or use of unspecified parts.
7. Malfunctions caused during moving or by falls or poor storage condition.
8. Malfunctions caused by the use of unspecified batteries. Chassis or motor damages caused by running over places with excessive resistance.
9. The manufacturer does not offer repair services for commodities restructured or disassembled by the user.
10. Other malfunctions or breaks not within the range of our quality guarantee.
11. If you do not intend to use the tank for a few days, set the main switch to "OFF" and remove the batteries.

► **Modifications not authorized by the manufacturer may void the user's authority to operate this device.**





Join [Free register at:](http://www.vstank.com/vsclub/register.asp)
<http://www.vstank.com/vsclub/register.asp>

JOIN VsClub for Free:
To buy the spare parts with worldwide free ship service
To receive the latest news of VsTank
To buy the Exclusive VsClub Limited Edition Item

Join our Facebook page:
<http://www.facebook.com/MyVsTank>

Beginner Intermediate Professional

CE !

This RC model is suitable for people who are 14 years of age and older. This is not a toy!
Contact Us By info@Vstank.com

POWERED BY: www.VSTANK.COM