


Start here				
<p>Following items are included</p>  <p>Ear hooks</p> <p>Ear cushions</p> <p>USB cable</p>	Product overview	Basic operation	Pairing	Call

Music	More features			
<p>Switch between the earphone and phone Press the Volume "+" for about 2 seconds during a call, the call will be switched to the mobile phone, redo this operation again, the call will be switched to the earphone.</p> <p>End current call and answer new call When a new call rings during a call, hold the Multifunction button once to answer new call and end current call simultaneously.</p> <p>On hold current call and answer new call When a new call rings during a music playing, the music automatically pauses to allow you to answer or ignore the call. Once the call is ignored or ends, the music is resumed.</p>	<p>Battery Indicator (Need media player support)</p> <p>Music play / pause Press Multifunction button once to play / pause music. (Some phones may require you to start a media player first)</p> <p>Track back/forward Press the Volume "+" for 2 seconds once to skip track forward, press Volume "-" for 2 seconds once to skip track backward.</p> <p>Switch Music and Call When a call rings during a music playing, the music automatically pauses to allow you to answer or ignore the call. Once the call is ignored or ends, the music is resumed.</p>	<p>Auto power-off When the earphone is connected to a device with iOS system, a battery indicator will appear at the upper right of the system, indicating battery status of the earphone.</p>  <p>Effective range 10m</p>	<p>Automatic connection after powering on When the distance between the earphone and the mobile phone is beyond effective range, a voice prompt "Connection lost" and earphone disconnects with the mobile phone, the earphone will power off automatically once no active for 10 minutes.</p> <p>Connection standby After successful pairing and connection, you will hear the voice prompt "Connection successful", the earphone will be in pairing mode or standby mode automatically and the blue LED will flash once every 5 seconds, when the earphone disconnect the phone, you will hear the voice prompt "Connection lost".</p> <p>Hard reset In turning on mode, press and hold the Multifunction button with the charger plugged to reset the earphone and power off you can release the Multifunction button 2 seconds after mounting the charger.</p>	<p>cannice</p> <p>Bluetooth headset</p> <p>FCC ID:2AAIH-MS04</p> <p>Muses 4 INSTRUCTION</p>

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference
that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance
could void the user's authority to operate the equipment.