

User Manual

E201

V1.0

Because the product version to upgrade or other reasons, the document content will not regular updates. Our company reserves in do not make any prior notice in this manual revision content of rights

1. Insert the SIM card and battery.

Pay attention to the SIM card chip contacts must be correct, SIM card slot to be identical with the outline.

2. Battery Charging

- The phones and charger connection.
- Will the power plug into the charger power socket.
- Cellular phone to start charging, the screen will show power icon scrolling effect.
- Power ICONS no longer scroll that charge is full already, please disconnect with the connection of the cell phone charger.

3. Keypad Description

1. **Up / Down Navigation Keys:** scroll through the names, telephone numbers, SMS, MMS and the sub-menu options; editing to move the cursor up and down; in the menu mode, scroll up and down options to choose.
2. **Left / Right Navigation Keys:** move the cursor around editing; in the menu mode, scroll around selection options.
3. **SIM2 dial key:** Call the phone number and answer a call; standby mode, SIM card out of a list of call _records.
4. **Right Soft key:** implementation guide at the bottom right corner of the screen display.
5. **Dial-up key:** Call the phone number and answer a call; standby mode, SIM card out of a list of call _records.
6. **Red Key:** press the red key to reject a call, end active call; also, it's the power key.
7. **Numeric Keys:** 0-9 number keys to enter numbers and characters; Long press the number key 1, you can into the voice mail of SIM1, SIM2. When the function of speed dial is open, long press the number keys 2-9 to set aside pre-set speed dial numbers.
8. *** Key:** Different status or menus with different functions.
9. **# Key:** Different status or menus with different functions.
10. **Middle Key:** implementation guide at the bottom center of the screen display.

Note: In this manual, "press the key" refers to press the button then release; "long press the key" refers to pressing the key and keeping 2 seconds or more than two seconds; 1,2 collectively referred to as navigation keys.

4. Keypad lock

In order to prevent the misoperation, you can lock the keypad. If the keypad be locked, you can press the dial key to answer a call, or dial the SOS number.

If you want to deblocking the key, Press the right soft key first, then press “#” key.

5. Call function

Making a call

- In idle mode, press the number key to input number. If you want to dial international number, long press key 0 to input “+”, then input the nation or area code, zone description, phone number. If you want to call a extension number, long press the key 0, then short press the key 0 once or twice to input “p” or “w”
- Press the Dial-up key, outdoing call.
- Press the Red Key to end call or cancel a call.

Receiving a call

- When a call coming, press the dial-up key answer. Press the red button, hang up the call.

6. Information

- In idle screen, choose Menu/Message/Write message.
- Input information, choose send.
- Edit the recipients.
- Press “sends” to send the message.

7. Input method

Editing screen, press the * key to input punctuation, the # key switch input method mode.

- **En**
In the ‘En’ input mode, according to the need of the English words. Press the corresponding key once, mobile phone will be combined from the corresponding words. At the same time, also with the other letter combinations, choose the words you need.
- **Abc**
In the ‘Abc’ input mode, press the number keys to input single English letters. Click once, can input the first letter on this key; Click twice, can input the second letter on this key, which in turn on. If the input of letters and a letter before in the same key, please wait for the cursor appear again, before the confirmation letter already input, then enter a letter after.
- **123**
In the ‘123’ input method, press the number keys to directly enter Numbers.
In the ‘Abc’ input mode, Press the corresponding digital key continuously, until all required number appearing on the screen can.
In the ‘En’ input method, press the corresponding key, when the number appearing in the

candidate area, chooses the words you need.

- **Input** punctuation

In any input method, press the * key to into the character list interface, chooses the character you need.

8. Recorder

- In idle screen, choose Menu/Multimedia/Recorder.
- Press the ok key to activate recorder.
- Press the stop key to stop recording, the record be saved in Menu/File management /Phone/Audio.

9. FM radio

Please plug in headphone, press “*”, “#” key to adjust the volume, the left or right navigation key to search the channel manually.

You can do other operation via option menu.

Note: This function is subject to the configuration of the mobile phone.

11. Bluetooth

- In idle screen, choose Menu/Extras/ Bluetooth. You can set up the Bluetooth in this menu.

Note: This function is subject to the configuration of the mobile phone.

12. Camera

- In idle screen, choose Menu/Multimedia/Camera to go to preview screen.
- Press the ok key to capture; you can do other operation via option menu.

13. Video recorder

- In idle screen, choose Menu/Multimedia/Video recorder to go to preview screen.
- Press the ok key to record; you can do other operation via option menu.

14. Services

This phone has wireless Internet function, make you and the whole world at all times maintain a more closely linked, for you to visit the Internet offers a more convenient.

15. File management

This phone can be all kinds of media resources for rapid access and use. Standby mode, select Menu/File management/ Phone into the file management interface, its support the following main function.

- Establish the default folder structure tree, these folder is related to the default storage location other applications (such as Audio, Photos, video, etc.);
- Support build new file folder;
- Support essential file operation, ex copy, delete, rename;
- Support operation to T-flash , format, edit etc. After being formatted ,it will generate a file named “Audio” to store the music and “Video” to store the video.
- Support preview and editor of the images.

16. Safety

This phone support many safety management function, can guarantee you information safety.

- Power-on password: you should input the correct password after power on. Otherwise, you cannot use the phone.
- PIN code: use PIN code to protect the phone safety. Once the PIN code is on, you should input the correct PIN code when power on.
- Auto keypad lock: set the time of auto keypad lock.

17. Warning

Before use this mobile phone, please read and compliance the following matters, in order to avoid dangerous or illegal conditions, and guarantee this equipment be best.

- **Armamentarium**

Make use of any wireless equipment, including honeycomb phone, may disturb armamentarium. Any case, please query the doctor or manufacture.

- **Hearing protection**

When listening music or making a dialing, please use the minimum volume to avoid hurting hearing

- **Flammable and combustible area**

Be sure to remember, you should abide by the special rules and regulations, in the place prohibition of use the phone, you should power off the phone.

In any place (ex gas station, chemical plant), if using the phone may arouse blast, please power off.

- **Traffic safety**

Please do not hold the phone while driving cars, and abide by the area or nation rules.

Please do not put the phone above the air bags or the area that the air bags can be reached if is expansion, because the phone may do harm to your body if is get a strong push.

Phone may disturb the airplane flight system, please abide by the rules of the airlines, please power off if you are in the area that the wireless equipment be forbidden to use.

- **Operating environment**

Keep the phone dry, liquid may corrode the metallic circuit.

Keep the phone far away high temperature, high temperature can shorten the life of electronic instrument, melt the plastic and damage the battery.

Please don't unpack the machine, nonprofessional dismantle may damage the phone.

Don't use strong acid or strong alkaline cleanser to clean the phone.

Please use the original accessories, go against the rules may result in warranty lose efficacy.

- **Children's health**

This phone and accessories may contains some little parts, please lay up the phone to the place that the children can't reach. Children may not be inclined to damage the phone or accessories, or to ingurgitation them, it is too dangerous.

- **Environmental protection**

Please abide by the local laws and degrees about the equipment, battery and accessories. Please don't take them as common house refuse.

- **Original accessories**

Only once use the original accessories. If the use of any original spare, may influence the use of equipment performance, It was a violation of this equipment warranty terms about the communications and the state of end products and relevant regulations, and even cause bodily harm..

- **Battery power and battery charger**

When the phone charging completes or not in charging, please disconnects the equipment from the connection of the charger and pulled out the charger from the socket.

Please don't butt joint the two poles of battery or contact the end point of the battery by metal object, in order to avoid the short circuit of battery, and avoid the damage by overheating of the battery.

Please don't put the battery or equipment around the heating equipment, such as the microwave oven, oven, heat sink etc. The overheating battery may cause explode.

Do not disassemble or modified battery, lest cause the battery leak, overheating, fire or blowout.

If the battery have seepage, please don't be exposed the skin or eye to battery seepage; if it is on, please wash quickly and go to the hospital to do Medical Treatment.

If the battery has the abnormal occurrence such as change color, transformation, abnormal heating and etc, please disuse it and renewal the battery.

If the power line is damaged, please don't use it, in order to avoid electric shock or fire hazard.

Don't take the battery into the fire, and it could lead to the battery fire and blowout.

- **Service and maintenance**

Please keep the equipment and accessories dry. Please don't use the microwave and other heating equipments to dry them.

Please don't let the equipment and accessories suffer strong push or shake, in order to avoid the damage of the equipment and accessories, or avoid the combustion or explosion of battery.

Please don't put the equipment and accessories at the area with over temperature or too low temperature, otherwise, the equipment, battery and charger may get breakdown, get fired, or get explosion. When the temperature is under zero centigrade, the performance of the battery is under restrictions.

Please don't put the metal items such as pin and other poignant items around the phone receiver, the phone may be able to grip them and do damage to you body.

Please don't use the violent chemical products, cleaning agent or strong detergent to clean equipment or accessories. Please power off before clean them, and disconnect the connection of the charger and equipment.

Please don't take down the equipment and accessories, otherwise the warranty will lose efficacy.

Emergency

In an emergency situation, when the mobile phone power on and be in service, you can use equipment for emergency calls. Because can't guarantee all cases network can link, therefore, in an emergency situation, do not use this device as the only way to contact.

For users don't comply with the above Suggestions or incorrect use of mobile phone of the consequences of, manufacturer disclaim all responsibility.

Electronic information products poisonous and harmful material statements

Parts	Poisonous and harmful substances or elements					
	Pb	Hg	Cd	Cr ⁶⁺	PBB	PBDE
Phone	X	0	0	0	0	0
Battery	X	0	0	0	0	0
Accessories	X	0	0	0	0	0

0 said the poisonous and harmful material in the part of all homogeneous material content are in SJ/T 11363-2006 standard requirement of set limit to the following.

X said the poisonous and harmful material in the parts of at least a homogeneous materials beyond the content SJ/T 11363-2006 standard requirement prescribed limits.

Note: this product is labeled "X" reason is not available at this stage of the alternative technology or components.

Note: if this manual involves version to upgrade, without notice. The company has the final explanation to the user guide.

FCC Caution.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

This **GSM Mobile Phone** meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: **E201 (FCC ID: 2AAK9FORMEE201)** has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the **ear is 0.68W/kg** and when properly worn on the **body is 0.76W/kg**. This device was tested for typical body-worn operations with the back of the handset kept **1.5cm** from the body.

To maintain compliance with FCC RF exposure requirements, use accessories that maintain a **1.5cm** separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of **1.5 cm** must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.