

User Manual

- 1,When using,connect the audio cable provided to your external device.(flg.1)
- 2,Switch on the mini speaker using the on/off button located underneath the speaker.(flg.2)
- 3,LED light will turn red once the speaker is switched on.(flg.3)
- 4,Enjoy up to 6 hours of playing time;For charging,use the USB cable provided and charge with computer.
- 5,Use your external device to change volume,song choice etc.

Note:

- Ensure that your mini speaker is switched off when charging.
- To fully maximize the battery life,use up the battery fully before re-charging and charge the speaker fully before playing.



Fig. 1




Fig. 2



Fig. 3

FCC ID: 2AALE62132

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.