



Polaroid



smart watch | B502

User Manual

Congratulations on your new ownership of a Polaroid smart watch. Please read the manual carefully for full understanding of all operations and functions of your new smart watch.


It is able to be monitor your sport data and heart rate. It is manufactured for your personal, professional and active lifestyle.

1 What's Included

The following components are included with your purchased product:

- Polaroid smart watch
- USB Cable & Charging Dock
- Instruction Manual
- Quick Start Guide
- App Guide
- Warranty Card

2 Appearance and buttons



3 Battery Charging

The Polaroid smart watch is equipped with a built-in rechargeable Li-ion battery. It is suggested to fully charge the battery before use.

Charging Process:

- Connect one end of the USB cable with PC or power adapter, and then connect the other end of USB cable with your smart watch's charging dock, put the smart watch on charging dock and make sure the charging points on watch fully contact the charging points on the charging dock.

Warning: power adapter requirements: output current must be within 0.1A, using power adapter with other specs may damage the watch.

4 Turn ON/OFF Smart Watch

1. Turn On: for the first time, please press and hold the touch key for 3 seconds to turn it on. You can also charge the watch to turn it on.
2. Turn Off: when the watch is ON, press and hold the touch key for around 3 seconds and use the touch key to select  icon and wait around 2 seconds to turn off the watch.

3. Sleep mode: your smart watch will automatically go into sleep mode when the smart watch is left in idle after a certain period of time. To wake up the smart watch from sleep mode, just briefly tap the touch key to wake it up.

Remarks:

- When the battery power has been used up, the watch will automatically shut down.

5 Touch Operations


Tap: quick tap the touch key to go to next page. Press and hold the touch key for 3 seconds, then select the exercise icon and wait for around 2 seconds to enter exercise mode. Press and hold the touch key again to exit exercise mode.

6 Smart Watch Functions

Normal mode:

After turning on the watch, it will display the time, step, heart rate, distance, calorie count, music control and find phone.

Remarks: Please note the music control and find phone functions are defaulted as off. When you turn on the music control and find phone functions in App, these two functions will display on watch.



Exercise mode:

Press and hold the touch key for 3 seconds, then tap the touch key again to select the exercise icon and wait around 2 seconds to enter exercise mode. Tap the touch key to check your exercise time, heart rate, step, distance and calorie count.



7 Downloading App

Scan below QR code or search “Purifit” from Apple store / Google Play Store. After installing the app on your smartphone, you can sync your activity data to your smartphone and change settings from the App.



For Android phone, after installing the App on your smartphone, please go to "settings" → "accessibility", please tap on "Purifit" to make sure it is ON.


Smartphone Operation System Requirements:

Android 4.4 or above

iOS 8.0 or above

How to pair the watch with your smartphone?

1. Please download the Purifit App and install it on your smartphone.
2. Turn on smartphone's Bluetooth function.
3. Register yourself on the App and you will be led to the App's home page after registration, tap on the below highlighted area to link your watch. Search for the device and select your watch "B502" to connect, at the same time, tap the watch touch key to confirm and complete connection.



8 Common Troubleshooting

If you experience any problems when using the watch, please see the below solutions. If the problems still exist, please contact your local distributor or appointed repair centers for more assistance. The Toll free number can be found on the last page of the warranty.

8.1 Bluetooth disconnects easily or connection failed?

Please ensure that app is running in the background for Android, it is recommended that your app is added to the protected background applications. If you are still unable get the Bluetooth connected, please shut down and close the app from the background of your phone and then restart it again.

8.2 The watch can't be found by the smartphone?

Please put the phone near the watch before searching for the connection. If your phone still can not find the watch, close the Purifit app, and then restart it again. Or turn off your mobile phone's Bluetooth, and turn it on again to connect it again.

8.3 I do not receive a message reminder from the binding.

Please ensure the messages are added to the status bar of the phone, and keep the Purifit app running in the background for Android users.

For more info, please run Purifit -- More -- Help.

9 Important maintenance precautions

In order to keep your Polaroid smart watch in good maintenance, always follow the below basic precautions:

- Keep it a safe distance from any strong magnetic field.
- Keep it away from water.
- Keep it and its accessories away from children.
- Prevent the device from falling or impact during usage, as this may cause damage to the smart watch.
- Do not use the device in an extremely humid environment, because moisture penetrates inside and may damage the smart watch without the possibility of repair.
- Do not clean your smart watch using harsh chemicals, detergents and chemicals that can and may dissolve the plastic.
- Do not place other objects on LCD screen, as it may crush and damage the LCD screen.
- Do not use any sharp objects to touch the LCD screen, as this will scratch the screen.
- Do not attempt to dismantle the smart watch by yourself to do any repair, this will damage the smart watch and void the warranty.
- Do not use the watch while driving! Keep your eyes focused on the road.
- Please turn off the watch in aircraft and follow any restrictions. Wireless devices can cause interference in aircraft.

10 Battery Management

The battery is not fully charged from factory, so it is recommended that you charge the battery for at least 1 hour before you start to use the device.

The rechargeable battery is designed and manufactured to be used and recharged frequently. As with all lithium batteries, the capacity of the battery reduces each time it is charged. However, you can still try to prolong the battery's lifetime by following the suggestions below:

- Use your Polaroid smart watch at least once a week.
- Fully charge the battery regularly.
- Never leave the battery fully discharged for a long period of time.
- Always keep the device and the battery away from heat and moisture.

11 Regulatory Information

FCC Notice

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment . This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.