

VDT1300 Label Location



3 - Top view of enclosure



1 - Enclosure opened to access power and to mount backplate (necessary for installation & use)



2 - Close-up of backplate and label location. User must separate backplate and expose label to access power and install device.