

# REMOTE CONTROL INSTRUCTIONS:

---




## Tech Spec:

1. Model Name: ZY16-12
2. Operating voltage: DC12V (12V/23A battery, shown as picture above)
3. Operating frequency: 433.92MHz
4. Frequency deviation:  $\pm 0.2\text{MHz}$

## How to use:

1. The 1-12 buttons are all for the on/off power switch for the lights, one channel is for one light, total could control 12 lights on/off. Press button 1 one time, the light on, press button 1 again, the light off.
2. Press one button, the remote control will transmitter a rf signal.
3. The remote control could not work in a sealed metal box.
4. When there is strong interference, you could pull straight the antenna of the remote control to reach better function.



**If the remote control does not work, check whether the battery of the remote control is out of power.**

**To replace the remote control battery:**

1. Open the back cover of the remote control.
2. Replace with a new alkaline "12V 23A" (12 volt) battery (included) into the compartment.

**WARNING:**

- A. This is not a toy and is not intended for use by children.
- B. Do not dispose of the battery in fire as the battery may leak and explode.
- C. Do not mix old and new batteries and do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- D. Exhausted batteries are to be removed from the product.
- E. Use type "12V 23A" (12 volt) batteries.
- F. Safe for indoor use.
- G. For this device, A transmitter activated automatically shall cease transmission within 5 seconds after activation.

**FCC warning:**

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.