

EXHIBIT C - EUT INTERNAL PHOTOGRAPHS

For model BF-TD511 UHF:

EUT – Cover off View 1




EUT – Cover off View 2



EUT – Cover off View 3



EUT – Cover off View 4



EUT – Cover off View 5




EUT – Cover off View 6




EUT – Cover off View 7




EUT – Main Board Top View



EUT – Main Board Top Shielding off View




EUT – Main Board Bottom View




EUT –Switch Board Top View




EUT –Switch Board Bottom View



EUT –Side Keyboard View




EUT –Accessory Connector View




EUT –FPC keyboard Top View




EUT –FPC keyboard Bottom View



EUT -Speaker View




EUT -LCD board View



EUT –IC Mains View 1



EUT –IC Mains View 2



For model BF-TD512 UHF:

EUT – Cover off View 1



EUT – Cover off View 2



For model BF-TD510 UHF:

EUT – Cover off View 1



EUT – Cover off View 2




EUT – Battery View



EUT – Charger Cover off View



EUT – Charger Main Board Top View



EUT – Charger Main Board Bottom View

