

Figure 1: Hera601 Product Label

Application

The Hera label will be applied in 3 locations per product:

1 On the rear of product, centered horizontally & vertically (2) On the product carton in the designated printed box 3 1 per product on the bulk carton

Figure 2: Hera601 Label Positioning