



**BLUE
SYNC
OR3**

Your easy-to-use reference for getting the most out of your product

USER GUIDE

Enjoy

FREE REGISTRATION

FREE PRODUCT REGISTRATION

Protect your investment and take advantage of this free product warranty.

YOU MUST REGISTER WITHIN 30 DAYS

of purchase to receive full warranty coverage and access to special offers.

www.AccessoryPower.com/warranty

Other products you may



*So convenient.
So comfortable.
Sounds so good.*



Version 2.1

GOgroove™ AirBAND™ Bluetooth® Headset

- > Adjustable headband design and plush padding offers complete comfort
- > Built-in, rechargeable battery for up to 8 hours of wireless music on one charge
- > Supports hands-free calling - equipped with Bluetooth v2.1



**Equip your car stereo
with Bluetooth.**

FlexSMART™ X2

- > Wirelessly transmit phone calls and music through your car stereo
- > Compatible with any Bluetooth enabled device
- > Controller provides full access to music and phone settings
- > Charging port for USB devices

need, want and enjoy!

Level Up Your Gaming Experience.



ENHANCE™ Touch Screen Joystick

- > Suction mounting is safe, removable and repositionable
- > For use with games with virtual gamepad controls
- > Compatible with all capacitive touch screen tablets and smartphones
- > Adds the control of a physical joystick for precise gaming

Every Product



Every Day

For information, special offers and more, please visit:

AccessoryPower.com/promo

Thank you for purchasing the
GOgroove™ BlueSync™ OR3
Portable Bluetooth® Speaker

Now you can take dynamic, wireless audio wherever you go! This compact, powerful speaker easily travels from room to room, to the office or even the beach. The long-lasting, internal, Li-polymer rechargeable battery will keep the beat for up to 16 hours. Designed with the optimal ratio of power and portability, the BlueSync OR3 is the perfect musical companion!

What's in the Box


- a- BlueSync OR3 Speaker
- b- USB charging cable
- c- Carrying bag



Product Diagram

- 1- Play/Pause button
- 2- Next/Volume + button
- 3- Back/Volume - button

- 4- LED function indicator
- 5- LED power indicator
- 6- Charging port



Operating Instructions

Charging the BlueSync OR3:

Connect the (b) *USB charging cable* into a powered USB port. Plug the barrel end of the (b) *USB charging cable* into the (6) *Charging port* on the **BlueSync OR3**. The (5) *LED power indicator* will illuminate red to indicate power flow. When the **BlueSync OR3** is fully charged the (5) *LED power indicator* will illuminate green.

Pairing your mobile Bluetooth device to the BlueSync OR3:

Pairing instructions may differ depending on the device you are using. Please refer to your device's user manual for further information.

1- Pairing

- a. Make sure that your mobile device is within at least 3 feet of the speaker when trying to pair and that the **BlueSync OR3** is powered off.
- b. Enter pairing mode on the **BlueSync OR3** by pressing and holding the (1) *Play/Pause button* for 10 seconds until the (4) *LED function indicator* flashes rapidly. You will hear 3 tones when the speaker turns on and then 2 short tones when it enters PAIRING MODE.
- c. Access the Bluetooth settings in your mobile device and select SEARCH/SCAN FOR DEVICES. Your mobile device will begin to search for a Bluetooth signal.
- d. You will see the name "**BlueSync OR3**" appear in the device list. Select it to pair, and if a password or PIN is needed enter the numbers "0000".
*****You may have to then select BlueSync OR3 and press "CONNECT".**
- e. After a successful connection has been made, you will hear a short tone and the (4) *LED function indicator* will flash every 4 seconds. If you do not pair the speaker within 5 minutes the power will automatically shut off.

Operating Instructions continued

2- Reconnecting

- a. The **BlueSync OR3** will automatically connect to the last Bluetooth device that was paired when powered on.
- b. If the **BlueSync OR3** does not automatically reconnect, make sure that your mobile device is within at least 3 feet of the speaker and access the Bluetooth settings in your mobile device. Select "**BlueSync OR3**" from the device list. If your device is not listed, start from the beginning of "Pairing your mobile Bluetooth device to the **BlueSync OR3**" instructions above.
- c. After a successful connection has been made, you will hear a short tone and the (4) *LED function indicator* will flash every 4 seconds.

Playing Music:

- 1- Make sure that your Bluetooth A2DP (audio/music) mobile device is paired with the **BlueSync OR3**.
- 2- Simply begin playing music on your mobile device and you should hear the music play through the **BlueSync OR3**. If the music is low, increase the volume on the **BlueSync OR3** first, then adjust your device's volume.
- 3- You can control the volume and playback directly from the **BlueSync OR3**.
 - a. Next track- briefly press the (2) *Next/Volume + button*.
 - b. Previous track- briefly press the (3) *Back/Volume – button*.
 - c. Increase volume- press and hold the (2) *Next/Volume + button*.
 - d. Decrease volume- press and hold the (3) *Back/Volume – button*.

Operating Instructions: Button Reference

| Button | Press Sequence | Function |
|---------------------|----------------|--------------------|
| (1) Play / Pause | Quick press | Play / Pause Music |
| (3) Back / Volume - | Quick press | Previous track |
| (3) Back / Volume - | Press and hold | Volume down |
| (2) Back / Volume + | Quick press | Next track |
| (2) Back / Volume + | Press and hold | Volume up |
| (1) Play / Pause | Quick press | ON / OFF |

Troubleshooting

Why can't I get the BlueSync OR3 to pair with my mobile device?

- Please make sure **BlueSync OR3** is in PAIRING MODE and that the (4) LED function indicator is flashing rapidly. If not, please turn off the **BlueSync OR3** and start from the beginning of "Pairing your mobile Bluetooth device to the **BlueSync OR3**" instructions above.

Why can't I play music via Bluetooth using my mobile device?

- Please make sure that your Bluetooth mobile phone supports A2DP (audio/music) connection, and that it has been paired properly.
- Please make sure only one device is paired to the **BlueSync OR3** at a time.

Why can't I hear any sound?

- Please make sure that **BlueSync OR3** is fully charged and powered on. The (4) LED function indicator should flash every 5 seconds.
- Please make sure that the volume on your mobile device and the **BlueSync OR3** are loud enough.
- Please make sure that your mobile Bluetooth device is within 30 feet of the **BlueSync OR3**. The maximum Bluetooth range may vary in different environments and on the paired device.

Cautions

- Please only use this product in the manner described in this manual
- Please keep out of the reach of children
- Do not expose the unit to dust, water, or extreme temperatures
- Do not attempt to disassemble the product

Product Specifications

Speaker: 3w, 70mm driver

Frequency Range: 20HZ-20kHz

Bluetooth profile: 2.1 +EDR, A2DP

Operating distance: 30 feet

Battery: Built in Li-polymer 3.7v, 1300mAh

Power: 3.3V-4.2V, 80mA

Charge time: 4 hours

Dimensions: 4.75 x 4.75 x 7.75 inches (121 x 121 x 121mm)

Weight: .99 lbs (450 grams)



Learn more about this and other
quality Accessory Power products



www.AccessoryPower.com



[Facebook.com/AccessoryPower](https://www.facebook.com/AccessoryPower)



[Twitter.com/AccessoryPower](https://twitter.com/AccessoryPower)

**For more on the BlueSync OR3
+ tips and tricks please visit
AccessoryPower.com/videos**



ACCESSORY POWER
WESTLAKE VILLAGE, CALIFORNIA

WWW.ACCESSORYPOWER.COM
MADE IN CHINA

©2012 ACCESSORY POWER

All trademarks and brand names are the property of their owners.



Please Always Recycle

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF warning statement: the device has been evaluated to meet general RF exposure requirement , The device can be used in portable exposure condition without restriction.