

# **User Manual**

## Tablet PC

# Content

Introduction.....	1
1. Power On/Off.....	2
2. Desktop.....	2
3. Standby mode (Screen off mode) /Unlock the screen.....	2
4. System settings.....	3
5. How to connect/disconnect the device with/from the computer.....	9
6. How to install Applications(.apk file) into the device.....	10
7. How to make desktop icons.....	11
8. Communication.....	13
Specification.....	19

## Introduction

**This manual contains important safety precautions and information of correct use.**

**Please be sure to read this manual carefully before use so as to avoid any accidents.**

Do not place the product in hot, wet or dusty environment, especially in summer, do not leave the product inside a car with all windows closed.

Avoid dropping, impacting or shaking the product violently, otherwise it may cause damages or malfunctions.

Select a proper volume to avoid ear problem when using earphones.

Do not cross the road or drive vehicles, using headphones to avoid traffic accident.

Be sure to use the provided chargers and accessories in the package.

Be sure to charge the product when the following situations take place:

- The battery icon shows lower or empty.
- System automatically shut down and it turns off soon after restart.
- Operation keys do not respond properly.
- The device shows  on the bottom right corner.

## 1. Power On/Off

- Long press power button to turn on/off the device, it may take a minute to boot the device.
- Short press power button to turn on/off the screen. (Standby mode Refer to 3 below)

## 2. Desktop

- After turning on the device, desktop displays with shortcut icons and arrow panel at the middle of bottom.



## 3. Standby mode (Screen off mode) /Unlock the screen

- Short press the power button to turn on/off the screen(standby mode on/off)
- After standby mode , slide the lock icon in order to unlock the screen.




#### 4. System settings

- On the desktop, press menu button and select settings



##### 1.1 Wireless & Networks & Bluetooth



**WIFI** : Press WIFI to turn on /off Set up each setting as you like.

Press Wi-Fi settings, then the device will automatically search the available Wi-Fi signals. Select the network you want to connect with.

## 1.2 Sound



### 1.3 Display



Set up each setting as you like.

### 1.4 Storage



Check device memory and micro SD card status. Unmount SD card – Unmount the SD card for safe removal.

### 1.5 Battery

Check battery usage status.



### 1.6 Apps

Manage downloaded or running applications.



**Downloaded** : All installed application are listing.

Keep pressing an application to manage.

Press Uninstall to uninstall the selected application.

**Running** : View and control currently running services.

### 1.7 Account & sync

Create your account. After connecting Wi-Fi network, the e-mailing system synchronizes your account with the device. Emails are automatically downloaded into the device.

### 1.8 Location services

**Google's location service** : Let apps use data from sources such as WiFi and mobile networks to determine your approximate location

### 1.9 Security

**Screen lock** : Protect your device from unauthorized use by creating a personal


screen unlock pattern. Make passwords visible – Show password as you type.

**Unknown sources** : If you want to allow installation of non-Market Applications, Press Unknown sources and presses OK



**Install from SD card** : Install encrypted certificates from SD card.

#### 1.10 Language & input



**Language** : Choose your preferable language.

**Keyboard & input method** : Change keyboard & keyboard settings.

On Language & input settings, if you need other languages besides English on keyboard, press the relevant keyboard and enter the chosen Keyboard settings, select Keyboards, press the language you need.

**1.11 Date & time**

Set date & time and format

**1.12 Developer options**


Set options for application development

**1.13 About tablet**

See status, legal information, ETC

**5. How to connect/disconnect the device with/from the computer**

On main desktop, connect the device with the PC, touch right side of the status bar on the bottom of desktop




Press “USB connected”, select “Turn on USB storage”. The device is recognized at

Explorer of the computer. Now you can use it as an external storage



After finishing your work, press “Turn off USB storage” to unmount it.



## 6. How to install Applications(.apk file) into the device

### Method 1.

1. Connect the device with internet. See above [1.Wireless & networks] in order

to connect internet.

2. Run “Getjar” and search the applications you want to install.

3. Follow the instruction on the screen for installation.

#### **Method 2.**

1. On your computer, search application file(.apk) that you want to install into the device

2. Download the file(.apk) into your computer

3. Connect the device with your computer.

See above [How to connect/disconnect the device with/from the computer.]

4. Copy and paste .apk file into the device and disconnect it from your computer.

5. Run “File browser” and .apk file that was copied into the device.

6. Press the file to install and follow the instruction on the screen.

#### **7. How to make desktop icons**

Press the upper right side icon of desktop, the pop-up displays.





### Shortcuts

Long press your desired APK icon and put it on the desktop.



### Widgets

Press Widgets and press your desired icon to put it on the desktop.

### Wallpaper

Long press the desktop, press Wallpapers and select one of categories of wallpaper.

Select one you desire and press Set wallpaper.

## 8. Communication

### Phone

To use calling functions, tap **Phone** from application list.



#### ◆ Make calls

To make calls, you can use any of the three ways:

- Enter numbers by using the virtual numeric keypad on the screen
- Make a call from call log.

● Make a call from contacts.

◆ Answer a call

To answer a call, drag the circled button to the green button.

◆ Decline or end a call

To decline a call, drag the circled button to the red button.

To end a call in progress, tap the red button.

◆ Call settings



To change call settings, tap the option button at the upper right.

#### 1. Quick responses

Quick response is a feature to reject the call with the predefined messages.

Tap one of the pre-written messages to be displayed when you want the call to be rejected, then tap **OK**.

#### 2. Fixed Dialing Numbers

If FDN mode is activated, your device will restrict outgoing calls, except for the numbers stored in the FDN list.

**Contacts** Tap People from application list to access contacts.

- **Groups:** List all your contacts by group.
- **All:** List all your contacts saved in the device memory.
- **Favorites:** List the contacts that you have set as favorites or the contacts that you have sent message to or dialed.

(To set the contact as your favourites, select  at the title bar.)

◆ **Add new contact**

1. Access **People**.
2. Tap .
3. Enter necessary fields.
4. Tap **DONE**.

◆ **Edit a contact**

1. To edit a contact, scroll to the contact you want to change.
2. Tap the option button at the upper right, then select **Edit**.
3. Change necessary fields.
4. Tap **DONE**.

◆ **Import/Export contacts**

1. **Import from the SIM card**

To copy the contacts from the SIM card, tap the option button at the upper right and then select **Import/Export**→**Import from the SIM card**, select contacts, and then select **Import**.

2. **Import from SD card**

To import contact files (in vcf format) from a memory card to your device, tap the option button at the upper right and then select **Import/Export**→**Import from SD card**, select a memory location and contact files to import and select **OK**.

3. **Export to SD card**

To export contacts from your device to a memory card, tap the option button at the upper right and then select **Import/Export**→**Export to SD card**, select **OK** to confirm.

◆ **Search for contacts**



1. Tap the search icon at the title bar from contact list screen, enter the desired information, then your device shows the result.
2. Tap the search icon at the upper left from home screen, enter the contact's name or number, your device shows the result immediately.

## **Messaging**

Learn to create and send a text or multimedia message, and view or manage messages that you

have sent or received.

◆ **View messages**

1. Tap **Messaging** from application list.
2. Tap the message to view the detailed information.

◆ **Create and send SMS**

1. Tap **NEW MESSAGE**.
2. In **To** field, enter the recipient's mobile phone numbers manually. If you enter more than one number, separate the numbers with a comma.
3. In **Type message**, enter the text of the message.
4. Select **Send** to send the message.

In **To** field, enter the recipient's mobile phone numbers or email addresses manually.

If you enter more than one number or email, separate them with a comma.

1. In **Type message** field, enter the text of the message.
2. Select **Send** to send the message.

Specification		
O/S	Android 4.2.2	
CPU	BOXCHIP A20 Cortex A7 1.2GHz	
RAM & Flash	DDR3 1GB, 16GB flash	
Display	7" LCD 1024*600 Capacitive multi-touch panel	
IO PORTS	Micro SD slot	2 / 4 / 8 / 16GB
	Audio port	3.5φ earphones
	USB port	1 x 5pin micro USB port (support USB host and OTG)
	HDMI	HDMI
	SIM card slot	1 x SIM card slot
	Button	Power, VOL-, VOL+, reset,
Speaker	1.5W, Frequency response : 20Hz – 20k Hz, N/S : >85%	
G-sensor	Yes	
Camera	Front 0.3M pixel, Rear 2.0M pixel	
Wi-Fi	802.11b/g/n	
Power	Adaptor 5V -2A	
Battery	3.7V Li-Polymer	
Dimension	187x 106 x 9mm	
Charging time	by charger	approx. 3~4hours

**FCC warning statement.**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Specific Absorption Rate (SAR) information:**

This 7inch Tablet PC meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: MT-708 i (FCC ID: 2AASXMTNTB708788I) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the body is 0.52W/kg. This device was tested for typical body-worn operations with the back of the handset kept 0 cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 0 cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

**Body-worn Operation**

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 0 cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.