



# WIDTV1

## Mobile TV Receiver



**audiovox®**  
**mobiletv**

**WIRELESS  
LIVE LOCAL TV  
ON THE GO**

**User's Guide**



## **FCC Caution:**

"Changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment."

## **FCC Statements:**

"This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation"

"This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."





# Table of Contents

Introduction.....	2
Package Contents .....	3
System Requirements .....	4
Safety Instructions .....	5
Installation Instructions .....	6
Troubleshooting .....	8
Warranty.....	10
Notes .....	12



## Introduction

Thank you for purchasing the Audiovox WIDTV1 Mobile TV Receiver. The WIDTV1 is an efficient, user-friendly accessory for viewing live free-to-air TV content on Android® and Apple® devices, and is compatible with ATSC-M/H digital TV transmissions. The WIDTV1 creates its own private WiFi network for use by the mobile device and there is no need to search for an internet connection or use cellular data airtime. Download the free SianoTV application from the App Store or Google Play®, watch TV and enjoy.

To ensure the best performance, please read this manual carefully.

## Highlights

- View live TV (ATSC-M/H broadcasts) on your Android® and Apple® smartphone or tablet
- Pause, rewind, and record programs while viewing
- Access to detailed programming information (Electronic Programming Guide - EPG)
- Equipped with internal battery for over 4 hours of viewing time





## Package Contents

1. WIDTV1 Mobile TV Receiver
2. Telescopic Antenna
3. User's Guide
4. Micro USB Cable





## System Requirements

Supports the following Apple® devices: iPad2®, New iPad®, iPad Mini®, iPhone 4S®, iPhone 5®, and iPod 5® with iOS 5.1.X or newer.

Designed for use with advanced Android® devices using Android® 4.0.3 or newer, such as Samsung® Galaxy S2/S3, Note/Note2, Google® Nexus 7, Asus® TF300, HTC® One and others (WIDTV1 was tested with a select list of manufacturers and models only).

### Trademark Notice:

Andriod® / Nexus® / Google Play® and Google® are all trademarks of Google® Inc. All rights reserved. Google® and the Google® Logo are registered trademarks of Google® Inc. in the U.S. and other countries.

Asus® is a registered trademark of ASUSTeK Computer in the U.S. and/or other countries.

HTC® is a registered trademark of HTC® Corporation. All Rights Reserved. HTC®, the HTC® logo, HTC® Innovation, ExtUSB, and HTC® Care are trademarks and/or service marks of HTC® Corporation.

iPad®/ iPad 2®/ iPad Mini®/ iPhone®/ iPhone 4S®/ iPhone 5®/ iPod® are all trademarks of Apple® Computer, Inc., registered in the U.S. and other countries.

SAMSUNG® is a trademarks of Samsung® Group, Samsung® Electronics in the United States or other countries.

Wi-Fi® is a registered trademark of the Wireless Fidelity Alliance, Inc.





## Safety Instructions

- Read this entire User's Guide to ensure proper usage.
- Keep this User's Guide handy for future reference.
- Do not use the WIDTV1 while driving, cycling, or operating any moving vehicle or apparatus. This is dangerous and may result in a traffic violation and may be illegal in some areas.
- Keep the WIDTV1 away from all liquids and liquid-prone locations such as sinks, bathtubs, rain, and other sources of moisture. Moisture can cause electric shock as with any electronic device.
- Clean the WIDTV1 with a soft lint-free cloth.
- Do not allow children under the age of 6 to use the WIDTV1 unsupervised.
- Never force any connector into the WIDTV1 USB and antenna ports. Ensure that your connectors are the identical shape and size before you connect.
- Do not disassemble, crush, short-circuit or incinerate the WIDTV1 battery, as it may cause fire, injury, burns or other hazards.





## Installation Instructions

1. Charge the WIDTV1 fully before initial operation.
  - Plug the supplied USB charging cable into a USB port.
  - Insert the Micro USB charging cable connector into the WIDTV1 and the red "Charge" LED will illuminate.
  - When the WIDTV1 is fully charged, the red "Charge" LED will turn OFF.  
**NOTE: While the WIDTV1 is in use, the blue "Power" LED will turn off 10 minutes before the battery is depleted.**
2. Download and install the free SianoTV application from the App Store or Google Play®.
3. Turn the WIDTV1 ON by sliding the ON/OFF switch to the ON position. The blue "Power" LED will illuminate.
4. Release the telescopic antenna from its docked position and swivel it to an upright position.
5. Extend the telescopic antenna and place the WIDTV1 in a suitable location close to a window or outdoors where it will not be subjected to moisture or excessive heat.





## Installation Instructions

6. Set up the WiFi connectivity on your mobile device's settings/connectivity manager.
  - Use your mobile device at a maximum of 7 meters distance from the WIDTV1
  - Go to the Network Manager on your mobile phone or tablet and search for the "Audiovox Mobile TV xxxxxx" network. **NOTE: The "xxxxxx" notation in the network name represents the last six digits of the WIDTV1 MAC address.**
  - Enter the password – "audvx" (all lowercase).
7. Activate the "SianoTV" application.
8. For initial use only, channels must be scanned;  
go to:  
*SianoTV --> Select Settings --> Choose your location--> Scan Channels.*
9. Once the channel scan is complete, press DONE .
10. Select "Live TV", press and watch TV channels. To switch from one channel to another, swipe fingertips over the screen either right or left.



# Troubleshooting

## *Cannot connect to WIDTV1's WiFi*

- Turn OFF the WIDTV1 and then turn it ON again
- Go to the network manager in your phone or tablet and search for the "WIDTV1" network
- Verify that the correct password was entered
- Make sure that the mobile device is not in flight/airplane mode

## *Poor Image Quality*

- Try to improve the antenna location (near a window if possible)
- Scan for available stations with strong signals again

## *Application is stuck or is not working*

- a.) Close the SianoTV application
- b.) Turn the WIDTV1 OFF
- c.) Turn the WIDTV1 ON and reconnect to the WiFi network
- d.) Open the SianoTV application again

**NOTE: Channels must be scanned again:**

*SianoTV-->Select Settings --> Choose your location--> Scan Channels*

## *Scan did not locate a TV channel*

- Try to improve the antenna location (near a window if possible)
- For up-to-date information on what stations may be available in your area, please visit [www.dyle.tv/coverage map](http://www.dyle.tv/coverage map) .





# Troubleshooting

## *"no signal" message appears*

- Try to improve the antenna location (near a window if possible)
- For up-to-date information on what stations may be available in your area, please visit [www.dyle.tv/coverage map](http://www.dyle.tv/coverage map) .

## *Application does not recognize the device*

- Close the application, turn the WIDTV1 OFF and back ON , reconnect to the WiFi and open the application again

## *While using WIDTV1, TV reception suddenly stops*

- Make sure that the blue LED is ON
- If it is not on, this means that the battery is either empty or has only 10 more minutes of operation; charge the battery until the red charging LED turns OFF.

## **NOTES:**

- a.) Reception inside buildings may be sub-optimal; it is recommended that the WIDTV1 is placed near a window.
- b.) Application may ask for a "Firmware Upgrade". If asked, accept request. WIDTV1 will reboot and when complete. **NOTE: Channels must be scanned again: SianoTV --> Select Settings --> Choose your location--> Scan Channels.**
- c.) Using more than one device with WIDTV1? It is recommended selecting "Forget" WIDTV1 network on previous device's WiFi manager before connecting WIDTV1 to another device.





**AUDIOVOX®**  
ELECTRONICS CORP.

### **12 MONTH LIMITED WARRANTY**

AUDIOVOX ELECTRONICS CORPORATION (the Company) warrants to the original retail purchaser of this product that should under normal use and conditions, be proven defective in material or workmanship within 12 months from the date of original purchase, such defect(s) will be repaired or replaced with new or reconditioned product (at the Company's option) without charge for parts and repair labor.

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to an approved warranty station or the Company at the address shown below.

This Warranty does not extend to the elimination of externally generated static or noise, to costs incurred for installation, removal or reinstallation of the product, or to damage to speakers, accessories or electrical systems.

This Warranty does not apply to any product in the opinion of the Company that has been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.





This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER MUST BE BROUGHT WITHIN 24 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

AUDIOVOX ELECTRONICS CORPORATION, 150 MARCUS BLVD., HAUPPAUGE, NEW YORK 11788  
[www.audiovoxproducts.com](http://www.audiovoxproducts.com)

Warranty: 128-7351

11





## Notes







For Customer Service  
Visit Our Website At

**[www.audiovoxproducts.com](http://www.audiovoxproducts.com)**

Product Information, Photos,  
FAQ's Owner's Manuals

© 2013 AUDIOVOX, 150 Marcus Blvd. Hauppauge, NY 11788

**128-9242**

