

正面



Holl WiFi Disk Box R200 User Quick Guide

©2011 Copyright by HOLL Technology Co.,Ltd. All rights reserved.

Thanks for purchasing Holl Wireless Disk -- BOX R200.
Holl R200 are the newest generation of multi-functional wireless hard drive.
The product collect of wireless router, wireless storage, wireless multi-media,
USB3.0 mobile hard disk and portable source function.
Let your phone and PC easily share the contents of wireless box anytime and where.

Functionality :

Mobile HDD

Built-in 320GB/500G/1TB optional, Super speed USB3.0 interface

Wireless storage

Support contents auto-sorting, read, delete, share and transfer.

Wireless multi-media

Support multiple streaming media formats of wireless player

Wireless router

Support wireless AP and wireless Relay function.

Portable source

Built-in 6000mAh polymer battery, charging for smart devices.


(The battery will be 4500mAh if you choose 1T storage HDD)

I. Accessories:

BOX R200 package list as below :

1. Box R200: 1pcs
2. Micro USB2.0 Data and charging cable: 1pcs
3. Micro USB3.0 cable: 1 pcs
4. User Quick Guide: 1pcs
5. Certificate of approval and warranty card: 1pcs

II. Product port view



- ① USB2.0 port
- ② Reset button
- ③ Micro USB3.0 port
- ④ RJ45 port
- ⑤ Micro USB2.0 port
- ⑥ Power button
- ⑦ WiFi LED
- ⑧ HDD LED
- ⑨ WLAN LED
- ⑩ Battery capacity LED

1. Hardware interface Introductions.

No.	Port	Logo	Function details
①	USB2.0		charge for your smart devices when Box shut down. After connect smart device, press the power button, the battery capacity LED will be bright. Box discharging
②	Reset button		When BOX is working, press reset button, system parameters will be restored the factory setting, then device will be automatically shutdown.
③	Micro USB3.0		USB3.0 and USB2.0 are all available, when the PC or Notebook isn't support USB3.0, device will be automatically adapte to USB2.0 When BOX shutdown, connect Micro USB3.0 to PC or Notebook, BOX will be a mobile harddisk
④	RJ45 PORT		Support dynamic and static IP. Default is DHCP. If change to static IP, It can be set up by Smart phone's Holl APP through Wifi. When RJ45 connected, the left yellow LED will bright (Link), when date transfer, the right green LED will be flashing (ACT)

No.	Interface	Logo	Function details
⑤	Micro USB2.0		Micro USB2.0 charge port, support input current 5V@2A. Please be sure to use attached standard Micro USB2.0 cable when charging.
⑥	Power button		support battery capacity display, or device start or shutdown function Long press power button, if battery LED isn't light, Be sure to recharge the battery

III. Device Usage

1. Holl APP download and install

Holl App support Android, iOS, Windows Operating System

Please download Holl App by your smart device.

iOS Holl App download and install	iOS
Please search "Holl" in "App Store" or scan QR code to download Holl App. Click "Install", Holl App will be installed successfully into smart devices (iPhone/iPad)	

反面

Android HotSpot App download and install

Please search "hot" in "Android market" or scan QR code to download HotSpot App, then click "Install". HotSpot App will be installed successfully into Android smart device



Android

Windows HotSpot App download and install

Please download HotSpot App for Windows from Hot website www.hot.com.cn or scan QR code download, then click "Install". HotSpot App will be installed successfully into PC or Notebook



Windows

1. Start device

Long press power button  about 3 seconds, Wi-Fi LED flash three times then release power button. After 40 seconds, Wi-Fi LED flashing, the device begin to start.


2. HotSpot using guide

1. **Wi-Fi connection:** After BOK work, open HotSpot App, click "setting" "WLAN" can connect Wi-Fi successfully.
 2. **Wi-Fi:** iPhone or Tablet internet storage data.
 3. **"Wi-Fi"** is HotSpot Wi-Fi storage data.

When the Box is working, long press power button about 3 seconds, WIFI LED go out, device shut down.



- a) Press power button , battery LED will light .user can judge battery capacity by displaying the number of LED. After 10 seconds, the light will go out.

	Lighting LED number	battery capacity meaning
 Battery Capacity LED	None	Please charging
	one	lower than 25%
	Two	between 25% and 50%
	Three	between 50% and 75%
	Four	between 75% and 100%



Connect BOX to Phone or Tablet with Micro USB2.0 cable , press power button to start discharging for phone or Tablet.



Two ways of charging for Box when the battery is running out :

2. Computer USB port charge : Connect BOX and computer or Notebook USB port with micro USB2.0 cable



1. Please choose adapter charger voltage is 5V (current between 600 and 2000mA) ,such as the charger adapter of iPhone, iPad, Android device ;
2. Charging time : about 4.5-5.5 hours if charger adapter is 5V 2000mA,
3. Please don't discharging for others devices at the same time when charging for Box

Welcome users download the latest firmware on Holi website.

- Loggy firmware to Box, Arise Box will, run Host App by phone, and click setting -> Firmware update. App will check device firmware version and update. When update is completed, device will automatically shut down
- More details please login HOLL website: www.holl.com.cn or call 400-8853-882**

More details please login Holi website: www.holi.com.cn or call 400-8853-882