


# Instructions

## SPECIFICATIONS

- ☆ Frequency: 49.82-49.90MHz
- ☆ Battery size: 1 x 6F22 (9V)


## A QUICK LOOK AT YOUR DEVICE



## BATTERY INSTALLATION

Please insert battery as below:

- ☆ Loosen the screw on the battery door (No. 1).
- ☆ Remove battery door.
- ☆ Insert battery with correct polarities (+/-) indicated (No. 2).
- ☆ Replace the battery door and tighten the screw.



## OPERATIONS

- ☆ Switch the unit on by turning ON/OFF switch.
- ☆ Push the talk switch for talking, release it for receiving.

## CAUTIONS

Weak battery can leak and severely damage the unit.

Always remove battery when the unit will not be used for a long time.

Replace battery immediately when it becomes weak.

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- \_\_\_ Reorient or relocate the receiving antenna.
- \_\_\_ Increase the separation between the equipment and receiver.
- \_\_\_ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- \_\_\_ Consult the dealer or experienced radio/ TV technician for help.



## **WARNING:**

CHOKING HAZARD - Small parts.  
Not for children under 3 years.