

Egreat

Quick Install Guide






Accessories

- 1. Remote control 1pcs
- 2. Quick install guide 1pcs
- 3. Warranty card 1pcs
- 4. QC passed 1pcs
- 5. Power adaptor 1pcs

Note: Different model accessories will be different, depend on the product

1

Connections



Note: Different model connection will be different, depend on the product


2

Connect the product to the TV




Note: Please turn off the TV when you connect the product to TV

Connecting the product via HDMI cable




Connecting the product via AV cable



3

Connect the power adaptor




2

Connect the product to the TV




Note: Please turn off the TV when you connect the product to TV

Connecting the product via HDMI cable




Connecting the product via AV cable



3

Connect the power adaptor



4

Setting up the video source



5

Setting up the network


① Setting up the Wi-Fi network



- 1). Press "Home" button of the product remote control, choose the "Settings--->Wi-Fi", then press "OK" button
- 2). Choose the current network connection from the list, please input the password if there is the password on your router
- 3). Press "Home" button back to the main menu, when the icon "Wi-Fi" (on the top right corner) is bright, the network is work

② Setting up the ethernet network

Connect the product to the network connection of your router via network cable




- 1). Press "Home" button of the product remote control, chooses the "Settings--->Network --->Ethernet---->DHCP", press "OK" button , tick '√' on the right icon, the system will be auto obtain the IP address 
- 2). Press "Home" button back to the main menu, when the icon "Network" (on the bottom-left corner) is bright, the network is work

 Note

⑧ You can choose the "Static IP", input the IP address and save it


6

Place the batteries in the remote control



7

Explanation of the remote control



No	Icons	Functions
①		Power: button to turn on or turn off the product
②		Mouse button: Press this button to enter the mouse state, press again to quit
③		Mute button: Used to mute the sound
④		Arrow buttons: 1. Buttons to navigate through the menu options 2. Under the video playback state, the left and right arrow button can be used to control the playback 3. Under the mouse state, can be used to move the mouse cursor
⑤		OK button: Confirm button
⑥		Menu button: This button is the multifunction key, according to the menu prompts ,it will have different functions
⑦		Home button: Return to the main menu
⑧		Return button: Return to the previous step
⑨		Volume buttons: Used to increase or decrease the sound volume
⑩		Previous/next buttons: Used to select the next (video)file
⑪		TV button,Press this key into Live TV,it will jump to the channel if it is live TV state
⑫		VOD button,Press this key into VOD

More information on our website www.egreatworld.com

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

***RF warning for Mobile device:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Note:

Our products only provide hardware support for the network functions, all other services of the network function are depending on the sources of the internet. Egreat will not be responsible for the internet content and website services' content, nor the genuine, legality and stability of internet resources, discontinuous or close business that responsible for any loss cause. Any changes of the sources of internet content are not our product function changed, nor is the reason for the product's features missing.

Egreat

SHENZHEN EGREAT TECHNOLOGY CO.,LTD

**Address: 4/F,1 Building,Sha San Chuang Ye Industry
Park,Sha Jing,BaoAn,ShenZhen,China**

Tell number:+86-0755-81490211/81490212

Support email:supporten@egreatworld.com

Website:<http://www.egreatworld.com>